

Mattel HHJ75

Mattel Disney Pixar Lightyear Zurg Action Figure Instruction Manual

Model: HHJ75

INTRODUCTION

Thank you for purchasing the Mattel Disney Pixar Lightyear Zurg Action Figure. This manual provides important information for the safe and proper use of your new toy. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INFORMATION

WARNING: This product contains or may generate small parts that can pose a choking hazard to infants. Not suitable for children under 3 years of age.

- Always supervise children during play.
- Keep packaging materials away from children to prevent suffocation.
- Inspect the toy regularly for any damage or loose parts. Discontinue use if damaged.

PRODUCT OVERVIEW

The Zurg Action Figure is a detailed collectible and play toy inspired by Disney Pixar's Lightyear movie. It features multiple points of articulation for dynamic posing.

Key Features:

- Large-scale figure, approximately 12 inches (30.48 cm) tall.
- 11 movable joints for various poses.
- Movie-authentic detailed design.
- Durable plastic construction.



Figure dimensions: Zurg action figure standing upright, with a measurement line indicating a height of 12 inches (30.48 cm).

SETUP

The Zurg Action Figure comes pre-assembled and ready for play. No assembly is required.

1. Carefully remove the figure from its packaging.
2. Dispose of all packaging materials responsibly.





The Zurg action figure displayed in its original retail packaging, ready to be unboxed.

OPERATING INSTRUCTIONS

The Zurg Action Figure is designed for imaginative play. It features multiple points of articulation for posing.

Posing the Figure:

- Gently move the arms, legs, and head at their joint points to create various poses.
- Avoid excessive force when moving joints to prevent damage.
- The figure has 11 points of articulation, allowing for a wide range of motion.



The Zurg action figure posed dynamically with one arm raised, demonstrating its articulation.



The Zurg action figure in a wide, action-ready stance, showcasing its movable leg joints.

MAINTENANCE

Proper care will ensure the longevity of your Zurg Action Figure.

- **Cleaning:** Wipe the figure with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent fading or material degradation.
- **Handling:** Avoid dropping the figure or applying excessive force to its parts.

TROUBLESHOOTING

Problem	Solution
Joints are stiff.	Gently manipulate the joint back and forth. If still stiff, ensure no foreign objects are obstructing movement. Do not force.

Problem	Solution
Figure appears dirty.	Clean with a soft, damp cloth as described in the Maintenance section.
Parts are loose or broken.	Discontinue use. Contact Mattel customer support for assistance.

SPECIFICATIONS

Brand: Mattel

Model Name: Zurg Action Figure

Model Number: HHJ75

Character: Zurg (Disney Pixar Lightyear)

Material: Plastic

Color: Multicolor (predominantly purple and grey)

Dimensions (L x W x H): Approximately 10.2 x 19.7 x 30.5 cm (4 x 7.75 x 12 inches)

Recommended Age: 3 years and up

Number of Articulation Points: 11

Assembly Required: No

Batteries Required: No

GTIN/UPC: 194735069224

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Mattel website. Keep your proof of purchase for any warranty claims.

Mattel Official Website: www.mattel.com