

[manuals.plus](#) /

› [Nokia](#) /

› [Nokia G100 Android 12 Unlocked Smartphone User Manual](#)

Nokia TA-1430

Nokia G100 Android 12 Unlocked Smartphone User Manual

Model: TA-1430 | Brand: Nokia

1. GETTING STARTED: SETUP

1.1 What's in the Box

Your Nokia G100 package includes the following items:

- Nokia G100 Smartphone
- USB Cable
- Charger
- Quick Start Guide
- Safety Booklet



In the Box

Charger
Quick Start Guide
Safety Booklet
USB Type C Cable





Image Description: A flat lay showing the Nokia G100 smartphone, a USB Type-C cable, a wall charger, and a SIM ejector tool, all neatly arranged next to a box labeled 'In the Box' with a list of contents.

1.2 Carrier Compatibility

The Nokia G100 is designed for universal compatibility with various mobile network providers. Confirmed compatible carriers include:

- AT&T
- Verizon
- T-Mobile
- Boost
- Cricket
- H2O Wireless
- Metro
- Mint
- Net10
- Simple Mobile
- Tracfone

Please note that carrier network coverage is dependent upon the carrier's service area. It is recommended to confirm compatibility with your chosen carrier prior to use.



Lights! Camera! Action!

The triple rear camera features a 13 MP main, an 8 MP ultra-wide, and a 2 MP depth lens, while the front-facing 8 MP camera is perfect for high quality selfies and video chats.

HMD Global Oy is the exclusive licensee of the Nokia brand for phones & tablets. Nokia is a registered trademark of Nokia Corporation. Google and Android are Trademarks of Google LLC. Qualcomm Mobile Platform is a product of Qualcomm Technologies, Inc. and/or its subsidiaries. All specifications, features and other product information provided are subject to change without notice. Variations on offering may apply. Check local availability.


1 Battery has limited recharge cycles and battery capacity reduces over time. Eventually the battery may need to be replaced.

Image Description: The Nokia G100 smartphone displayed alongside a grid of logos for various mobile network carriers, illustrating its universal compatibility.

2. OPERATING YOUR NOKIA G100

2.1 Display and User Interface

The Nokia G100 features a large 6.52-inch HD+ screen with an edge-to-edge display, providing clear viewing. It runs on the latest Android 12 operating system, offering an optimized and secure user experience.



4G Connectivity

Qualcomm® Snapdragon™ 662 Mobile Platform



Memory & Storage

4 GB RAM, 128 GB Internal storage, Single SIM



Edge-to-edge

6.52" HD+ screen with edge-to-edge display

Image Description: A close-up of the Nokia G100's screen and side profile, highlighting its 4G connectivity, 4GB RAM/128GB storage, and 6.52-inch edge-to-edge HD+ display.

2.2 Performance

Powered by a Snapdragon CPU running at 2 GHz, the Nokia G100 ensures smooth performance for daily tasks and applications. It comes with 4 GB of RAM and 128 GB of internal storage, expandable up to 512 GB.

2.3 Camera Features

Capture your moments with the Nokia G100's versatile camera system:

- **Triple Rear Camera:** A 13MP primary lens, enhanced with AI-powered night mode for clear photos in low light.
- **Front-Facing Camera:** An 8MP camera perfect for selfies and video calls.



13 MP triple-rear camera

With enhanced AI powered night mode and 8 MP front-facing.



Image Description: A detailed view of the Nokia G100's rear, showcasing its triple-rear camera setup with a 13 MP main sensor, accompanied by text highlighting its AI-powered night mode and 8 MP front-facing camera.




Image Description: A person holding the Nokia G100 horizontally, taking a photo with the triple rear camera, with text overlay 'Lights! Camera! Action!' and a description of the camera features.

2.4 Security Features

The Nokia G100 includes advanced security options to protect your device and data:

- **Side-Mounted Fingerprint Sensor:** Conveniently unlock your phone with your fingerprint.
- **Face Unlock:** Use facial recognition for quick and secure access.



Image Description: A split image showing the Nokia G100's screen playing a video on one side and a close-up of the phone's side with a fingerprint icon, illustrating the side-mounted fingerprint sensor and face unlock features.

2.5 Software Updates

Keep your Nokia G100 up-to-date with the latest software for improved performance and security.

Your browser does not support the video tag.

Video Description: An animated guide demonstrating how to check for and install software updates on a Nokia phone, showing the steps to navigate through settings to the system update option.

3. MAINTENANCE: BATTERY LIFE

The Nokia G100 is equipped with a 5000 mAh Lithium Polymer battery, designed to provide extended usage. It offers up to 3 days of standby time with data and 18 hours of talk time. A full charge typically takes 3 hours.



Image Description: A close-up of the Nokia G100's screen displaying the battery settings, showing 100% charge and an estimated 'About 2 days left', emphasizing its long-lasting battery.

3.1 Rebooting Your Phone

If your phone is unresponsive or experiencing minor issues, a simple reboot can often resolve the problem.

Your browser does not support the video tag.

Video Description: An animated guide illustrating how to perform a hard reboot on a Nokia phone by pressing the volume up and power buttons simultaneously until the phone vibrates.

4. TROUBLESHOOTING

4.1 Charging Issues

If your Nokia G100 is not charging, follow these steps:

- Check Power Source:** Ensure the issue is not with the power outlet. Try plugging your phone into a different outlet.
- Inspect Cable and Port:** Examine the charging cable and the phone's charging port for any visible

damage or debris.

3. **Reboot and Reconnect:** Turn your phone off completely and then plug it into the charger. If the battery is fully drained, it may take 2-3 minutes before it starts charging.

4.2 Contacting Support

If you encounter issues that cannot be resolved with the provided troubleshooting steps, Nokia offers customer support.

Your browser does not support the video tag.

Video Description: An animated guide demonstrating how to contact Nokia mobile support via chat through the 'My phone' app, showing the steps to initiate a support chat.

5. SPECIFICATIONS

Model Name	G100
Item Model Number	TA-1430
Operating System	Android 12.0
CPU Model	Snapdragon
CPU Speed	2 GHz
RAM	4 GB
Memory Storage Capacity	128 GB
Expandable Memory	Up to 512 GB
Screen Size	6.52 Inches
Resolution	1600 x 720
Refresh Rate	60 Hz
Rear Camera Features	13MP Triple Camera (Primary, Ultra-wide, Depth)
Front Camera Features	8MP
Battery Capacity	5000 mAh
Phone Standby Time (with data)	3 days
Phone Talk Time	18 Hours
Charging Time	3 Hours
Connectivity Technologies	Bluetooth, USB, Wi-Fi

Special Features	Built-In GPS, Expandable Memory, Fast Charging Support, Supports USB OTG, Fingerprint Sensor, Face Unlock
Audio Jack	3.5 mm
Color	Polar Night
Product Dimensions	6.5 x 3 x 0.4 inches
Item Weight	6.8 ounces
Manufacturer	HMD Global Oy
Date First Available	August 25, 2022

6. WARRANTY AND SUPPORT

For further assistance, including warranty information and additional support resources, please visit the official Nokia website or use the My Phone app on your device.

You can find more tips and support at Nokia.com/mobile-support.

© 2024 Nokia. All rights reserved.