

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Zowill](#) /
- › [Zowill Keyless Entry Door Lock with 2 Lever Handles - Instruction Manual](#)

Zowill DK01-L

Zowill Keyless Entry Door Lock with 2 Lever Handles - Instruction Manual

MODEL: DK01-L

Brand: Zowill

1. INTRODUCTION

Thank you for choosing the Zowill Keyless Entry Door Lock. This electronic keypad deadbolt offers enhanced security and convenience for your home or property. With features like auto-locking, anti-peeping password protection, and multiple access methods, this lock is designed to provide a secure and smart living experience. This manual will guide you through the installation, operation, and maintenance of your new lock.



Image: Zowill Keyless Entry Door Lock with 2 Lever Handles, Oil Rubbed Bronze.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning installation:

- Exterior Assembly (Keypad Deadbolt)
- Interior Assembly
- Mounting Plate
- Latch

- 2 Standard Backup Keys
- Mounting Screws
- Latch Screws
- 2 Lever Handles
- Installation Instructions (this manual)
- Programming Instructions

3. TOOLS NEEDED (NOT INCLUDED)

- 4x AA Batteries
- 1x PH2 Phillips Screwdriver

4. SPECIFICATIONS

Feature	Detail
Brand	Zowill
Model Name	DK01-L-Bronze-01
Color	Oil Rubbed Bronze
Material	Aluminum
Lock Type	Pin Tumbler
Item Dimensions (L x W x H)	11.6 x 7.1 x 3.5 inches
Item Weight	4.44 pounds
Special Features	Anti-Peeping Password, Auto-Lock, Back-Lit Keypad, Keyless Entry, One-Touch Lock
Controller Type	Keypad
Control Method	Touch, Hand Control
Door Thickness Compatibility	1.38"-2" (35-50mm)
Bore Hole Diameter	2.1" (54mm)
Bore Hole Backset	2.4" or 2.8" (60mm or 70mm)
Durability	100,000 usage test, 2000N appearance pressure resistance, ANSI Grade 3 certified
Weatherproof Rating	IP54 (operates from -22°F to 158°F)

Easy to Install & Program

Please don't put in the battery before the installation is completed.



Image: Detailed product dimensions and door compatibility requirements.

5. SETUP AND INSTALLATION

Follow these steps carefully to install your Zowill Keyless Entry Door Lock. For a visual guide, please refer to the installation video below.

Your browser does not support the video tag.

Video: Zowill Keypad Deadbolt Installation Guide. This video provides a step-by-step walkthrough of the installation process for the Zowill keypad deadbolt.

Installation Steps:

1. Step 1: Adjust and Fix the Latch

Adjust the latch length if necessary (60mm or 70mm backset). Ensure the latch is oriented correctly (UP arrow pointing upwards) and secure it to the door edge with the provided latch screws.




Image: Proper orientation and installation of the latch.

2. Step 2: Install the Exterior Assembly (Front Lock)

Carefully insert the exterior assembly into the door, ensuring the lock cylinder is correctly aligned with the latch. Pass the cable through the door hole.

3. Step 3: Install the Mounting Plate

Position the mounting plate on the interior side of the door, aligning it with the exterior assembly. Secure it using the mounting screws. Ensure the cable passes through the opening in the mounting plate.

4. Step 4: Install the Interior Assembly

Connect the cable from the exterior assembly to the interior assembly. Carefully tuck the excess cable into the designated space. Attach the interior assembly to the mounting plate and secure it with the remaining screws. Do not install batteries until installation is complete.

5. Step 5: Test the Deadbolt Functionality

Insert 4 AA batteries (not included) into the interior assembly. Close the battery cover. Test the deadbolt by manually turning the thumb turn on the interior assembly and by entering the default master code (12345678) on the exterior keypad to ensure it locks and unlocks smoothly.

The lock is designed for easy installation and can be installed on both left and right-handed doors. Only a screwdriver is needed for most of the process.



Image: The lock can be easily installed on both left and right-handed doors.

6. OPERATING INSTRUCTIONS

Keyless Entry:

The Zowill lock supports multiple ways to access your property:

- **User Codes:** Program up to 20 unique user codes for family members, friends, or regular visitors.
- **One-Time Code:** Generate a temporary code for single use, ideal for service personnel or deliveries.
- **Backup Keys:** Two physical keys are provided for traditional access.

Share Access, Keyless Entry



Image: Keyless entry options including 20 user codes and one-time codes.

Auto-Lock Function:

Prevent accidental unlocking or forgetting to lock the door:

- **Automatic Locking:** Set the lock to automatically re-lock after 10 to 99 seconds.
- **One-Touch Locking:** Press and hold any key on the keypad for 2 seconds to instantly lock the door.

Auto-lock & One-touch Locking




Image: Auto-lock feature with adjustable time and one-touch locking.

Anti-Peeping Password:

Enhance security by entering random digits before or after your actual code. This prevents others from guessing your code by observing fingerprints on the keypad.



Image: Illustration of the anti-peeping password feature using random digits.

Mute Mode:

Activate mute mode to silence keypad tones, providing quiet entry and exit, especially useful during late hours or when others are sleeping.

Product Dimension




Image: Mute mode feature for quiet operation of the lock.

Vacation Mode:

When going on an extended trip, activate vacation mode to disable all user codes, ensuring no unauthorized access while you are away. Only the master code or physical key can unlock the door in this mode.




Image: Vacation mode feature, ideal for securing your home when away.

No App / No Wi-Fi Required:

This lock operates independently without the need for a smartphone app or Wi-Fi connection, simplifying setup and usage.



Image: The lock functions without requiring a mobile application or Wi-Fi connectivity.

7. MAINTENANCE

Battery Life and Alerts:

The Zowill lock is designed for long battery life, typically lasting over 1 year with 4 AA batteries (not included). The lock features a low battery alert function to notify you when it's time to replace the batteries.



Image: Information on battery life, low battery alerts, and backlit keypad.

Weather Resistance:

With an IP54 weatherproof rating, your Zowill lock is protected against dust and splashing water, ensuring reliable operation in various weather conditions. It is designed to withstand temperatures ranging from -22°F to 158°F.

No App / No Wi-Fi Required



Image: The lock's IP54 waterproof rating and temperature operating range.

8. TROUBLESHOOTING

For common issues and solutions, please refer to the official Troubleshooting Guide provided by Zowill. This guide covers topics such as programming errors, lock malfunctions, and battery-related problems.

You can access the Troubleshooting Guide here: [Zowill Troubleshooting Guide \(PDF\)](#)

If you encounter issues not covered in the guide, please contact Zowill customer service for assistance.

9. WARRANTY AND SUPPORT

Zowill offers at least a 1-year product warranty and lifetime customer service for this keyless entry door lock. For warranty claims or technical support, please contact Zowill directly through their official channels.