

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko Electric Height Adjustable Standing Desk 100 x 60 cm User Manual

Devoko 0427

Devoko Electric Height Adjustable Standing Desk 100 x 60 cm User Manual

Model: 0427

INTRODUCTION

Thank you for choosing the Devoko Electric Height Adjustable Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.



Image: The Devoko Electric Standing Desk in a light wood finish with white legs, featuring a laptop, monitor, keyboard, mouse, and headphones. This image illustrates the desk's functionality and aesthetic.

IMPORTANT SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly.
- Keep children and pets away from the desk during operation.
- Do not overload the desk. The maximum load capacity is 70 kg (154.32 lbs).
- Ensure there are no obstructions in the desk's path during height adjustment.
- Only use the provided power adapter.
- If the desk malfunctions, disconnect it from the power supply and contact customer support.

SETUP AND ASSEMBLY

The Devoko Electric Standing Desk is designed for simplified installation, typically taking around 30 minutes. Detailed instructions and numbered parts are included in the packaging.

Unpacking and Component Check

Carefully unpack all components and verify against the parts list provided in your package. Ensure no parts are missing or damaged.



Image: An overhead view showing all the components of the Devoko adjustable desk laid out, including two desktop panels, metal frame parts, screws, and assembly tools. This illustrates the '2 work surfaces' and 'pre-drilled holes' mentioned in the image text.

Assembly Steps

1. Assemble the desk frame according to the provided instruction manual.
2. Attach the two desktop panels to the frame. Pre-drilled holes ensure accurate alignment and no additional drilling is required.
3. Install the control panel on the underside of the desk.
4. Connect all necessary cables as per the wiring diagram.
5. Attach the cable management port and headphone hook for an organized workspace.
6. Adjust the leveling feet to ensure the desk is stable on uneven surfaces.



Image: A detailed view highlighting the desk's thoughtful design features, including a convenient headphone hook, cable ties for wire management, a wire pass-through hole on the desktop, and adjustable feet for stability.

Height Adjustment

The Devoko Electric Standing Desk offers an electric height adjustment range from 71 cm to 119 cm, accommodating users of various heights. Use the up and down arrow buttons on the control panel to adjust the desk to your desired sitting or standing position.




Image: A close-up of the desk's control panel, showing the up and down buttons, and two memory preset buttons (1 and 2). The image also highlights the ultra-silent operation (below 50dB) during height adjustment.

Memory Presets

The integrated control panel features 2 pre-programmed memory buttons. This allows for easy switching between your preferred sitting and standing heights. To set a memory position:

1. Adjust the desk to your desired height using the up/down arrows.
2. Press and hold one of the memory buttons (1 or 2) until you hear a beep or see the display flash, indicating the position is saved.
3. To recall a saved position, simply press the corresponding memory button.



Multifuncional Control Panel




Image: A detailed view of the desk's multifunctional control panel, showing the up and down movement arrows and the two memory preset buttons (1 and 2). This panel allows for precise height adjustments and quick recall of favorite positions.

Anti-Collision Safety System

The Devoko Electric Standing Desk is equipped with an anti-collision protection system. If the desk encounters an obstacle while lowering, it will immediately stop and automatically reverse by 2 cm. This feature helps prevent accidents and ensures the safety of users and objects around the desk.

MAINTENANCE

To ensure the longevity and optimal performance of your Devoko standing desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. The galvanized coating on the feet resists corrosion and is easy to clean.
- **Cable Management:** Regularly check and organize cables to prevent tangles and damage. Utilize the integrated cable management port and headphone hook.
- **Inspection:** Periodically inspect all screws and connections to ensure they are tight. Retighten if necessary.
- **Motor Care:** The durable motor is designed for 50,000 lifts and includes overheat protection. No special maintenance is required for the motor itself, but ensure it is not exposed to excessive moisture or extreme temperatures.



Image: A close-up of the desk surface with a stack of balanced stones, illustrating the desk's stability. The image also implies the surface is easy to clean, contributing to overall maintenance.

TROUBLESHOOTING

If you encounter any issues with your Devoko Electric Standing Desk, please refer to the following common solutions:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected, motor error, overload.	Check power connections. Reduce weight on the desk. Perform a reset (refer to manual for specific reset procedure, often involves holding down arrow).
Uneven height adjustment	Uneven load, loose connections.	Distribute weight evenly. Check and tighten all frame connections.
Anti-collision system triggers frequently	Obstruction, sensitivity setting.	Ensure no objects are in the desk's path. If the issue persists, contact support for potential sensitivity adjustment.

Problem	Possible Cause	Solution
Unusual noise during operation	Loose parts, motor issue.	Check for any loose screws or components and tighten them. If the noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact Devoko customer support for professional assistance.

SPECIFICATIONS

- **Brand:** Devoko
- **Model Number:** 0427
- **Color:** Beige
- **Product Dimensions (L x W x H):** 100 cm x 60 cm x 71-119 cm
- **Material:** Metal, Engineered Wood
- **Features:** Ergonomic, Adjustable, Electric, Anti-collision system, Memory presets
- **Item Weight:** 18 Kilograms
- **Maximum Load Capacity:** 70 kg (154.32 lbs)
- **Noise Level:** ≤55dB during operation
- **Frame Construction:** Industrial steel frame with T-shaped enlarged feet for stability.



Image: A diagram illustrating the dimensions of the desk (100cm length, 60cm width, 73cm-118cm height range) and showcasing the available color options for the desktop (wood grain, light wood, white, black) and the steel frame upgrade.



Construction robuste en acier

Le cadre industriel en acier maintient la table plus stable

- Cadre de table en acier
- cales de renforcement pour augmenter la stabilité
- Taille du cadre 65*45mm
- épaisseur 1,2 mm
- Entretoise de pied de 5 cm pour plus de stabilité
- joints antidérapants augmentent la friction

Image: A detailed diagram showcasing the robust steel construction of the desk frame. It highlights the steel table frame, reinforcement wedges for stability, frame size (65x45mm), 1.2mm thickness, 5cm foot spacer for added stability, and non-slip joints to increase friction.

WARRANTY INFORMATION

Specific warranty details are not provided in the product information. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage and terms.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Devoko Electric Height Adjustable Standing Desk, please contact the seller or manufacturer directly. Detailed contact information can usually be found on your purchase receipt or the product packaging.

You can also visit the [Devoko Brand Store](#) for more information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BBZ3VBDV>

More documents and user manuals: <https://manuals.plus/>