

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Insta360](#) /

> [Insta360 X3 Mic Adapter Instruction Manual](#)

Insta360 CINSBAQ/A

Insta360 X3 Mic Adapter Instruction Manual

Model: CINSBAQ/A

PRODUCT OVERVIEW

The Insta360 X3 Mic Adapter is designed to enhance the audio capabilities of your Insta360 X3 camera. It allows for the connection of an external 3.5mm microphone while simultaneously enabling USB-C charging, ensuring uninterrupted recording sessions with superior sound quality. Its compact design is optimized to remain invisible in 360-degree footage.

WHAT'S IN THE BOX

- 1x Mic Adapter

SETUP

Follow these steps to properly set up your Insta360 X3 Mic Adapter:

1. **Remove Camera's Lock Cover:** Before attaching the Mic Adapter, ensure you unplug and remove the camera's USB Type-C port lock cover. This cover protects the port and must be detached to allow the adapter to connect.
2. **Attach Mic Adapter:** Align the Mic Adapter with the USB Type-C port on your Insta360 X3 camera. The buckle design ensures a secure connection. Gently push until it clicks into place.
3. **Connect External Microphone:** Plug your 3.5mm external microphone into the audio port on the Mic Adapter.
4. **Connect Charging Cable (Optional):** If needed, connect a USB Type-C charging cable to the charging port on the Mic Adapter to power your camera during use.




Image: Side view of the Insta360 X3 Mic Adapter, showing its compact form factor and the USB-C connector.



Image: The Mic Adapter connected to an Insta360 X3 camera, illustrating how it integrates with the device.

OPERATING

Once the Mic Adapter is securely attached and your external microphone is connected, your Insta360 X3 camera will automatically recognize the external audio input. You can then proceed with recording as usual.

- **Enhanced Audio:** The external microphone will capture higher quality audio compared to the camera's built-in microphones, ideal for vlogging, interviews, or environments with background noise.
- **Invisible in 360 Footage:** The design of the Mic Adapter ensures it remains completely invisible when shooting in 360-degree mode, maintaining the immersive quality of your footage.
- **Simultaneous Charging:** The integrated USB Type-C charging port allows you to power your

camera while recording with the external microphone, extending your shooting time.



Image: An example of 360-degree footage where the Mic Adapter is not visible, demonstrating its seamless integration.

Record and charge.

Type-C and 3.5mm audio ports so you can charge Insta360 X3 while connected to your mic.



Image: The Mic Adapter connected to the Insta360 X3, with both an external microphone and a USB-C charging cable plugged in.

MAINTENANCE

- **Not Waterproof:** The Mic Adapter itself is not waterproof. Using it in wet conditions may damage the adapter and potentially your camera. Always ensure the adapter is dry before connecting it to your camera.
- **Storage:** Store the Mic Adapter in a dry, cool place away from direct sunlight and extreme temperatures when not in use.
- **Cleaning:** Use a soft, dry cloth to clean the adapter. Avoid using harsh chemicals or abrasive materials.

TROUBLESHOOTING

If you encounter any issues with your Insta360 X3 Mic Adapter, please consider the following:

- **No Audio Input:** Ensure the Mic Adapter is securely connected to the camera and the camera's original USB Type-C port lock cover has been removed. Verify that your external microphone is properly plugged into the adapter's 3.5mm port and is functioning correctly.
- **Charging Issues:** Check that the USB Type-C charging cable is fully inserted into the adapter's charging port and connected to a working power source.
- **Loose Connection:** The buckle design is intended for a firm fit. If the adapter feels loose, ensure it is correctly aligned and fully clicked into place.

For further assistance, please refer to the official Insta360 support resources or contact their customer service.

SPECIFICATIONS

Product Dimensions	1.18 x 0.55 x 1.06 inches (30.4 x 14.2 x 26.5 mm)
Item Weight	0.212 ounces (5.7g)
Model Number	CINSBAQ/A
Compatible Devices	Insta360 X3 Camera
Connector Type	Auxiliary (3.5mm audio), USB Type-C
Color	Black
Manufacturer	Arashi Vision Inc.

NOTES

- The Mic Adapter is **not waterproof**. Exercise caution in wet environments.
- Always remove the camera's original USB Type-C port lock cover before installing the Mic Adapter.

WARRANTY AND SUPPORT

For warranty information, technical support, or any product-related inquiries, please visit the official Insta360 website or contact their customer service directly. Keep your purchase receipt for warranty claims.