

[Manuals.plus](#) /

› [Kintion](#) /

› Kintion Portable Night Light User Manual

Kintion XL-XY11

Kintion Portable Night Light User Manual

Model: XL-XY11

PRODUCT OVERVIEW

The Kintion Portable Night Light is a versatile and safe LED lamp designed for various uses, including nurseries, baby rooms, kids' rooms, and general home ambiance. It features dimmable 8-color lighting and a built-in 1800mAh rechargeable battery for portability and convenience.



Figure 1: Kintion Portable Night Light in use, providing soft illumination on a nightstand.

This night light is constructed from toy-grade ABS and PC materials, ensuring it is 100% safe for children. Its compact design makes it easy to place anywhere, and the adhesive backing allows for flexible mounting options.



Figure 2: The Kintion Night Light is available in multiple vibrant colors, enhancing any room's atmosphere.

PACKAGE CONTENTS

- 1 x Kintion Portable Night Light
- 1 x Type-C Power Cable

SPECIFICATIONS

Brand	Kintion
Model Number	XL-XY11
Dimensions	3.1"D x 3.1"W x 2.6"H
Item Weight	5.3 ounces (0.15 Kilograms)

Material	Acrylonitrile Butadiene Styrene (ABS), PC
Battery Capacity	1800mAh Lithium Polymer (included)
Charging Time	Approx. 3 hours
Working Time	Up to 10-250 hours (depending on brightness/mode)
Light Source	LED
Brightness	40 Lumen
Voltage	5 Volts
Control Method	Touch
Special Features	Rechargeable, Dimmable, RGB Color Changing

Setup and Installation

Charging the Night Light

Before first use, fully charge the night light. Connect the provided Type-C power cable to the light's charging port and a suitable USB power source (e.g., computer, USB wall adapter). The lamp body will indicate charging status:

- **Red:** Charging
- **Green:** Fully Charged

1800 mAh

Battery Capacity

3 hours

Charging Time

25-160 hours

Working Time



Figure 3: Charging the Kintion Night Light. The indicator light turns red when charging and green when fully charged.

Mounting Options

The Kintion Night Light can be placed on any flat surface or mounted using the included adhesive velcro. This allows for flexible placement on desktops, walls, or under cabinets.

1. Ensure the surface is clean and dry.
2. Peel off the protective film from one side of the 3M adhesive velcro.
3. Attach the adhesive side firmly to the desired mounting location.
4. Align the night light with the velcro on the mounted surface and press firmly to secure.
5. The light can be easily removed from the velcro for charging or repositioning.



Figure 4: Steps for mounting the Kintion Night Light using the adhesive velcro.

OPERATING INSTRUCTIONS

The Kintion Night Light features three touch-sensitive buttons for easy operation: MODE, ON/OFF, and +/-.

- **ON/OFF Button:** Short press to turn the light on or off.
- **MODE Button:** Short press to cycle through the 8 available colors and color-changing modes (Warm White, Dim White, Bright White, Red, Green, Blue, Three Colors Change, Gradient).
- **+/- Button:** Long press to adjust brightness from 10% to 100%. The lamp remembers your last brightness setting.



Figure 5: Adjusting brightness on the Kinton Night Light. Long press the +/- button for dimming.

Using Velcro on a clean wall can realize a movable wall lamp



Figure 6: The Kintion Night Light offers 8 distinct color modes, including static colors and dynamic transitions.

Brightness Memory Function

The lamp is designed to remember your last used color and brightness settings. When you turn the lamp on again, it will resume with the previously selected color and brightness level.

MAINTENANCE

- To clean the night light, gently wipe it with a soft, dry cloth.
- Do not use abrasive cleaners or solvents, as these may damage the surface.
- Keep the device away from water and excessive moisture. It is not waterproof.
- Store in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the night light using the provided Type-C cable.
Light flickers or is dim.	Low battery or incorrect brightness setting.	Charge the night light. Long press the +/- button to increase brightness.
Cannot change color mode.	MODE button not pressed correctly or device malfunction.	Ensure you are short-pressing the MODE button. If issue persists, contact customer support.
Adhesive mount not holding.	Surface not clean or smooth, or adhesive worn out.	Clean the surface thoroughly before applying. If adhesive is worn, replace with new 3M adhesive velcro.

WARRANTY AND SUPPORT

Kintion products come with a 24-month warranty. For any product inquiries, technical support, or warranty claims, please contact Kintion customer service. We are committed to providing 24-hour email service online.

You can visit the official Kintion store for more information and support:[Kintion Official Store](#)



Figure 7: Kintion offers dedicated customer support and a 24-month warranty.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question