

[Manuals.plus](#) /

› [DRYGUY](#) /

› DryGuy Force Dry Sport Electric Dryer Instruction Manual (Model 11620)

DRYGUY 11620

DryGuy Force Dry Sport Electric Dryer Instruction Manual

PRODUCT OVERVIEW

The DryGuy Force Dry Sport dryer is designed for efficiently drying wet, moist, or sweaty shoes, boots, sports equipment, and outdoor gear. It utilizes forced air and gentle heating to dry most items within 1-2 hours. Its robust design accommodates heavy boots, helmets, and other bulky items, while its compact size allows for placement in various locations. The unit features a digital display, push-button controls, and an automatic shutoff timer for convenience and energy conservation. Regular use helps prevent odors and extends the lifespan of your gear by mitigating moisture and bacteria damage.



Image: The DryGuy Force Dry Sport Electric Dryer, a compact unit with two drying ports.

Key Features:

- **Powered, Forced Air, Heated Drying:** Effectively removes moisture from various items.
- **Dual Port Design:** Dries up to two items simultaneously within 1-2 hours, depending on conditions.
- **Digital Display & Timer:** Features a push-button digital display and a 3-hour automatic shut-off timer.
- **Odor Prevention:** Heated air helps eliminate moisture, reducing odors and preventing gear deterioration.
- **Safe & Gentle:** Gentle heating circulation prevents shrinking, warping, or damage to delicate materials.
- **Long Power Cord:** A 6-foot power cord offers flexible placement options.
- **Collapsible Design:** Allows for convenient storage when not in use.

SETUP INSTRUCTIONS

The DryGuy Force Dry Sport is designed for easy assembly and use. Follow these steps to set up your dryer:

1. **Unpack the Unit:** Carefully remove all components from the packaging.

2. **Position the Dryer:** Place the main unit on a stable, flat surface in a well-ventilated area. Ensure the 6-foot power cord can reach an electrical outlet without strain.
3. **Extend Drying Ports:** The drying ports are collapsible for storage. Gently pull each port upwards until it locks into its extended position. The ports can also rotate to accommodate different footwear sizes and shapes.
4. **Plug In:** Insert the power cord into a standard electrical outlet. The unit is now ready for use.



MULTIPLE DRYING OPTIONS

Forced Air +
Convection Heat

Image: A person demonstrates placing a shoe onto one of the extended drying ports of the DryGuy dryer.



PORTS CAN EXTEND AND ROTATE TO DRY VARIOUS FOOTWEAR SIZES & SHAPES

Image: The drying ports of the DryGuy dryer are shown extended and rotated, illustrating their adjustability for various footwear.

OPERATING INSTRUCTIONS

The DryGuy Force Dry Sport offers simple controls for effective drying:

- 1. Place Items on Ports:** Position your shoes, boots, gloves, or other gear onto the extended drying ports. Ensure the items are securely placed to allow air circulation inside.
- 2. Set Drying Time:** Use the timer dial on the front of the unit to select the desired drying duration. The timer can be set for up to 180 minutes (3 hours). The unit will automatically shut off once the set time has elapsed.
- 3. Select Heat Setting:** Use the 'NO HEAT' / 'HEAT' switch to choose your preferred drying mode.
 - **HEAT:** Provides gentle, warmed air for faster drying and odor elimination. Recommended for most wet items.
 - **NO HEAT:** Circulates ambient air, suitable for delicate materials or items that only require airing out.
- 4. Start Drying:** Once the time and heat settings are selected, the dryer will begin operation.

5. **Monitor Progress:** Check your items periodically. Drying times may vary based on material, moisture level, and ambient conditions.



3-HOUR SHUTOFF TO MANAGE DRY TIME

Image: A close-up view of the DryGuy dryer's control panel, showing the digital timer and the 'NO HEAT' / 'HEAT' switch.



Image: The DryGuy dryer with an icon indicating its whisper-quiet fan operation.

MAINTENANCE

To ensure optimal performance and longevity of your DryGuy Force Dry Sport dryer, follow these simple maintenance guidelines:

- **Cleaning:** Periodically wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Clear Air Vents:** Ensure that the air intake and exhaust vents are free from dust, lint, or other obstructions to maintain proper airflow.
- **Storage:** When not in use, collapse the drying ports for compact storage. Store the unit in a cool, dry place.

SPECIFICATIONS

Feature	Detail
Brand	DRYGUY

Model Name	DryGuy Force Dry Dryer - Digital
Model Number	11620
UPC	096506116208
Form Factor	Top Load
Access Location	Top Load
Capacity	2 Items (e.g., 2 shoes/boots)
Color	Gray, Orange
Material Type	Plastic
Item Weight	2.9 Pounds
Item Dimensions (D x W x H)	10.5"D x 8.7"W x 4.4"H
Included Components	Shoe Dryer Unit
Smart Home Compatibility	Not Smart Home Compatible



Image: The DryGuy Force Dry Sport dryer with its key dimensions (depth, width, height) clearly labeled.

WARRANTY & SUPPORT

The DryGuy Force Dry Sport Electric Dryer is backed by a manufacturer's warranty to ensure your satisfaction and product reliability.

- **Manufacturer's Warranty:** The product is free of manufacturing defects for 365 days after the purchase date.
- **Additional Protection Plans:** Extended protection plans may be available for purchase separately. Please refer to your retailer for details on 2-Year, 3-Year, or Complete Protect options.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact DryGuy customer service through their official website or the retailer where the product was purchased.