

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [XDOBO](#) /

› [XDOBO X8 Portable Bluetooth Speaker User Manual](#)

XDOBO X8

XDOBO X8 Portable Bluetooth Speaker User Manual

MODEL: X8

1. Introduction

Thank you for choosing the XDOBO X8 Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your device. The X8 speaker features a powerful 60W output, True Wireless Stereo (TWS) connectivity for an immersive audio experience, a 3-band equalizer, advanced DSP technology for enhanced bass, and an IP65 waterproof rating, making it suitable for various environments.

Please read this manual carefully before use and retain it for future reference.

2. Package Contents

Ensure all items are present upon unpacking:

- XDOBO X8 Bluetooth Speaker Unit
- USB Type-C Charging Cable (Power adapter not included)
- 3.5mm Stereo Audio Cable
- Simple Instruction Manual (Japanese)

3. Product Layout and Controls

Familiarize yourself with the speaker's buttons and ports for optimal operation.



Image: Top view of the XDOBO X8 speaker showing the control panel buttons.

This image displays the control buttons located on the top surface of the speaker. From left to right, these include the Power button, Mode (M) button, Play/Pause button, Volume Down/Previous Track button, Volume Up/Next Track button, and Voice Assistant button.

产品信息



按键信息

M(模式转换)键 减号键 语音助手键

Image: Side view of the XDOBO X8 speaker showing the input ports.

This image illustrates the various input ports on the side of the speaker, including the Type-C fast charging port, TF card slot, and 3.5mm AUX input port.

Button Functions:

- **Power Button:** Long press to power ON/OFF. Double press to toggle TWS mode ON/OFF.
- **M (Mode) Button:** Short press to switch between input modes (Bluetooth, TF Card, AUX). Long press to cycle through equalizer settings.
- **Play/Pause Button:** Short press to Play/Pause music. Short press to Answer/End calls. Double press to Redial the last number.
- **Volume Down / Previous Track Button (-):** Short press for Volume Down. Long press for Previous Track.
- **Volume Up / Next Track Button (+):** Short press for Volume Up. Long press for Next Track.
- **Voice Assistant Button:** Short press to activate your device's voice assistant (Siri, Google Assistant, etc.).

4. Setup

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB Type-C cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status. Always use the included USB cable for charging.

4.2 Powering On/Off

- **To Power On:** Long press the **Power** button until you hear an audible prompt.
- **To Power Off:** Long press the **Power** button again until you hear an audible prompt.

4.3 Bluetooth Pairing

The XDOBO X8 speaker is compatible with most Bluetooth-enabled devices (smartphones, tablets, PCs).

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your device, enable Bluetooth and search for available devices.
3. Select "XDOBO X8" from the list of devices.
4. Once paired, the speaker will emit a confirmation sound, and the LED light will remain solid.

4.4 True Wireless Stereo (TWS) Pairing

Connect two XDOBO X8 speakers for a stereo sound experience.



Image: Two XDOBO X8 speakers connected via TWS, providing stereo sound with a computer monitor.

This image demonstrates the TWS functionality, showing two XDOBO X8 speakers positioned for stereo playback, enhancing the audio experience for media consumption.

1. Ensure both XDOBO X8 speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will become the primary speaker), double press the **Power** button. The speaker will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. A confirmation sound will indicate successful

TWS pairing.

- Now, connect your device to the primary speaker via Bluetooth as described in section 4.3. Both speakers will play audio in stereo.

4.5 AUX and TF Card Mode

The speaker supports audio playback via a 3.5mm AUX cable and from a TF (Micro SD) card.

- AUX Mode:** Insert the 3.5mm audio cable into the AUX port on the speaker and connect the other end to your audio source. Short press the **M** button to switch to AUX mode.
- TF Card Mode:** Insert a TF card (up to 64GB, supporting MP3, FLAC, WAV formats) into the TF card slot. Short press the **M** button to switch to TF card mode. The speaker will automatically begin playing audio from the card.

5. Operating Instructions

5.1 Basic Audio Controls

- Play/Pause:** Short press the **Play/Pause** button.
- Volume Adjustment:** Short press the **+** button to increase volume, and the **-** button to decrease volume. Note that volume levels on your connected device and the speaker may be independent.
- Next Track:** Long press the **+** button.
- Previous Track:** Long press the **-** button.

5.2 Equalizer (EQ) Settings

The XDOBO X8 features 3 distinct equalizer settings to customize your audio experience, including enhanced bass. Long press the **M** button to cycle through the available EQ modes. You will hear an audible prompt indicating the current EQ setting.



Image: XDOBO X8 speaker with visual representation of sound waves and passive radiators.

This image highlights the speaker's large passive radiators and full-range drivers, which contribute to its powerful and deep bass output, a key feature enhanced by the DSP technology.

5.3 Hands-Free Calling

When connected via Bluetooth, you can use the speaker for hands-free phone calls.

- **Answer/End Call:** Short press the **Play/Pause** button.
- **Redial Last Number:** Double press the **Play/Pause** button.

6. Maintenance

To ensure the longevity and optimal performance of your XDOBO X8 speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents.
- **Water Resistance:** The speaker has an IP65 waterproof rating, meaning it is protected against dust ingress and low-pressure water jets from any direction. Do not submerge the speaker in water. Ensure the charging port cover is securely closed when exposed to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.

7. Troubleshooting

If you encounter issues with your XDOBO X8 speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided USB Type-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; Bluetooth is off on device; Speaker is already connected to another device.	Ensure speaker is powered on and flashing (pairing mode). Turn Bluetooth on your device. Disconnect from other devices or restart the speaker.
No sound or low volume.	Volume too low on speaker or device; Incorrect input mode; Speaker is muted.	Increase volume on both the speaker and your connected device. Press the 'M' button to ensure the correct input mode (Bluetooth, AUX, TF Card).
TWS pairing fails.	Speakers are already connected to other devices; Incorrect TWS pairing procedure.	Ensure both speakers are disconnected from other devices. Follow the TWS pairing steps in section 4.4 carefully.
Distorted sound at high volume.	Volume too high.	Reduce the volume on both the speaker and your connected device.

Problem	Possible Cause	Solution
Loud, repetitive warning sound (low battery).	Battery is critically low.	Charge the speaker immediately. The warning sound indicates the battery is about to run out.

8. Specifications

Detailed technical specifications for the XDOBO X8 Portable Bluetooth Speaker:

Feature	Specification
Brand	XDOBO
Model Number	X8
Product Dimensions	22 x 9.5 x 7.2 cm (approx. 8.66 x 3.74 x 2.83 inches)
Weight	Approx. 860g (1.9 lbs)
Wireless Communication Technology	Bluetooth
Connectivity Technology	AUX, Bluetooth
Speaker Maximum Output Power	60 Watts
Waterproof Rating	IP65
Control Method	Touch buttons
Recommended Uses For Product	Computer, Smartphone
Power Source	Power Cord (Rechargeable Battery)
Battery Required	Yes
Mounting Type	Tabletop Mount
Special Features	Bluetooth, Portable, Wireless

9. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact XDOBO customer service through the retailer where you purchased the product. Keep your proof of purchase for warranty claims.

Important Notes

- Product specifications and appearance are subject to change without prior notice due to continuous product improvement.
 - The English instructions provided in this manual are based on the latest available information. Minor discrepancies with other language versions or product updates may occur.
-