Scosche MPQ4V3EX2-CP0

Scosche MagicMount Pro Charge4 Extendo

Model: MPQ4V3EX2-CP0

Wireless Charging Phone Holder Mount

INTRODUCTION

The Scosche MagicMount Pro Charge4 Extendo is a versatile 15W Qi-Certified wireless charging phone holder mount designed for secure placement in your vehicle. It features a telescoping arm and a 220-degree adjustable head, allowing for optimal viewing angles. This mount is compatible with MagSafe devices and other Qi-compatible smartphones, providing both secure holding and efficient wireless charging.

Image: The Scosche MagicMount Pro Charge4 Extendo, showcasing its adjustable arm and magnetic charging head.

PACKAGE CONTENTS

Verify that all items are present in your package:

- MagicMount Charge4 Extendo
- Optional Vent Base
- 2-port 20W USB-C Power Delivery Car Charger
- MagicPlate (for non-MagSafe devices)

INSTALLATION GUIDE

The MagicMount Pro Charge4 Extendo offers multiple installation options for your vehicle.

Option 1: Window or Dashboard Mount

1. **Prepare the Surface:** Clean the desired mounting surface (window or dashboard) thoroughly with an alcohol wipe and allow it to dry completely. Ensure the surface is smooth and free of debris.

2. **Attach the Mount:** Remove the protective film from the suction cup. Press the suction cup firmly onto the cleaned surface.

3. **Secure the Mount:** While pressing down, push the lever on the base of the mount down to create a strong vacuum seal.

4. **Adjust the Arm:** Loosen the adjustment knob on the telescoping arm to extend or retract it to your preferred length. Tighten the knob to secure the arm position.

Image: The MagicMount Pro Charge4 Extendo mounted on a vehicle dashboard, demonstrating secure placement.

Option 2: Vent Mount

1. **Attach Vent Base:** Slide the included vent base onto the ball joint of the MagicMount head.

2. **Secure to Vent:** Gently push the vent clips into a horizontal or vertical vent slat until secure. Ensure the mount is stable and does not obstruct airflow or vehicle controls.

Device Compatibility & Charging

The MagicMount Pro Charge4 Extendo is designed for broad smartphone compatibility and efficient wireless charging.

MagSafe Compatibility

For iPhone 12, 13, 14, 15 series, and later devices with MagSafe technology, no MagicPlate is required. The device will magnetically attach directly to the mount's charging head.

Qi-Compatible Devices (Non-MagSafe)

For other Qi-compatible smartphones (e.g., iPhone 8-11, Android, Galaxy, Pixel), the included MagicPlate must be applied to your device or its case. For optimal wireless charging, place the MagicPlate below the charging zone on your phone or case, ensuring it does not obstruct the wireless charging coil.

Image: Illustrates how a standard phone case requires the included MagicPlate for magnetic attachment, while a MagSafe compatible case attaches directly.

iPhone 12/13*

No MagicPlate is required on all iPhone 12 models or 13 & 13 Pro Max models.

*13 Pro requires the included MagicPlate.

iPhone 13 Pro

with included MagicPlate applied to case below charging zone.

Samsung Galaxy
or other wireless charging phones

with included MagicPlate applied to case below charging zone.

○ MagSafe® Magnets   ▢ MagicPlate™

Image: Diagram detailing the recommended placement of the MagicPlate for iPhone 13 Pro and Samsung Galaxy devices to ensure proper wireless charging.

Wireless Charging

Once your device is securely attached to the magnetic charging head, connect the included 2-port 20W USB-C Power Delivery Car Charger to your vehicle's 12V power outlet. Connect the USB-C cable from the mount to the car charger. Your device will begin to charge wirelessly at up to 15W, provided it is Qi-compatible.

Image: A smartphone positioned on the MagicMount, indicating active wireless charging.

OPERATION & ADJUSTMENTS

The MagicMount Pro Charge4 Extendo offers flexible positioning for optimal viewing.

- **Attaching Your Phone:** Simply bring your MagSafe-compatible phone or a phone with a properly placed MagicPlate close to the magnetic charging head. The strong rare-earth magnets will securely hold your device in place.

- **Adjusting Viewing Angle:** The mount features a 220-degree adjustable head. Gently pivot the phone to switch between portrait and landscape orientation or to adjust the viewing angle.

- **Telescoping Arm Adjustment:** Loosen the knob on the telescoping arm to extend or retract the arm (from 5.07" to 8.61") to bring your phone closer or further away. Tighten the knob to lock the arm in position.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your MagicMount Pro Charge4 Extendo, follow these care instructions:

- **Cleaning:** Use a soft, dry cloth to wipe down the mount. For the suction cup, a damp cloth can be used, but ensure it is completely dry before re-applying. Do not use harsh chemicals or abrasive cleaners.

- **Storage:** If storing the mount for an extended period, release the suction cup and store it in a cool, dry place away from direct sunlight.

- **Avoid Extreme Temperatures:** Prolonged exposure to extreme heat or cold can affect the performance and lifespan of the mount.

TROUBLESHOOTING

If you encounter issues with your MagicMount Pro Charge4 Extendo, refer to the following common solutions:

- **Mount Not Sticking:**

  - Ensure the mounting surface is clean, smooth, and dry.
  - Press the suction cup firmly against the surface before engaging the locking lever.
  - If using on a textured dashboard, consider using a dashboard mounting disc (not included) for a smoother surface.

- **Phone Not Holding Securely:**

  - For non-MagSafe devices, verify the MagicPlate is correctly positioned on your phone or case, ensuring it is centered and securely adhered.
  - Ensure there are no obstructions (e.g., thick phone cases, pop sockets) between the phone and the mount that could interfere with the magnetic connection.
  - The magnets are designed to be 100% mobile device safe.

- **Wireless Charging Not Working:**

  - Confirm the car charger is properly inserted into the vehicle's 12V power outlet and the vehicle's ignition is on.
  - Ensure the USB-C cable is securely connected from the mount to the car charger.
  - Verify your phone is Qi-compatible and correctly aligned on the charging head.
  - Remove any unusually thick phone cases or metal objects between the phone and the mount that

might interfere with wireless charging.

PRODUCT SPECIFICATIONS

Model Number	MPQ4V3EX2-CP0
Brand	Scosche
Mounting Type	Dashboard, Vent, Windshield
Wireless Charging Output	Up to 15W (Qi-Certified)
Telescoping Arm Range	5.07 inches to 8.61 inches
Adjustable Head	220-degree rotation
Magnet Strength	Rare-Earth neodymium magnets (30% stronger than standard MagicMounts)
Compatible Devices	MagSafe compatible iPhones (12 series and later), Qi-compatible smartphones (iPhone 8-11, Android, Galaxy, Pixel, etc.)
Item Weight	1.07 pounds
Package Dimensions	14.76 x 13.11 x 2.83 inches

Image: Technical diagram showing various components and approximate dimensions of the mount.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Scosche website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Scosche Customer Support:

- Visit the Scosche Store on Amazon for more information.
- Refer to the contact information provided in your product packaging.

Related Documents - MPQ4V3EX2-CP0

	Scosche MagicMount PRO CHARGE User Manual and Setup Guide Comprehensive guide for the Scosche MagicMount PRO CHARGE, covering included elements, device setup for various smartphones (iPhone, Android), mounting instructions for windshield and dash, charging specifications, and compliance information.
	Scosche MagicMount Pro2 Extendo: Setup and Usage Guide Comprehensive guide for setting up and using the Scosche MagicMount Pro2 Extendo, a telescoping magnetic and MagSafe compatible phone mount for vehicles and surfaces.
	Scosche MagicMount Pro MS 4-in-1 Installation Guide This guide provides instructions for installing and using the Scosche MagicMount Pro MS 4-in-1 car mount, compatible with MagSafe devices and other smartphones.
	Scosche MagicMount Pro2 4-In-1 Dash/Vent Mount User Guide User guide for the Scosche MagicMount Pro2 4-In-1 magnetic and MagSafe-compatible vent/dash phone mount, detailing included elements, device setup for various smartphones, and installation instructions for dash and vent mounts.
	Scosche MagicMount Charge Elite 3-in-1: Wireless Car Charger Mount Setup Guide Comprehensive setup guide for the Scosche MagicMount Charge Elite 3-in-1 wireless car charger mount. Learn how to install and use the dash mount, monitor mount, and vent mount options.
	Scosche MagicMount Elite2: Magnetic Phone Mount Installation Guide Comprehensive installation guide for the Scosche MagicMount Elite2 magnetic phone mount, including setup for MagSafe and non-MagSafe devices, dash mounting, and optional bases. Features multilingual instructions.