

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [KCO Lighting](#) /

› KCO Lighting T1010-L Contemporary Gradient Gold Floor Lamp User Manual

KCO Lighting T1010-L

KCO Lighting T1010-L Contemporary Gradient Gold Floor Lamp User Manual

Model: T1010-L

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor Use Only:** This lamp is designed for indoor use in dry locations. Do not use in wet or damp areas.
- **Electrical Safety:** Ensure the power supply is disconnected before assembly, installation, or maintenance. Use only the specified bulb type and wattage.
- **Stable Placement:** Always place the lamp on a firm, level surface to prevent tipping.
- **Cord Care:** Do not place the power cord near heat sources. Do not allow children or pets to play with the cord.
- **Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth. Avoid abrasive cleaners.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with assembly. If any parts are missing or damaged, please contact customer support.

- Lamp Base
- Multiple Pole Sections (for main lamp body)
- Lamp Head with Bulb Socket
- Glass Globe Shade
- E26 LED Light Bulb (1 included)
- Power Cord with Foot Switch



Figure 2.1: Exploded view of lamp components, highlighting the heavy base, modular pole, and glass shade.

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your floor lamp. Assembly typically takes 10-15 minutes.

1. **Insert the Pole to the Base:** Carefully thread the power cord through the lamp base. Insert the lowest pole section into the base and rotate clockwise to secure it. Ensure the cord is not pinched.
2. **Connect and Tighten Pole Sections:** Connect the remaining pole sections one by one by screwing them clockwise. Ensure the electrical cord runs freely through the center of each section and is not twisted or taut. Tighten each connection securely.
3. **Loosen Metal Ring from Socket:** Locate the lamp head with the bulb socket. Unscrew and remove the metal ring from the socket.
4. **Install the Glass Lampshade:** Carefully place the glass globe shade over the lamp head.
5. **Tighten Metal Ring from Inside Globe:** From inside the glass globe, re-attach and tighten the metal ring onto the bulb socket to secure the shade.
6. **Install the E26 Light Bulb:** Screw the provided E26 LED light bulb into the socket. Do not overtighten.



Figure 3.1: Visual guide for lamp assembly.

Note on Height Adjustment: The lamp features a modular pole design. Its height can be adjusted by varying the number of pole sections assembled. Ensure all connections are tight for stability.

4. OPERATION

The KCO Lighting T1010-L floor lamp is operated using a convenient foot pedal switch located on the power cord.

- **Power Connection:** Plug the lamp's power cord into a standard 110V electrical outlet.
- **Turning On/Off:** Gently press the foot pedal switch to turn the lamp on or off.



Figure 4.1: Lamp features, including the foot switch for operation.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry, lint-free cloth to wipe the metal pole and base. For the glass shade, a slightly damp cloth can be used, followed by a dry cloth to prevent water spots. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled before attempting to replace it. Use only E26 base bulbs with a maximum wattage of 60W.

- **Tighten Connections:** Periodically check and gently tighten all pole connections to maintain stability.

6. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on	<ol style="list-style-type: none"> 1. Power cord not plugged in 2. Light bulb is loose or burnt out 3. Wall outlet is not functioning 	<ol style="list-style-type: none"> 1. Ensure the power cord is securely plugged into a working outlet. 2. Unplug the lamp, then check and tighten the bulb. Replace if burnt out. 3. Test the outlet with another device.
Lamp appears unstable or leans	<ol style="list-style-type: none"> 1. Pole sections are not fully tightened 2. Lamp base is not on a level surface 	<ol style="list-style-type: none"> 1. Unplug the lamp and carefully tighten all pole connections. Ensure the internal cord is not interfering. 2. Move the lamp to a flat, stable surface.
Light is too dim or too bright	Incorrect wattage bulb installed	Replace the bulb with an E26 base LED bulb within the recommended wattage (max 60W) and desired color temperature.

7. SPECIFICATIONS

Technical details for the KCO Lighting T1010-L Floor Lamp:

Feature	Detail
Model Number	T1010-L
Dimensions (Overall)	9.8"D x 9.8"W x 61"H (25cm D x 25cm W x 155cm H)
Item Weight	17.91 pounds (8.14 kg)
Material	Metal (Base, Pole), Glass (Shade)
Finish Type	Gold
Bulb Base	E26
Light Source Type	LED (Bulb included)
Maximum Wattage	60 Watts
Voltage	110 Volts
Color Temperature	3000 Kelvin
Switch Type	Foot Switch
Power Source	Corded Electric
Usage	Indoor Use Only
Assembly Required	Yes



Figure 7.1: Product dimensions and bulb type.

8. WARRANTY AND SUPPORT

KCO Lighting is committed to providing quality products and customer satisfaction.

- **Warranty:** This product comes with a 1-year professional after-sales support and a 3-year warranty. If you receive broken, cracked, damaged glass globe, or missing parts, please contact us for replacement.
- **Customer Service:** For any questions, issues, or support needs, please contact KCO Lighting customer service.

We aim to provide a solution within 24 hours.

- **Contact Information:** Refer to your purchase documentation or the seller's page on Amazon for the most current contact details for KCO Lighting.

