AIRIVO HJ-XKD09

AIRIVO Galaxy Light Projector

User Manual (Model: HJ-XKD09)

1. Introduction

Thank you for purchasing the AIRIVO Galaxy Light Projector. This device combines a Northern Lights aurora projector, a star projector, a Bluetooth music speaker, and a white noise machine into one unit. It is designed to create a relaxing and immersive atmosphere in any room. Please read this manual carefully before use to ensure proper operation and to maximize your experience.



Figure 1: AIRIVO Galaxy Light Projector

2. Safety Information

- Ensure the power adapter and cable are undamaged before use.
- Use only the provided power adapter.
- Do not look directly into the laser light source. Keep the device out of reach of children to prevent eye injury.
- Do not disassemble or modify the device. Contact customer support for repairs.
- Keep the device away from water, moisture, and high temperatures.
- Clean the device with a soft, dry cloth only.

3. Package Contents

Verify that all items are present in the package:

- AIRIVO Galaxy Light Projector (1)
- Remote Control (1)
- USB Power Cable (1)
- User Manual (1)



Figure 2: Projector and Remote Control

4. Product Overview

Familiarize yourself with the main components of the projector:



Figure 3: Projector Control Panel

1. **Projection Lens:** Emits aurora and star effects.
2. **Power Button:** Turns the device on/off.
3. **Light Mode Button:** Cycles through light effects.
4. **Bluetooth/White Noise Button:** Switches between Bluetooth and white noise modes.
5. **Volume Up/Next Track Button:** Increases volume or skips to next track.
6. **Volume Down/Previous Track Button:** Decreases volume or skips to previous track.
7. **USB-C Power Port:** For connecting the power cable.
8. **Speaker:** Outputs audio.

5. Setup

1. **Power Connection:** Connect the provided USB power cable to the projector's USB-C port and plug the other end into a compatible USB power adapter (not included) or a USB port.

2. **Placement:** Place the projector on a stable, flat surface. For optimal projection, position it in the center of the room or at an angle to cover the desired area on the ceiling or walls.
3. **Initial Power On:** Press the Power Button on the device or remote control to turn it on. The projector will emit a voice prompt indicating "Bluetooth mode" upon startup.

6. Operating Instructions

6.1 Light Modes

The projector offers a combination of Northern Lights aurora and star effects. You can control these independently or in unison.

- **Changing Light Effects:** Press the Light Mode Button on the device or the corresponding buttons on the remote control to cycle through various color combinations (Red, Green, Blue, White) and effects.
- **Adjusting Brightness:** Use the brightness adjustment buttons on the remote to select from 4 available brightness levels.
- **Adjusting Motion Speed:** Use the motion speed buttons on the remote to select from 4 available speeds for the aurora effect.



Figure 4: Star Projection Effect

6.2 Bluetooth Speaker

The projector features a built-in Bluetooth speaker for playing music from your connected devices.

1. **Pairing:** When the projector is powered on, it will automatically enter Bluetooth pairing mode (indicated by a voice prompt). On your mobile device, search for "HJ-XKD09" (or similar name) in your Bluetooth settings and connect.
2. **Playing Music:** Once connected, play music from your device.
3. **Music Sync:** The lights can sync with the music beat, creating a dynamic visual effect.
4. **Volume Control:** Use the Volume Up/Down buttons on the projector or remote, or control volume directly from your

connected device.



Figure 5: Galaxy Projection Effect

6.3 White Noise Function

The projector includes 8 built-in white noise sounds for relaxation.

- **Activating White Noise:** Press the Bluetooth/White Noise Button on the device or remote to switch to white noise mode.
- **Selecting Sounds:** Use the Next/Previous Track buttons on the device or remote to cycle through the 8 available sounds (e.g., birds, running water, chimes, crackling firewood).



Figure 6: Soothing Sounds Feature

6.4 Auto-Off Timer

Set a timer for the projector to automatically turn off.

- **Setting Timer:** Use the timer buttons on the remote control to set the auto-off duration to 1 hour, 2 hours, or 4 hours (default setting).



Figure 7: Timer Function in use

7. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the projector's surface and lens. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
Projector does not turn on.	No power connection or faulty cable/adapter.	Ensure the USB cable is securely connected and the power adapter is working. Try a different USB port or adapter.
No light projection.	Light mode is off or brightness is set to minimum.	Press the Light Mode button. Increase brightness using the remote.
Bluetooth cannot connect.	Device not in pairing mode or already connected to another device.	Ensure the projector is in Bluetooth mode. Disconnect from other devices. Restart both projector and mobile device.
Remote control not working.	Battery depleted or obstruction.	Replace the CR2 battery in the remote. Ensure no objects are blocking the signal path to the projector.
Loud "Bluetooth mode" voice prompt.	This is a default startup announcement.	This is normal operation. There is no option to disable this voice prompt.

9. Specifications

- **Model Number:** HJ-XKD09
- **Material:** Plastic
- **Light Source Type:** LED
- **Power Source:** Corded Electric
- **Voltage:** 5 volts
- **Mounting Type:** Ceiling Mount (intended projection)
- **Special Features:** Sound activated, adjustable brightness and motion speeds, Bluetooth speaker, White noise
- **Remote Battery:** 1 CR2 battery (included)

10. Warranty Information

The AIRIVO Galaxy Light Projector (Model HJ-XKD09) comes with a**1-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.

Please retain your proof of purchase for warranty claims.

11. Customer Support

If you encounter any issues or have questions regarding your AIRIVO Galaxy Light Projector, please contact our customer support team for assistance.

- **Manufacturer Contact:** Shenzhenshilixiangkejiyouxiangongsi
- For the most up-to-date support information, please visit the official AIRIVO store on Amazon or refer to the contact details provided with your purchase.

© 2026 AIRIVO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question