

XLAQ CS-ADL930CL

XLAQ Compatible Battery Instruction Manual

Brand: XLAQ
Model: CS-ADL930CL

1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your XLAQ 3.6V 1200mAh Nickel-Metal Hydride (NiMH) compatible battery, model CS-ADL930CL. This battery is designed as a replacement for various devices, including specific Bosch and CT-COM series models. Please read this manual thoroughly before installation and use.

2. PRODUCT OVERVIEW

The XLAQ CS-ADL930CL battery is a high-quality replacement power source featuring:

- **Voltage:** 3.6 Volts
- **Capacity:** 1200 Milliamp Hours (mAh)
- **Battery Cell Composition:** Nickel-Metal Hydride (NiMH)
- **Dimensions:** Approximately 1.96 x 0.57 x 1.67 inches (49.9 x 14.4 x 42.4 mm)
- **Weight:** Approximately 3.95 ounces (112g)
- **Compatibility:** Designed to be compatible with devices requiring batteries such as Bosch BT192, CM517, CT-COM 314, CT-COM157, CT-COM214, CT-COM311, CT-COM314, CT-COM316, CT-COM405, CT-COM412.




Front view of the XLAQ CS-ADL930CL battery, displaying its specifications and safety warnings on the label.



An angled perspective of the battery, providing a clear view of the product label and the attached connector cable.



Top view of the battery, showing its compact form factor and the arrangement of its cells.



Side angled view of the battery, illustrating its overall shape and the position of the wiring.



Another front view of the battery, providing an alternative angle of the product label and its details.



A direct top-down view of the battery, showing the arrangement of the cells and the connector cable.



A detailed close-up of the battery's electrical connector, showing the pin configuration and wire colors.

3. SAFETY INFORMATION

Please adhere to the following safety guidelines to prevent injury or damage to the battery and device:

- **Do not attempt to disassemble, open, or service the battery pack.** Unauthorized tampering can lead to electric shock, fire, or explosion.
- **Replace only with the battery pack designated for this product.** Using an incompatible battery may cause damage or malfunction.
- **Do not crush, puncture, short external contacts, or dispose of in fire or water.** These actions can cause severe damage, fire, or explosion.
- **Do not store above 60°C (140°F).** High temperatures can degrade battery performance and pose a safety risk.
- Keep batteries out of reach of children and pets.
- Dispose of used batteries according to local regulations. Do not dispose of with household waste.

4. SETUP AND INSTALLATION

Follow these steps to properly install your new battery:

1. Ensure the device is powered off and disconnected from any power source.
2. Locate the battery compartment on your device. Refer to your device's original manual for specific instructions on accessing the battery.
3. Carefully remove the old battery, if present.
4. Insert the new XLAQ CS-ADL930CL battery into the compartment, ensuring the connector aligns correctly with the device's port. Do not force the connection.
5. Secure the battery within the compartment and close the cover.
6. It is recommended to fully charge the battery before its first use.

5. OPERATING THE BATTERY

To ensure optimal performance and longevity of your NiMH battery:

- **Charging:** Use a charger compatible with NiMH batteries and the voltage requirements of your device. Overcharging or undercharging can reduce battery life. Follow the charging instructions provided with your device or charger.

- **Initial Charge:** For the first use, charge the battery completely.
- **Regular Use:** NiMH batteries generally perform best when fully discharged before recharging, though modern NiMH batteries have a reduced

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BC559JDV>

More documents and user manuals: <https://manuals.plus/>