Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WANAI B110black

WANAI 5.0 Cu.Ft Black Compact Chest Freezer Instruction Manual

Brand: WANAI

Model: B110black

Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your new WANAI 5.0 Cu.Ft Black Compact Chest Freezer. Designed for versatile storage, this unit is ideal for various settings including homes, basements, cottages, and businesses. Please read this manual thoroughly before using the appliance to ensure proper function and longevity.

Key Features

- **All-Purpose Deep Freezer:** Provides 5.0 cu. ft of valuable storage space, ideal for meats, vegetables, seafood, or cool drinks.
- **Adjustable Temperature Panel:** Offers deep freezing and refrigeration in one machine with a temperature regulation range of -11.2°F to 50°F. Features a D-shaped condensing tube for effective temperature retention.
- **Power Saving:** Equipped with good thermal insulation foam and an aluminum liner to keep coldness inside and block external heat, contributing to electricity savings.
- **Super Quiet Operation:** Designed to operate at a noise level not higher than 40 dB, ensuring minimal disturbance.
- **Space-Saving Design:** Compact dimensions (26.2"W x 17.5"D x 30.3"H) with a flat back for efficient placement.
- **Stay-Open Lid:** Features auto-hold hinges for convenient loading and unloading.
- **Side-Access Drain:** For easy manual defrosting.
- **Removable Storage Basket:** For organized storage of smaller items.

Unboxing & Initial Setup

Upon receiving your WANAI Chest Freezer, carefully remove it from its packaging. Inspect the unit for any signs of damage during transit. It is crucial to allow the freezer to stand upright for at least 24 hours before plugging it into a power outlet. This allows the refrigerant to settle, ensuring optimal performance and preventing damage to the compressor.



Image: The WANAI 5.0 Cu.Ft Black Compact Chest Freezer, showcasing its capacity with various frozen items inside.

Video: An unboxing demonstration of the WANAI 5.0 Cu.Ft Chest Freezer, showing the removal of packaging and initial inspection of the unit.

Operating Instructions

Your WANAI Chest Freezer features an adjustable temperature control dial located on the exterior. This dial allows you to select from 7 different temperature settings, ranging from -11.2°F to 50°F, enabling you to use it as either a freezer or a refrigerator depending on your needs. A higher number on the dial indicates a colder setting.

1. **Power On:** After the 24-hour settling period, plug the freezer into a grounded electrical outlet. The power indicator light will illuminate.
2. **Set Temperature:** Rotate the temperature control dial to your desired setting. For freezing, select a higher number. For refrigeration, select a lower number within the specified range.
3. **Loading Food:** Once the freezer has reached the desired temperature (allow several hours for initial cooling), you can begin loading food items. Utilize the removable storage basket for easy access to frequently used or smaller items.



Image: The temperature control dial with 7 settings, illustrating suitable food types for each temperature level.

Maintenance

Defrosting

This is a manual defrost freezer. Frost buildup on the interior walls can reduce cooling efficiency and storage capacity. Defrost your freezer when the frost layer is approximately 1/4 to 1/2 inch thick.

1. **Unplug the Freezer:** Disconnect the power cord from the electrical outlet.
2. **Remove Food:** Transfer all frozen food to another freezer or cooler.
3. **Open Drain:** Locate the side-access drain plug at the bottom of the freezer. Place a shallow pan or towel beneath the drain to

collect melting ice. Remove the drain plug to allow water to escape.

4. **Allow to Defrost:** Keep the lid open to accelerate the defrosting process. You can use a plastic scraper to carefully remove ice, but avoid sharp objects that could damage the liner.
5. **Clean and Dry:** Once all ice has melted, clean the interior with a mild detergent and warm water. Wipe thoroughly dry before plugging the freezer back in.
6. **Restart:** Replace the drain plug, plug in the freezer, and allow it to cool down to the desired temperature before returning food.



Image: Close-up of the side-access drain outlet, designed for convenient manual defrosting.

Cleaning the Exterior

Wipe the exterior of the freezer with a soft cloth and mild detergent. Avoid abrasive cleaners or solvents that could damage the powder-coated steel finish.

Troubleshooting

If your freezer is not operating correctly, please check the following common issues before contacting customer service:

- **Freezer not cooling:** Ensure the power cord is securely plugged into a working outlet. Check the temperature control dial to confirm it is set to a sufficiently cold setting. Verify that the 24-hour settling period after transport has been observed.
- **Excessive frost buildup:** This is a manual defrost unit. Regular defrosting is required. Ensure the lid gasket is sealing properly.
- **Unusual noise:** A slight humming sound from the compressor is normal. Ensure the freezer is level; adjust the foot pegs if necessary.
- **Lid not closing properly:** Check for any obstructions preventing the lid from sealing. Ensure the lid gasket is clean and intact.

For issues not resolved by the above steps, please refer to the Warranty & Support section.

Specifications

Specification	Value
Brand Name	WANAI
Model Info	B110black
Item Weight	45 pounds
Product Dimensions	17.5"D x 26.2"W x 30.3"H
Item Model Number	B110black
Noise Level	40 dB
Installation Type	Freestanding
Color	Black
Voltage	110 Volts
Defrost Type	Manual
Door Hinges	Top
Door Material Type	Stainless Steel
Shelves	1

What's in the Box

- WANAI 5.0 Cu.Ft Black Compact Chest Freezer
- Side Handle

- Switch
- Removable Storage Basket
- Instruction Manual

Warranty & Support

WANAI is committed to providing customers with the highest standard of customer experience. For any questions or issues regarding your product, please feel free to contact us via Amazon communication. Our customer service team is dedicated to solving after-sales problems and will reply within 24 hours to provide a satisfactory answer.

Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question