Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi Rotary Control Knob for DE120, DE210, DE220, DE320

De'Longhi Dehumidifier Rotary Control Knob Replacement Manual

For Models: DE120, DE210, DE220, DE320

Introduction

This document provides essential information regarding the identification and replacement of the original De'Longhi rotary control knob, a genuine spare part designed for specific De'Longhi dehumidifier models.

Product Overview

This is an original De'Longhi replacement rotary control knob. It is designed to fit various De'Longhi dehumidifier models, allowing for precise adjustment of settings.



Image Description: A close-up view of the gray, circular rotary control knob with a raised indicator line, designed for adjusting settings on a dehumidifier.

Compatibility and Model Identification

This rotary control knob is compatible with the following De'Longhi dehumidifier models:

- DE120
- DE210
- DE210 (Label Type A)
- DE210 (Label Type B)
- DE220
- DE220BW
- DE220ECO (Label Type A)
- DE320

Important: For models DE210 or DE220 ECO, it is crucial to verify the specific label type on your appliance. The identification plate, typically located on the underside of the unit, contains this information. Refer to the image below for examples of Label Type A and Label Type B.



Image Description: Two examples of identification labels. The top label, "LABEL TYPE A," shows a De'Longhi product label with model "MW 345" and serial number details. The bottom label, "LABEL TYPE B," shows a barcode with "DEC-18" and a numerical code. These labels help distinguish between different versions of the DE210 and DE220 ECO models.

To ensure correct part selection, always locate your product's identification plate. If your specific model is not listed or you are unsure, please contact De'Longhi customer support.

Installation Instructions

This section provides general guidance for replacing the rotary control knob. Specific steps may vary slightly depending on your dehumidifier model.

1. **Safety First:** Before attempting any replacement, ensure the dehumidifier is unplugged from the electrical outlet to prevent electric shock.
2. **Remove Old Knob:** Gently pull the existing rotary control knob directly off its shaft. It may require a firm but steady pull. Avoid twisting or prying with excessive force, which could damage the shaft.
3. **Inspect Shaft:** Examine the control shaft for any damage or debris. Clean if necessary.
4. **Install New Knob:** Align the new rotary control knob with the control shaft. The knob typically has a flat edge or a specific orientation that matches the shaft. Push the new knob firmly onto the shaft until it is securely seated.
5. **Test Functionality:** Plug the dehumidifier back into the electrical outlet and test the new knob's operation to ensure it turns smoothly and engages correctly with the internal controls.

If you encounter any difficulties or are uncomfortable performing this replacement, it is recommended to seek assistance from a qualified service technician.

Specifications

- **Part Type:** Original De'Longhi Rotary Control Knob
- **Dimensions (L x W x H):** Approximately 2 x 1 x 2 cm (0.79 x 0.39 x 0.79 inches)

- **Weight:** Approximately 10 grams (0.35 ounces)
- **Material:** Plastic (typical for control knobs)

Note: Dimensions and weight are approximate and may vary slightly.

Troubleshooting

- **Knob does not fit:** Double-check your dehumidifier's model number and label type against the compatibility list. Ensure the knob is correctly aligned with the shaft.
- **Knob turns but does not change settings:** The internal shaft or control mechanism may be damaged. This issue is beyond the scope of a simple knob replacement and may require professional service.
- **Knob is loose:** Ensure the knob is pushed firmly onto the shaft. If it remains loose, the shaft itself might be worn or damaged.

Warranty and Support

As an original spare part, this rotary control knob is subject to De'Longhi's standard spare parts warranty policy. Please refer to your original dehumidifier's warranty documentation or contact De'Longhi customer service for specific warranty details.
For further assistance, technical support, or to inquire about professional service, please visit the official De'Longhi website or contact their customer support line. When contacting support, have your dehumidifier's full model number and serial number ready.

This manual is for informational purposes only. De'Longhi is not responsible for any damage or injury resulting from improper installation or use.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BC8RKL7G

More documents and user manuals: **https://manuals.plus/**