

SICOTAS Sideboard Buffet Cabinet - 2

SICOTAS Sideboard Buffet Cabinet Instruction Manual

Model: Sideboard Buffet Cabinet - 2

1. INTRODUCTION

Thank you for choosing the SICOTAS Sideboard Buffet Cabinet. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This product is designed to offer versatile storage solutions in various home environments, including dining rooms, kitchens, living rooms, and entryways. It features a durable engineered wood construction with rattan-style doors and adjustable shelving.

2. SAFETY INFORMATION

- **Adult Assembly Required:** This product requires adult assembly. Keep children and pets away during assembly.
- **Use Proper Tools:** Ensure you have the necessary tools for assembly as specified in the included assembly guide.
- **Secure Placement:** Place the cabinet on a flat, stable, and level surface to prevent tipping.
- **Weight Limits:** Do not exceed the maximum weight limit of 200 pounds for the entire unit. Distribute weight evenly across shelves.
- **Wall Anchoring:** For enhanced safety and to prevent tipping, especially in households with children, it is highly recommended to anchor the cabinet to a wall using the provided anti-tip hardware. Follow the wall anchoring instructions carefully.
- **Avoid Overloading:** Do not overload shelves or drawers.
- **Chemicals:** Avoid contact with harsh chemicals or abrasive cleaners, which can damage the finish.

3. PACKAGE CONTENTS

Before assembly, verify that all components and hardware are present. Refer to the detailed parts list included in your product packaging. Typically, each cabinet unit includes:

- Engineered wood panels (top, bottom, sides, back, shelves)

- Rattan-style doors
- Metal handles
- Adjustable shelf pins
- Hinges and mounting hardware
- Assembly screws and accessories
- Anti-tip hardware
- Assembly Instructions (separate booklet)

If any parts are missing or damaged, please contact customer support immediately.

4. SETUP AND ASSEMBLY

Assembly of the SICOTAS Sideboard Buffet Cabinet is designed to be straightforward. It is recommended to have a second person assist with certain steps for ease and safety. Each cabinet is packaged in a separate box.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts on a soft, clean surface to prevent scratches. Identify all components using the parts list in your separate assembly manual.
2. **Frame Assembly:** Follow the step-by-step diagrams in your assembly manual to construct the main frame of the cabinet. Ensure all screws are tightened securely.
3. **Back Panel Installation:** Attach the back panel to the frame. This adds stability to the unit.
4. **Shelf Installation:** Insert the adjustable shelf pins into the desired holes. Place the shelves onto the pins. The shelves can be repositioned later to accommodate items of varying heights.
5. **Door Attachment:** Attach the hinges to the doors and then to the cabinet frame. Ensure the doors are aligned properly. Adjusting the hinge screws (as detailed in the assembly manual) can help achieve perfect door alignment and smooth closure.
6. **Handle Installation:** Secure the metal handles to the doors.
7. **Wall Anchoring:** For safety, especially if children are present, attach the anti-tip hardware to the back of the cabinet and secure it to a wall stud.

A detailed assembly guide with diagrams is included in your product packaging. Please refer to it for specific instructions and illustrations.



Image: Interior view of the SICOTAS Sideboard Buffet Cabinet, highlighting the two adjustable shelves for flexible storage.



Image: Detailed view of a single cabinet, illustrating key features such as the spacious top, metal knobs, unique rattan design, quality thickened board, height-adjustable shelves, and sturdy spike feet.

5. OPERATING AND USAGE

The SICOTAS Sideboard Buffet Cabinet is designed for versatile storage and display.

- **Storage:** Utilize the internal compartments and adjustable shelves to store various items such as crockery, cutlery, dishes, kitchen appliances, tableware, utensils, or other household goods.
- **Adjustable Shelves:** The two internal shelves can be adjusted to different heights to accommodate

taller items like wine bottles or shorter items like plates. To adjust, remove the shelf, reposition the shelf pins to the desired height, and then place the shelf back on the pins.

- **Top Surface:** The spacious top surface can be used for displaying decorative items, serving food, or as a coffee bar area. Ensure items placed on top do not exceed the overall weight capacity.
- **Door Operation:** The doors are equipped with metal handles for easy opening and closing. Close doors gently to prevent wear and tear.

Large Capacity Sideboard

Provides Adequate Storage Space



Image: Two SICOTAS Sideboard Buffet Cabinets with doors open, showcasing the ample storage space and adjustable shelves filled with various household items.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your SICOTAS Sideboard Buffet Cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or furniture polish containing silicone, as these can damage the lacquered finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage or staining.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Keep the cabinet away from direct heat sources and excessive moisture.
- **Rattan Care:** The rattan-style panels are made of plastic for durability. Clean them gently with a soft,

damp cloth. Avoid excessive scrubbing or harsh brushes.

- **Hardware:** Periodically check and tighten all screws and hardware to ensure stability.
- **Movement:** When moving the cabinet, always lift it rather than dragging it to prevent damage to the legs and frame.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Doors do not align or close smoothly.	Hinges are not properly adjusted or installed.	Refer to the assembly manual for detailed instructions on adjusting hinge screws. Typically, adjusting the screws on the hinges allows you to alter the height and position of the door for proper alignment. Ensure the cabinet is on a level surface.
Cabinet feels wobbly or unstable.	Screws are loose; cabinet is on an uneven surface; missing wall anchor.	Check and tighten all assembly screws. Move the cabinet to a level surface. Install the anti-tip wall anchor hardware as instructed in the assembly manual.
Missing parts or damaged components upon arrival.	Shipping damage or packaging error.	Do not proceed with assembly. Contact SICOTAS customer support immediately with your purchase details.

8. SPECIFICATIONS

- **Brand:** SICOTAS
- **Model Name:** Sideboard Buffet Cabinet - 2
- **Product Dimensions:** 13.9"D x 68.6"W x 35.4"H (for two pieces combined)
- **Color:** Reclaimed Caramel Oak
- **Material:** Engineered Wood (Frame, Back Material, Top Material)
- **Door Style:** Flat Panel with Rattan-style (plastic) inserts
- **Number of Pieces:** 2 (as per this variant)
- **Number of Shelves:** 2 per cabinet (adjustable)
- **Number of Compartments:** 3 per cabinet
- **Weight Limit:** 200 Pounds (total)
- **Item Weight:** 55 Pounds (per cabinet)
- **Mounting Type:** Floor Mount
- **Installation Type:** Freestanding
- **Assembly Required:** Yes
- **Included Components:** Screw Accessories and Assembly Instructions

2 Adjustable Shelves

Flexible for Different Storage Needs



Image: Dimensions of a single SICOTAS Sideboard Buffet Cabinet.

9. WARRANTY AND SUPPORT

SICOTAS is committed to providing quality products. While specific warranty details are not provided in this manual, if you encounter any problems with your product, please contact SICOTAS customer support directly. Do not return the product without first contacting support, as they can assist with troubleshooting, replacement parts, or other solutions.

For support, please refer to the contact information provided in your product packaging or visit the official SICOTAS store page on Amazon: [SICOTAS Store](#).