YEELIGHT YLFWD-0006

Yeelight Sunset YLFWD-0006 Projection Lamp

User Manual

Introduction

Thank you for choosing the Yeelight Sunset YLFWD-0006 Projection Lamp. This manual provides detailed instructions for the setup, operation, and maintenance of your new projection lamp. Please read this manual thoroughly before using the product to ensure safe and optimal performance. Keep this manual for future reference.

Safety Instructions

- Do not expose the lamp to water or moisture.
- Do not disassemble or modify the lamp. This may cause damage or injury.
- Use only the specified power adapter (5 Volts) to avoid damage.
- Keep the lamp away from heat sources and direct sunlight.
- Ensure the lamp is placed on a stable surface to prevent tipping.
- Do not look directly into the light source for extended periods.
- Clean the lamp with a soft, dry cloth only.

Package Contents

Please check the package contents upon unboxing:

- Yeelight Sunset YLFWD-0006 Projection Lamp (1 unit)
- USB Power Cable (1 unit)
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your Yeelight Sunset Projection Lamp.



Figure 1: Front view of the lamp, showing the projection lens and the power button on the side.



Figure 2: Rear view of the lamp, highlighting the USB power input port.



Figure 3: Detail of the adjustable arm, allowing for flexible projection angles.



Figure 4: The lamp in use, demonstrating its projection capability.

Setup

1. **Unpack the Lamp:** Carefully remove all components from the packaging.

2. **Choose a Location:** Place the lamp on a stable, flat surface where you intend to use it. Ensure there is enough space for the projection.
3. **Connect Power:** Insert the small end of the provided USB power cable into the USB input port on the back of the lamp (refer to Figure 2). Connect the other end of the USB cable to a compatible 5V USB power adapter (not included) or a USB port on a computer/power bank.
4. **Adjust Angle:** Use the adjustable arm (refer to Figure 3) to set the desired projection angle and direction.

Operating Instructions

1. **Power On/Off:** Press the power button located on the side of the lamp (refer to Figure 1) to turn the lamp on. Press it again to turn the lamp off.
2. **Adjust Projection:** The lamp projects a multicoloured sunset effect. Adjust the angle of the lamp using its flexible arm to change the size and position of the projection on your wall or ceiling.
3. **Optimal Distance:** For the best projection effect, experiment with different distances from the projection surface.

Maintenance

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry, lint-free cloth to wipe the surface of the lamp. Do not use abrasive cleaners, solvents, or chemical sprays.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place, away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected to both the lamp and the power source. Try a different USB port or power adapter.
Projection is dim or unclear.	Dust on the lens or incorrect distance.	Gently clean the projection lens with a soft, dry cloth. Adjust the lamp's distance from the projection surface.
Lamp flickers.	Unstable power supply.	Ensure the power source provides stable 5V output. Avoid using shared USB hubs if possible.

Specifications

Brand	YEELIGHT
Model Number	YLFWD-0006
Dimensions (L x W x H)	0.05 x 0.05 x 0.05 cm
Weight	281 g
Power	3 Watts
Voltage	5 Volts

Light Source Type	LED (Light Emitting Diode)
Bulb Base	E27
Shade Color	Multicolore
Power Source	Corded Electric

Warranty and Support

For warranty information or technical support, please contact Yeelight customer service through their official website or the retailer where you purchased the product. Please have your model number (YLFWD-0006) and purchase details ready when contacting support.

Note: Specific warranty terms may vary by region and retailer.

© 2024 YEELIGHT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question