JVC HAA6TB

JVC Gumy Mini True Wireless Earbuds User Manual

Model: HAA6TB

1. Introduction

Welcome to the user manual for your JVC Gumy Mini True Wireless Earbuds. These earbuds are designed for comfort and superior audio experience, featuring a compact and lightweight design. They are equipped with Bluetooth 5.1 for stable connectivity and an IPX4 water resistance rating, making them suitable for various activities, including outdoor use.

The JVC Gumy Mini earbuds come with a portable charging case, providing extended battery life for on-the-go listening. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds.



Figure 1: JVC Gumy Mini True Wireless Earbuds and Charging Case (Black)

2. What's in the Box

Upon opening your JVC Gumy Mini True Wireless Earbuds package, you should find the following components:

- JVC Gumy Mini True Wireless Headphones (Left and Right Earbuds)
- Wireless Charging Case
- USB Charging Cable
- Multiple sizes of Earpieces (S/M/L) for optimal fit



Figure 2: Package Contents including earbuds, charging case, cable, and eartips.

3. Setup

3.1 Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Place the earbuds into their respective slots in the charging case.
2. Connect the provided USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).
3. The indicator light on the charging case will show the charging status. Refer to the case's indicator light guide for full details.
4. A full charge provides up to 7.5 hours of playback for the earbuds, with the charging case extending total playtime to approximately 23 hours.



Figure 3: Earbuds and charging case providing up to 23 hours of total playtime.

3.2 Pairing with a Device

The JVC Gumy Mini earbuds feature an auto-connect function for seamless pairing.

1. Ensure your device's Bluetooth is turned on.
2. Remove both earbuds from the charging case. They will automatically power on and enter pairing mode.
3. On your device, search for "JVC HAA6TB" (or similar JVC Gumy Mini model name) in the Bluetooth settings and select it to connect.
4. Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.




Figure 4: Stable wireless connection of earbuds to multiple devices.

4. Operating Instructions

4.1 Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case to automatically power them off and begin charging.




Figure 5: Earbuds featuring touch sensor controls and automatic power on/off.

4.2 Sound Modes

Your JVC Gumy Mini earbuds offer three distinct sound modes to enhance your listening experience:

- **Normal:** Balanced audio profile for everyday listening.
- **Bass:** Enhanced bass for a richer, more impactful sound.
- **Clear:** Optimized for vocal clarity, ideal for podcasts and calls.

Refer to the full user manual for specific touch control gestures to switch between these sound modes.




Figure 6: Selectable sound modes for personalized audio experience.

4.3 Touch Sensor Controls

The earbuds are equipped with intuitive touch sensors for easy control of music playback, calls, and voice assistant activation. The touch controls are designed to be gentle on the ears.

Specific touch gestures for functions like play/pause, skip track, answer/end call, and activating voice assistant are detailed in the comprehensive user guide available for download.

4.4 Water Resistance (IPX4)

The JVC Gumy Mini earbuds have an IPX4 rating, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts, light rain, and other activities where they might encounter sweat or splashes.

Important: The IPX4 rating does not mean the earbuds are waterproof. Do not submerge them in water or expose them to strong jets of water. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.




Figure 7: Earbuds designed to be sweat and splash proof, ideal for running and active use.

5. Maintenance

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.

- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain proper charging.
- Remove eartips and clean them separately with mild soap and water if necessary, then dry thoroughly before reattaching.

5.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case and earbuds in a cool, dry place, away from extreme temperatures and direct sunlight.

6. Troubleshooting

If you encounter issues with your JVC Gumy Mini earbuds, try the following common troubleshooting steps:

Problem	Solution
Earbuds not pairing/connecting	Ensure Bluetooth is enabled on your device. Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them to re-enter pairing mode. Forget the device ("JVC HAA6TB") from your device's Bluetooth settings and attempt to pair again. Ensure earbuds are charged.
Only one earbud working	Place both earbuds back into the charging case, close the lid, and then remove them simultaneously. Check if the non-working earbud is charged. Perform a factory reset (refer to the full user manual for specific instructions on resetting).
Low volume or poor sound quality	Adjust the volume on both your device and the earbuds. Ensure the eartips provide a good seal in your ear canal. Try different sizes. Clean any earwax or debris from the earbud nozzles. Try switching between the available sound modes (Normal, Bass, Clear).
Charging issues	Ensure the charging cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and inside the case. Try a different USB cable or power adapter.

For more detailed troubleshooting steps, please refer to the official JVC Troubleshooting Guide (PDF) available online:JVC Gumy Mini Troubleshooting Guide

7. Technical Specifications

Feature	Specification
Model Name	GUMY Mini (HAA6TB)
Connectivity Technology	Bluetooth 5.1
Wireless Range	Up to 10 meters (33 feet)

Feature	Specification
Battery Life (Earbuds)	Up to 7.5 hours
Total Playtime (with Charging Case)	Up to 23 hours
Water Resistance Level	IPX4 (Sweat and Splash Proof)
Frequency Response	20 Hz - 20000 Hz
Impedance	16 Ohm
Control Type	Touch Sensor, Voice Control
Included Components	Headphones, Wireless Charging Case, USB Cable
Weight	3.2 ounces (earbuds + case)
Material	Plastic (earbuds), Water-resistant material (case)
UPC	046838500893

8. Warranty and Support

JVC products are manufactured to high quality standards and are backed by a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official JVC website.

For further assistance, product registration, or to explore other JVC products, please visit the official JVC Store: JVC Official Store on Amazon

You can also download the complete User Manual (PDF) for detailed instructions and diagrams: JVC Gumy Mini User Manual (PDF)

© 2024 JVC. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question