

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Samsung](#) /

› SAMSUNG Auto Rotating TV Stand User Manual

Samsung VG-ARAB43STD/ZA

SAMSUNG Auto Rotating TV Stand User Manual

Model: VG-ARAB43STD/ZA

INTRODUCTION

This user manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your SAMSUNG Auto Rotating TV Stand. Designed for 55-inch televisions, this stand offers the flexibility to view content both vertically and horizontally, enhancing your viewing experience. It is compatible with specific Samsung TV models, including the QN95B and QN700B Series.

IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions carefully before assembling and using the product. Failure to follow these instructions may result in property damage, injury, or death. Keep this manual for future reference.

- Ensure all components are present and undamaged before assembly.
- Do not exceed the maximum weight capacity or screen size specified for this stand.
- Always use two or more people to lift and position the television onto the stand.
- Place the stand on a stable, level surface to prevent tipping.
- Keep children and pets away from the stand during assembly and operation.
- Do not attach any accessories (e.g., webcam) to the TV when using the auto-rotating feature, as this may interfere with rotation.

WHAT'S IN THE BOX

Verify that all the following components are included in your package:

- 55in Auto Rotating Stand (2022)
- User Manual
- *(Additional assembly hardware such as screws, bolts, and tools are typically included but not explicitly listed in the provided data.)*

SETUP AND ASSEMBLY

Follow these steps to correctly assemble your SAMSUNG Auto Rotating TV Stand and mount your television.

1. Unpacking and Component Identification

Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Identify all parts against the packing list.



Figure 1: Front view of the assembled Auto Rotating TV Stand.

2. Assembling the Stand Base

Attach the three tripod legs to the central column of the stand. Ensure they are securely fastened according to the included hardware instructions. The legs provide stability for the television.



Figure 2: Side view illustrating the stand's structure.

3. Attaching the TV Mounting Plate

The stand features a VESA compatible mounting plate (400x300 VESA compatible). Secure the mounting plate to the top of the stand's central column. Ensure all screws are tightened to prevent wobbling.



Figure 3: Rear view of the mounting plate with VESA holes.

4. Mounting the Television

This stand is designed for 55-inch televisions and is compatible with SAMSUNG QN95B and QN700B Series models. Carefully align the VESA mounting holes on your television with the corresponding holes on the stand's mounting plate. Use the appropriate screws provided with your TV or stand to secure the television. It is highly recommended to have at least two people for this step to prevent injury or damage to the TV.



Figure 4: Side view of the stand with a mounted television.

OPERATING INSTRUCTIONS

The SAMSUNG Auto Rotating TV Stand allows for dynamic content viewing by rotating your television between horizontal

and vertical orientations.

1. Auto-Rotation Function

To rotate your television, use the dedicated auto-rotate button on your compatible Samsung TV remote control. Pressing this button will initiate a smooth 90-degree rotation of the screen, allowing you to switch between landscape and portrait modes. Ensure no obstacles are in the path of the TV during rotation.



Figure 5: Auto-rotation in action, controlled by remote.

2. Mobile Content Mirroring

Enhance your mobile viewing experience by mirroring content from your Samsung mobile device directly to the large screen. This feature is supported on Samsung mobile devices running Android version 10 or higher. When mirroring vertical content, the stand will automatically adjust the TV to a vertical orientation, utilizing the full screen without black bars.



Figure 6: Mobile mirroring to the Auto Rotating TV Stand.



Figure 7: Example of vertical content display.



Figure 8: Example of horizontal content display.

MAINTENANCE AND CARE

Proper care will ensure the longevity and optimal performance of your Auto Rotating TV Stand.

- **Cleaning:** Use a soft, dry cloth to wipe down the stand. For stubborn marks, a slightly damp cloth with mild detergent can be used, followed by drying thoroughly. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Loose connections can affect stability and rotation.
- **Environment:** Keep the stand in a dry environment, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your SAMSUNG Auto Rotating TV Stand, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Stand does not rotate.	Power issue. Obstruction. Incompatible TV model. Remote control issue.	Ensure the stand is properly connected to power (if applicable, though this model seems passive). Check for any objects blocking the TV's rotation path. Verify your TV model is QN95B or QN700B Series (55-inch). Ensure remote batteries are functional and the remote is paired with the TV.
TV appears unstable on the stand.	Loose connections. Uneven surface. Incorrect TV size/weight.	Re-tighten all screws connecting the TV to the mounting plate and the stand's legs. Place the stand on a firm, level surface. Confirm your TV is 55 inches and within the stand's weight limits.

Problem	Possible Cause	Solution
Mobile mirroring not working.	Incompatible mobile device. Network connectivity issues.	Ensure your Samsung mobile device has Android 10 or higher. Verify both your mobile device and TV are connected to the same Wi-Fi network.

If the problem persists after trying these solutions, please contact Samsung customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	VG-ARAB43STD/ZA
Brand	Samsung
Product Dimensions	29.98 x 37.65 x 41.37 inches
Item Weight	26.8 pounds
Mounting Type	Floor Mount
Movement Type	Rotate
Material	Metal
Color	Black
Maximum Compatible Size	55 Inches
Minimum Compatible Size	55 Inches
Compatible Devices	Television (Samsung QN95B and QN700B Series)
VESA Compatibility	400x300
UPC	887276651811

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Samsung website. For technical support, product registration, or service inquiries, please contact Samsung customer service through their official channels.

Online Support: www.samsung.com/us/support/

© 2024 Samsung. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.