Bousnic RS2

Bousnic RS2 Dog Training Collar User Manual

Model: RS2

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Bousnic RS2 Dog Training Collar. This device is designed to assist in training dogs by providing various stimulation modes to correct unwanted behaviors and reinforce positive commands. Please read this manual thoroughly before operating the device to ensure proper usage and the well-being of your pet.

2. PRODUCT FEATURES

- **Multiple Training Modes:** Features Beep, Vibration, and Static Stimulation modes to suit various training needs and dog temperaments.
- **Waterproof Receiver:** The collar receiver is IP67 rated, making it suitable for use in wet conditions.
- **Extended Remote Range:** Operates effectively up to 3300 feet (approximately 1000 meters), ideal for outdoor training.
- **Adjustable for Various Dog Sizes:** Designed for dogs weighing between 5 lbs and 120 lbs, with an adjustable collar strap from 0 to 24 inches.
- **Long-Lasting Battery:** Both the remote and receiver feature rechargeable lithium-ion batteries, offering 30-60 days of standby time on a 2-hour charge.
- **Security On/Off Switch:** Prevents accidental activation and ensures safe handling.

Image 1: The Bousnic RS2 remote control and collar receiver. The remote features a display for mode and level, along with buttons for various functions. The collar is adjustable and designed for comfort.

3. SAFETY INFORMATION AND IMPORTANT WARNINGS

- **Not for Aggressive Dogs:** This training collar is not intended for use with aggressive dogs. Consult a professional dog trainer for guidance on aggressive behavior.

- **Proper Fit is Crucial:** Ensure the collar fits snugly but not too tightly. It should be possible to fit one finger between the collar and your dog's neck. A loose fit can lead to inconsistent stimulation or skin irritation.

- **Limited Wear Time:** Do not leave the collar on your dog for more than 12 hours per day. Prolonged wear can cause

skin irritation or pressure sores.

- **Regular Skin Checks:** Inspect your dog's neck daily for any signs of irritation, redness, or sores. If irritation occurs, discontinue use until the skin heals.

- **Supervised Use:** Always supervise your dog when the training collar is in use.

- **Keep Away from Children:** This device is not a toy. Store the collar and remote out of reach of children.

- **Avoid Over-Correction:** Use stimulation sparingly and only when necessary to correct unwanted behavior. Over-correction can cause stress or fear in your dog.

4. PACKAGE CONTENTS

The Bousnic RS2 Dog Training Collar package typically includes:

- Remote Transmitter
- Collar Receiver with Adjustable Strap
- USB Charging Cable
- Test Light Tool
- User Manual
- Contact Points (short and long, if applicable)

5. SETUP GUIDE

5.1 Charging the Devices

1. Connect the USB charging cable to the charging ports on both the remote transmitter and the collar receiver.

2. Plug the other end of the USB cable into a standard USB power adapter (not included) or a computer USB port.

3. Allow approximately 2 hours for a full charge. The battery indicator on the remote will show full, and the receiver's indicator light will change (e.g., from red to green) when fully charged.

Image 2: Illustration of the Bousnic RS2 collar and remote, highlighting the long-lasting battery life. A full charge takes 2 hours and can last 30-60 days.

5.2 Pairing the Remote and Receiver

The remote and receiver are typically pre-paired from the factory. If re-pairing is needed:

1. Ensure both devices are fully charged and turned off.
2. Turn on the remote transmitter.
3. Press and hold the power button on the receiver until its indicator light flashes rapidly.
4. Within 10 seconds, press any mode button (Beep, Vibrate, or Static) on the remote. The receiver's light will stop flashing, indicating successful pairing.

5.3 Fitting the Collar

1. Place the receiver on your dog's neck so that the contact points are positioned underneath, making direct contact with the skin.

2. Adjust the strap to ensure a snug fit. You should be able to fit one finger comfortably between the collar strap and your dog's neck.

3. If your dog has long fur, you may need to trim the fur around the contact points or use longer contact points (if provided) to ensure proper skin contact.

Image 3: Visual guide showing the Bousnic RS2 collar's suitability for dogs ranging from 5 lbs to 120 lbs, with an adjustable strap up to 24 inches in length.

5.4 Testing the Static Stimulation

To ensure the static stimulation is functioning:

1. Turn on the receiver and remote.

2. Place the test light tool (included in the package) over the contact points on the receiver.

3. Select the static stimulation mode on the remote and press the stimulation button. The test light should illuminate, indicating the static function is working.

6. OPERATING INSTRUCTIONS

6.1 Remote Control Overview

The remote features a display, mode selection buttons, intensity level adjustment, and a channel switch for training one or two dogs.

Image 4: Close-up of the Bousnic RS2 remote control, showing the security on/off switch and the display. The device always starts static stimulation at level 1 to prevent accidental high-level activation.

6.2 Selecting Training Modes and Levels

- **Beep Mode:** Press the Beep button to emit an audible tone from the receiver. This is often used as a warning or attention-getter.
- **Vibration Mode:** Press the Vibration button to activate a vibration on the receiver. The intensity can typically be adjusted (e.g., 1-16 levels).
- **Static Stimulation Mode:** Press the Static Stimulation button to deliver a static pulse. The intensity can be adjusted

from 1 to 99 levels. Always start at the lowest level and increase gradually to find the appropriate level for your dog. The remote's security switch ensures static stimulation always starts at level 1.

- **Adjusting Levels:** Use the up/down buttons on the remote to increase or decrease the intensity level for the selected mode.

6.3 Training with the Collar

- **Consistency is Key:** Use the collar consistently to reinforce commands or correct behaviors.
- **Positive Reinforcement:** Always pair corrections with positive reinforcement when your dog performs the desired action.
- **Short Training Sessions:** Keep training sessions short and positive to prevent your dog from becoming stressed or overwhelmed.
- **Range Considerations:** The remote offers a range of up to 3300 feet. Environmental factors such as terrain, weather, and electromagnetic interference can affect the actual range.

Image 5: A visual representation of the Bousnic RS2 remote control's updated range of 3300 feet, demonstrating its capability for training

7. MAINTENANCE

- **Cleaning:** Regularly clean the collar strap with a damp cloth and mild soap. Ensure the receiver is dry before charging.

- **Contact Points:** Periodically check the contact points for dirt or debris. Clean them gently to ensure proper conductivity.

- **Battery Care:** Charge the devices fully before long periods of inactivity. Avoid completely draining the battery frequently to prolong its lifespan.

- **Storage:** Store the collar and remote in a cool, dry place when not in use.

Image 6: The Bousnic RS2 receiver collar submerged in water, illustrating its IP67 waterproof rating, allowing dogs to enjoy water activities freely while wearing the collar.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not responding to remote.	Low battery; devices not paired; out of range.	Charge both devices; re-pair remote and receiver; move closer to the dog.
Static stimulation feels weak or inconsistent.	Poor contact with dog's skin; fur interference; low battery.	Ensure snug fit; trim fur; use longer contact points; charge receiver.
Remote display is blank.	Low battery; remote is off.	Charge remote; turn on remote using the power switch.
Dog shows signs of skin irritation.	Collar worn too long; collar too tight; allergic reaction.	Remove collar immediately; allow skin to heal; consult a veterinarian if severe. Ensure proper fit and limited wear time.

9. SPECIFICATIONS

| Feature	Detail
Model Number	RS2
Training Modes	Beep, Vibration, Static Stimulation
Waterproof Rating	IP67 (Receiver)
Remote Range	Up to 3300 feet (approx. 1000 meters)
Dog Size Compatibility	5 - 120 lbs
Collar Length	Adjustable, 0 - 24 inches
Battery Type	Rechargeable Lithium-ion (2 included)
Charging Time	Approx. 2 hours
Battery Life (Standby)	30 - 60 days
Product Dimensions (Receiver)	2.54 x 2.54 x 0.25 cm (approx.)
Product Weight	330 grams (approx.)
Collar Material	Nylon

10. WARRANTY AND CUSTOMER SUPPORT

Bousnic is committed to providing high-quality products and excellent customer service. If you encounter any issues with your RS2 Dog Training Collar, or have questions regarding its operation, please do not hesitate to contact our support team.

For assistance, please refer to the contact information provided on the product packaging or the official Bousnic website.

Our customer service team is available to help with troubleshooting, warranty claims, and general inquiries.

Related Documents - RS2

Bousnic Dog Training Collar RS2 User Manual and Quick Start Guide
This document provides a comprehensive user manual and quick start guide for the Bousnic Dog Training Collar Model RS2. It covers important safety information, setup instructions, product overview, training modes, fitting the receiver, pairing procedures, indicator definitions, troubleshooting, and FCC statements.

Bousnic OBT3 Dog Training Collar: User Manual and Safety Guide
This comprehensive user manual for the Bousnic OBT3 Dog Training Collar provides detailed instructions on setup, operation, various training modes (Dog Training, Bark Control), safety warnings, fitting guidelines, troubleshooting, and FAQs. Learn to use tone, vibration, and shock commands effectively and safely for your dog.

Bousnic Dog Training Guide: Basic Obedience and E-Collar Training
Comprehensive guide to basic obedience training for dogs using the Bousnic E-Collar. Learn how to use stimulation levels, teach commands like Sit, Come, Stay, and address unwanted behaviors such as jumping, digging, chasing, and trash raiding. Includes troubleshooting and FAQs.

Bousnic Dog Training Guide: Basic Obedience with E-Collar
A comprehensive guide to basic obedience training for dogs using the Bousnic E-Collar. Learn how to use the remote transmitter and receiver collar for effective training, including commands like 'Sit', 'Come', and 'Stay', and how to address unwanted behaviors such as jumping, digging, chasing, and trash raiding.

Bousnic Dog Training Collar User Manual - Model p-collar 670
Comprehensive user manual for the Bousnic p-collar 670 dog training collar, detailing package contents, product overview, safety information, operation instructions, training tips, troubleshooting, and warranty details.

Documents - Bousnic – RS2

 Manuel d'utilisation Bousnic RS2 : Collier de Dressage Électronique pour Chien
Guide complet pour le collier de dressage pour chien Bousnic RS2. Apprenez à utiliser les fonctions de bip, vibration et choc, à ajuster le collier, et à résoudre les problèmes courants pour un dressage efficace et sécuritaire.
lang:fr score:21 filesize: 5.27 M page_count: 22 document date: 2023-03-15

 Bousnic Dog Training Collar RS2 User Manual and Quick Start Guide
This document provides a comprehensive user manual and quick start guide for the Bousnic Dog Training Collar Model RS2. It covers important safety information, setup instructions, product overview, training modes, fitting the receiver, pairing procedures, indicator definitions, troubleshooting, and FCC statements.
lang:fr score:14 filesize: 6.76 M page_count: 22 document date: 2023-02-21