

[manuals.plus](#) /

› [Xanlite](#) /

› [Xanlite LAMRVBM LED RGB Floor Lamp Instruction Manual](#)

Xanlite LAMRVBM

Xanlite LAMRVBM LED RGB Floor Lamp Instruction Manual

Model: LAMRVBM

1. PRODUCT OVERVIEW

The Xanlite LAMRVBM is an LED RGB floor lamp designed to provide dynamic lighting with sound synchronization capabilities. It features multiple light modes and can be controlled via a remote control. This manual provides essential information for the safe and efficient use of your floor lamp.




Image 1: The Xanlite LAMRVBM LED RGB Floor Lamp, showcasing its sleek, vertical design and integrated base.

2. PACKAGE CONTENTS

Please check the package contents to ensure all components are present:

- Xanlite LAMRVBM LED RGB Floor Lamp (main unit with integrated LED strip)
- Lamp Base/Feet (for assembly)
- Remote Control
- USB Power Cable
- Instruction Manual (this document)

Note: A 5V/2A mains adapter is required for power but is not included in the package.

3. SETUP INSTRUCTIONS

3.1 Assembly

1. Carefully unpack all components from the packaging.
2. Attach the provided feet to the base of the floor lamp. Ensure they are securely fastened to provide stability.
3. Confirm the LED strip is correctly positioned within the lamp housing.

3.2 Power Connection

1. Connect the USB power cable to the lamp's USB port.
2. Plug the other end of the USB cable into a compatible 5V/2A USB mains adapter (not included).
3. Insert the mains adapter into a wall socket.



Image 2: The USB power cable. A 5V/2A mains adapter is required and sold separately.

3.3 Placement

Position the floor lamp in your desired location. It is ideal for corners, next to a sofa, or near a television for optimal ambient lighting and sound synchronization effects.



Image 3: The floor lamp illuminating a living room, demonstrating its ambient lighting capabilities.



Image 4: The floor lamp integrated into a gaming setup, providing dynamic background lighting.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Operation

The Xanlite LAMRVBM floor lamp is controlled using the included remote control. Ensure the remote control has working batteries (not included) and maintain a clear line of sight to the lamp's sensor.

- **Power On/Off:** Press the 'ON' or 'OFF' button to turn the lamp on or off.
- **Color Selection:** Use the color buttons (R, G, B, W, etc.) to select static colors.
- **Brightness Adjustment:** Adjust the light intensity using the brightness control buttons.
- **Mode Selection:** Cycle through the 12 luminous modes and 4 musical modes using the designated mode buttons.



Contrôle par télécommande

Image 5: A hand demonstrating the use of the remote control to operate the lamp's functions.

4.2 Sound Synchronization

The lamp features an integrated microphone that detects ambient sound and synchronizes the light effects to the rhythm. Activate a musical mode via the remote control to enable this feature.



Synchronisation musicale



Image 6: The lamp in a room, highlighting its musical synchronization feature with an integrated microphone.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Xanlite LAMRVBM floor lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the lamp from power before cleaning. Use a soft, dry cloth to wipe the lamp's surface. Avoid abrasive cleaners or solvents.
- **Storage:** If storing the lamp for an extended period, disconnect it from power and store it in a cool, dry place.
- **LEDs:** The integrated LED strip is designed for a long lifespan (approximately 25,000 hours) and is not user-replaceable.

6. TROUBLESHOOTING

If you encounter issues with your Xanlite LAMRVBM floor lamp, please refer to the following troubleshooting steps:

- **Lamp does not turn on:**

- Ensure the USB cable is securely connected to both the lamp and the power adapter.
- Verify that the 5V/2A mains adapter is properly plugged into a working wall socket.
- Check if the wall socket is receiving power.

- **Remote control is unresponsive:**

- Ensure the remote control has fresh batteries and they are inserted correctly.
- Point the remote control directly at the lamp's sensor, located at the bottom of the product.
- Ensure you are within the effective range (less than 5 meters) of the lamp's sensor.
- Remove any obstructions between the remote control and the lamp's sensor.

- **Light effects are not synchronizing with sound:**

- Ensure the lamp is set to one of the musical modes via the remote control.
- Check that the ambient sound source is loud enough for the integrated microphone to detect.
- Ensure the microphone is not obstructed.

7. SPECIFICATIONS

Feature	Specification
Brand	Xanlite
Model Number	LAMRVBM
Dimensions (L x W x H)	23 x 23 x 130 cm
Weight	1.15 Kilograms
Material	Metal, Plastic
Power Consumption	9 Watts
Voltage	5 Volts
Light Source Type	LED
Average Lifespan	25,000 Hours
Special Features	Remote control, Sound synchronization (microphone), 12 Luminous Modes, 4 Musical Modes
Power Source	USB Cable (requires 5V/2A mains adapter, not included)

Dimensions




Image 7: Technical diagram illustrating the dimensions of the floor lamp (1300mm height, 230mm base width).





Image 8: Diagram indicating the lamp's height (130cm) and primary material (aluminum).

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or further assistance, please visit the official Xanlite website or contact their customer service department.




Related Documents - LAMRVBM



[XANLITE DECO RFDHE180TFR/TRO Decorative Lamp: User Manual, Installation & Specifications](#)

User manual and specifications for the XANLITE DECO RFDHE180TFR and RFDHE180TRO decorative lamps. Learn about installation, safety precautions, warranty, and recycling. Features E27 base, 4W power, and 230V~50Hz operation.



[Xanlite Astrolite LED Projector Night Light User Guide](#)


Comprehensive guide to the Xanlite Astrolite LED projector night light, detailing timer functions, various lighting modes (cloudy sky, starry sky, rotating effects), button controls, and technical specifications. Includes multilingual instructions and manufacturer details.



[XANLITE PRS10WMCEE Solar LED Projector User Manual](#)

Comprehensive user manual for the XANLITE PRS10WMCEE solar LED projector. Learn about installation, operation modes, remote control functions, charging, warranty, and safety precautions for this energy-efficient outdoor lighting solution.

Documents - Xanlite – LAMRVBM



[\[pdf\] Accessories Catalog](#)

241114 CATALOGUE INTRO MULTILANGUE diffusion XANLITE ENxanlite img cms Nos Gammes EN |||
CATALOGUE EN 2024 - 2025 2 SUMMARY 12 153 186 210 263 273 298 3 4
SUMMARY I. ABOUT II. HOME ... se display panels is strictly prohibited. RRP* 59.99
19.99 12.99 141 TUDRVBM 3700619437743 **LAMRVBM** 3700619433240 1300 mm
USB recharging Remote 15000 h of life 2-year guarantee LISRVBM ...
lang:en score:21 filesize: 261.6 M page_count: 309 document date: 2024-12-17

