

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PATPET](#) /

› [PATPET Wireless Dog Doorbell for Dog Potty Training - IP65 Waterproo](#) Touch Button with 55 Melodies 5 Volume Levels LED Flash

PATPET B0BCFY3KG4

PATPET Wireless Dog Doorbell Instruction Manual

Model: B0BCFY3KG4

1. INTRODUCTION

The PATPET Wireless Dog Doorbell is designed to assist in potty training your dog by providing a clear and consistent signal when your dog needs to go outside. This system includes a waterproof touch button transmitter and a plug-in receiver with multiple melody and volume options. Its robust design ensures reliable performance in various home environments.



Image: A dog patiently waiting by a door, with the PATPET wireless doorbell visible on the wall, illustrating its use for potty training.

2. SAFETY INFORMATION

- Do not expose the receiver to water or excessive humidity. The transmitter is IP65 waterproof, but the receiver is for indoor use only.
- Keep the device away from heat sources and direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Ensure the power outlet for the receiver is easily accessible.
- Keep out of reach of small children and pets to prevent accidental ingestion of small parts.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Receiver (Plug-in unit)
- 1 x Transmitter (Touch button)
- 1 x Mounting Base for Transmitter
- 1 x 12V 23A Battery (pre-installed in transmitter)
- 2 x 3M Adhesive Pads
- 2 x Screws
- 2 x Anchors
- 1 x Screwdriver



Image: An organized display of all components included in the PATPET Wireless Dog Doorbell package, ensuring users can verify their contents.

4. PRODUCT OVERVIEW

Familiarize yourself with the main components and their functions:

Receiver



Image: The PATPET receiver and transmitter shown together, highlighting their compact design.

- **Chimes Button:** Press to cycle through 55 available melodies.
- **Volume Button:** Press to adjust volume through 5 levels (0-85dB).
- **Mode Button:** Press to select one of 4 modes: Light on + Music, Light Flashes + Music, Music Only, Light Flashes Only.
- **LED Indicator:** Flashes when the doorbell is activated.



Image: A detailed view of the receiver's LED indicator, which illuminates upon activation.

Transmitter (Touch Button)

Just touch lightly Wide contact



Image: A dog interacting with the PATPET doorbell transmitter, demonstrating the touch activation feature.

- **Touch Surface:** Activates the doorbell when pressed by a paw or nose.
- **IP65 Waterproof & Dustproof:** Designed to withstand wet noses and dirty paws, suitable for outdoor or indoor use near doors.



Image: The transmitter with water droplets, visually confirming its IP65 waterproof and dustproof capabilities.

5. SETUP

Follow these steps to set up your PATPET Wireless Dog Doorbell:

5.1 Installing the Transmitter

The transmitter can be installed using either 3M adhesive pads or screws.

1. **Prepare the Mounting Base:** Hold the doorbell and unscrew the mounting base counter-clockwise to separate it from the main unit.
2. **Choose Installation Method:**
 - **Method A: Using 3M Adhesive**
Stick a 3M adhesive pad on the backside of the mounting base. Ensure the surface where you plan to mount the doorbell is clean and dry. Press the mounting base firmly onto the desired location.
 - **Method B: Using Screws**
Use the provided screws and anchors to secure the mounting base to the wall or door frame.
3. **Attach the Transmitter:** Align the buckle of the transmitter with the card slot on the mounted base and rotate clockwise to secure it.

(1) Hold the door bell and unscrew it counterclockwise.



(2) Align the buckle with the card slot and rotate clockwise to reset.



NO Damage to the wall or the door

Image: A visual guide demonstrating how to detach the transmitter from its mounting base by twisting counter-clockwise.



Image: Illustrations detailing both the screw-in and 3M adhesive installation methods for the doorbell transmitter.

5.2 Installing the Receiver

Simply plug the receiver into a standard electrical outlet in a central location within your home, or where you can easily hear it.

5.3 Video Installation Guide

For a visual guide on installation, please watch the following video:

Video: A step-by-step guide demonstrating the installation process of the PATPET Wireless Dog Doorbell, including how to apply the 3M adhesive and mount the unit.

6. OPERATING INSTRUCTIONS

Using your PATPET Wireless Dog Doorbell is straightforward:

1. **Pairing (if necessary):** The doorbell is pre-paired from the factory. If re-pairing is needed, consult the full user manual or contact support.
2. **Adjusting Settings:** Use the buttons on the receiver to select your preferred melody, volume level, and operating mode (Light on + Music, Light Flashes + Music, Music Only, Light Flashes Only).
3. **Training Your Dog:** Encourage your dog to touch the transmitter with their paw or nose when they need to go outside. Reward them immediately after they activate the doorbell and go outside. Consistency is key for effective training.

4 Selectable Modes



Light on+Music



Light Flashes+Music



Music Only



Light Flashes Only



Image: This image illustrates the four selectable modes of the doorbell, emphasizing its versatility for different user preferences and environments.

Memory Function

The doorbell features a memory function, meaning your selected settings (melody, volume, mode) will be retained even after the receiver is unplugged or power is interrupted. Settings will not change after restart.



Memory Function


Setting will not change
after restart

Image: The doorbell receiver on a wall, accompanied by a shield graphic, symbolizing its memory function that preserves settings.

7. MAINTENANCE

To ensure the longevity and optimal performance of your PATPET Wireless Dog Doorbell:

- **Cleaning:** Wipe the surfaces of both the receiver and transmitter with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Transmitter Battery:** The transmitter uses a 12V 23A battery. Replace the battery when the signal becomes weak or the transmitter stops working. Battery life is typically 6 to 12 months depending on usage.
- **Receiver Placement:** Ensure the receiver is plugged into a stable power source and is not obstructed, which could affect signal range.



Battery Life

6 month - 12 month

Image: A transparent view of the transmitter revealing its internal battery, highlighting the 6 to 12 month battery life.



Image: A graphic emphasizing the 12-month battery life of the PATPET doorbell, indicating long-lasting performance.

8. TROUBLESHOOTING

If you encounter issues with your PATPET Wireless Dog Doorbell, try the following solutions:

Problem	Possible Cause	Solution
Doorbell does not ring	Receiver unplugged or no power Transmitter battery low/dead Out of range Not paired	Ensure receiver is plugged in and power is on Replace transmitter battery Move receiver closer to transmitter Re-pair transmitter and receiver (refer to full manual)
Sound is too low/high	Volume setting incorrect	Press the Volume Button on the receiver to adjust
Melody is not desired	Incorrect melody selected	Press the Chimes Button on the receiver to cycle through melodies
Doorbell rings randomly	Interference from other devices Faulty transmitter	Change receiver location or re-pair Contact customer support

9. SPECIFICATIONS

- **Model:** B0BCFY3KG4
- **Brand:** PATPET
- **Transmitter Waterproof Rating:** IP65
- **Melodies:** 55 selectable
- **Volume Levels:** 5 (0-85dB)
- **Operating Range:** Up to 500 feet (in open area)
- **Transmitter Battery Life:** 6-12 months (typical)
- **Item Weight:** 7 ounces
- **Package Dimensions:** 4.13 x 4.09 x 3.11 inches



Image: A floor plan illustrating the 500ft operating range of the doorbell, showing its ability to cover multiple rooms within a home.



Image: A graphic highlighting the 500ft range capability of the PATPET doorbell, indicating extensive coverage.

10. WARRANTY & SUPPORT

PATPET products are designed for reliability and performance. For warranty information and customer support, please refer to the official PATPET website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Shenzhen Patpet Technology Co.,Ltd

Date First Available: August 30, 2023

For further assistance, visit the [PATPET Store on Amazon](#).

© 2024 PATPET. All rights reserved.