

[Manuals.plus](#) /

> [Zicbol](#) /

> Zicbol 47.24 Inch Linear LED Pendant Light Fixture Instruction Manual

**Zicbol 265581f0-9549-4d3a-a353-25cd3efea240**

# Zicbol 47.24 Inch Linear LED Pendant Light Fixture Instruction Manual

Model: 265581f0-9549-4d3a-a353-25cd3efea240

## 1. PRODUCT OVERVIEW

---

The Zicbol 47.24 inch linear LED pendant light fixture is designed to provide warm, dimmable illumination for various indoor spaces such as dining rooms, kitchens, breakfast bars, and living rooms. This modern fixture features a minimalist design with a black finish and an acrylic lampshade for excellent light transmission.



Image 1.1: The Zicbol linear LED pendant light fixture installed above a dining table, showcasing its sleek design and warm illumination.

## Key Features:

- **Fully Dimmable:** Compatible with dimmer switches (not included) for brightness adjustment from 0% to 100%.
- **Adjustable Height:** Pendant strings can be adjusted up to 118.11 inches maximum length.
- **Minimalist Design:** Clean lines and simple aesthetics suitable for modern interiors.
- **Durable Construction:** Made of metal with a painted finish for corrosion resistance, and an acrylic lampshade.
- **Warm Light:** Integrated 3000K LED light source.

## 2. PACKAGE CONTENTS

---

Please verify that all components are present before beginning installation.

- Linear LED Pendant Light Fixture
- Mounting Hardware (screws, wire nuts, etc.)

- Instruction Manual

### 3. SAFETY INFORMATION

---

Read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **WARNING:** Always turn off the power at the circuit breaker before installing, cleaning, or servicing the fixture.
- Consult a qualified electrician if you are unsure about the installation process.
- Do not modify the fixture in any way.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- This fixture is for indoor use only and is not water-resistant.

### 4. SETUP AND INSTALLATION

---

Follow these steps for proper installation of your Zicbol linear LED pendant light fixture.

#### 1. Prepare for Installation:

- Turn off power at the main circuit breaker.
- Unpack the fixture and inspect for any damage.
- Gather necessary tools (screwdriver, wire stripper, ladder, etc.).

#### 2. Adjust Pendant Height:




Image 4.1: Dimensions of the pendant light, indicating a maximum height of 118.11 inches and a minimum height of 4.5 inches.



Image 4.2: A close-up view of the ceiling canopy, highlighting the adjustable pins used for cable length modification.

- Before mounting, determine the desired hanging height.
- Use a screwdriver to depress the pin located on the ceiling canopy.
- While holding the pin in place, gently pull the cable to adjust the length. Repeat for each cable.
- Ensure both cables are adjusted to the same length for a level fixture.

### 3. Straighten Pendant Wires (Optional):



Image 4.3: Illustration demonstrating the use of a wire scraper to gently pull and straighten the pendant wires from top to bottom.

- If wires appear crinkled, use a plastic scraper or similar tool.
- Pinch the wires with the scraper and pull firmly but gently from the top down.
- Repeat until the wires are straight. Exercise careful strength to avoid damage.

### 4. Mount the Fixture:



# Zicbol

Image 4.4: A visual guide detailing the installation steps: adjusting cable length, connecting power, fixing the ceiling plate, and hanging the fixture.

- Unscrew the mounting plate from the ceiling canopy.
- Secure the mounting plate to the junction box in the ceiling using the provided screws.
- Connect the fixture's wires to the household electrical wires according to standard wiring practices (black to black, white to white, ground to ground). Use wire nuts to secure connections.
- Carefully tuck all wires into the junction box.
- Attach the ceiling canopy to the mounting plate, securing it with the screws.

#### 5. Final Check:

- Ensure the fixture is securely mounted and all connections are tight.
- Restore power at the circuit breaker.

## 5. OPERATING INSTRUCTIONS

---

The Zicbol linear LED pendant light fixture is designed for simple operation.

### Turning On/Off:

Operate the light using a standard wall switch connected to the fixture's circuit. The fixture is designed to respond to a push-button type switch.



Image 5.1: A visual comparison showing the pendant light fixture when turned off (top) and when illuminated with warm

light (bottom).

## Dimming Function:

This fixture is fully dimmable and compatible with most standard LED dimmer switches (dimmer switch not included). The dimming range is 0% to 100%.

- To dim the light, ensure a compatible dimmer switch is installed in your wall.
- Adjust the dimmer switch to achieve the desired brightness level.

## 6. MAINTENANCE

---

Regular maintenance helps ensure the longevity and optimal performance of your light fixture.

- **Cleaning:** Turn off power at the circuit breaker before cleaning. Use a soft, dry, or slightly damp cloth to wipe the fixture. Avoid abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** This fixture uses integrated LED lighting and does not require bulb replacement. If the LED light source fails, the entire fixture may need to be replaced or serviced by a qualified technician.
- **Inspection:** Periodically check the fixture for any loose connections or signs of wear. If any issues are found, turn off power and consult a qualified electrician.

## 7. TROUBLESHOOTING

---

If you encounter issues with your light fixture, refer to the following common troubleshooting steps:

- **Light does not turn on:**
  - Check if the power switch is in the 'ON' position.
  - Verify that the circuit breaker for the light fixture is not tripped.
  - Ensure all wire connections are secure. Turn off power at the breaker before checking connections.
- **Light flickers or is too dim/bright:**
  - If using a dimmer, ensure it is compatible with LED fixtures and functioning correctly.
  - Check for loose wiring connections.
- **Fixture makes humming noise:**
  - This can sometimes occur with incompatible dimmer switches. Try a different LED-compatible dimmer.
  - Ensure all mounting screws are tight.

If problems persist after attempting these steps, please contact customer support.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Zicbol
<b>Model Number</b>	265581f0-9549-4d3a-a353-25cd3efea240

<b>Color</b>	Black
<b>Material</b>	Acrylic
<b>Style</b>	Modern
<b>Light Fixture Form</b>	Ceiling
<b>Room Type</b>	Dining Room, Kitchen, Living Room
<b>Product Dimensions</b>	49.21"L x 8.46"W x 2.95"H
<b>Indoor/Outdoor Usage</b>	Indoor
<b>Power Source</b>	Corded Electric
<b>Installation Type</b>	Semi Flush Mount
<b>Special Feature</b>	Dimmable
<b>Control Method</b>	Push Button (via wall switch)
<b>Light Source Type</b>	LED
<b>Finish Type</b>	Matte
<b>Shade Material</b>	Acrylic
<b>Number of Light Sources</b>	1
<b>Voltage</b>	120 Volts
<b>Light Color</b>	Warm Light
<b>Included Components</b>	Mounting Hardware
<b>Item Weight</b>	3.75 Pounds
<b>Wattage</b>	16 Watts
<b>Bulb Base</b>	Wedge (Integrated LED)
<b>Color Temperature</b>	3000 Kelvin
<b>Size</b>	47.24 inches
<b>Maximum Compatible Wattage</b>	20 Watts

## 9. WARRANTY AND SUPPORT

Zicbol offers a **one-year warranty** on this linear LED pendant light fixture. Additionally, a **30-day no-reason return policy** is provided.

For any issues with the product, please do not hesitate to contact Zicbol customer support. We aim to reply to your inquiries within 24 hours.

Please refer to your purchase documentation for specific contact details or visit the official Zicbol store page.

