Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy KMB55-W

SoBuy KMB55-W Children Kids Bookcase User Manual

Model: KMB55-W

Introduction

Welcome to your new SoBuy KMB55-W Children Kids Bookcase. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly or use, and retain them for future reference.

Safety Information

General Safety Guidelines

- Ensure the bookcase is securely mounted to a wall using the appropriate hardware provided. This is crucial to prevent accidental tipping.
- Do not overload shelves beyond their specified weight limits.
- Always follow assembly instructions precisely for safe and stable use.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Regularly inspect all connections and fasteners to ensure they remain tight. Re-tighten if necessary.
- Do not allow children to climb on the bookcase.

Anti-Tipping Device

The SoBuy KMB55-W bookcase includes an anti-tipping device for enhanced safety. It is mandatory to install this device to prevent accidental tipping, especially in households with children. Failure to install this device can result in serious injury.



Image: Close-up view of the anti-tipping device, showing its attachment to the bookcase.

Package Contents

Before beginning assembly, please verify that all components listed in the separate assembly guide are present and undamaged. The package includes all necessary parts and hardware for the bookcase assembly.
If any parts are missing or damaged, please do not proceed with assembly. Contact SoBuy customer support immediately for assistance.

Assembly Instructions

Tools Required

A Phillips head screwdriver (not included) may be required for assembly. Please refer to the included hardware pack for specific tool needs.

Step-by-Step Assembly

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Follow the detailed, numbered instructions provided in the separate assembly guide included with your product.
3. Ensure all screws, dowels, and fasteners are inserted and tightened securely at each step. Do not overtighten.
4. Pay special attention to the installation of the anti-tipping device as described in the safety section and the assembly guide. This step is critical for safety.
5. Once assembled, place the bookcase in its desired location and secure it to the wall using the anti-tipping device.



Image: Overview of bookcase features, including the anti-tipping device location.

Usage and Features

The SoBuy KMB55-W bookcase is designed for children's rooms, offering versatile and accessible storage for books, toys, and other items.

Storage Compartments

The bookcase features a thoughtful design with various storage options:

- **6 Small Open Spaces:** Ideal for organizing books, small toys, or decorative items.
- **2 Large Storage Compartments:** Perfect for larger toys, bins, or bulkier items, promoting easy access for children.



Image: A close-up view of a shelf demonstrating storage capacity with books and a basket.

Weight Capacity

To ensure stability and safety, adhere to the following weight limits for each section:

- **Top Shelf:** Maximum 15 kg (33 lbs)
- **Side Shelves:** Maximum 10 kg (22 lbs) each

Do not exceed these weight limits. Overloading can compromise the structural integrity of the bookcase and pose a safety risk.



Image: Technical diagram illustrating the dimensions and maximum weight capacity for different sections of the bookcase.



Image: The SoBuy KMB55-W bookcase in a child's room, showcasing its storage capabilities.

Maintenance

To ensure the longevity and maintain the appearance of your SoBuy KMB55-W bookcase, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth.
- **Avoid Chemicals:** Do not use abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Regular Checks:** Periodically check all screws and fasteners. If any feel loose, gently tighten them to ensure the bookcase remains stable.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.

Troubleshooting

Wobbly Bookcase

If your bookcase feels unstable or wobbly after assembly:

- Ensure all screws and fasteners are fully tightened.
- Verify that the bookcase is placed on a level surface. Use furniture pads or shims if the floor is uneven.
- Confirm that the anti-tipping device is securely installed and properly anchored to the wall.

Missing or Damaged Parts

If you discover any missing or damaged parts during unpacking or assembly, please stop assembly immediately and contact SoBuy customer support for replacement parts.

Specifications

Model Name	KMB55-W
Brand	SoBuy
Material	Engineered Wood
Color	White
Item Dimensions (L x W x H)	11.81 x 41.73 x 40.94 inches (30 x 106 x 104 cm)
Item Weight	25 Kilograms (55 lbs)
Number of Shelves	9
Mounting Type	Freestanding (with wall mount option for anti-tipping)
Required Assembly	Yes

Warranty and Support

For detailed warranty information, please refer to the documentation included with your purchase or visit the official SoBuy website. SoBuy is committed to providing quality products and customer satisfaction.
If you have any questions, require technical assistance, or need to report missing/damaged parts, please contact our customer service team through the contact information provided on the SoBuy website or your purchase receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BCJK5KRD

More documents and user manuals: **https://manuals.plus/**