

[Manuals.plus](#) /

> [PERFASCIN](#) /

> PERFASCIN XRT140-V5 Replacement Smart Remote Control User Manual

PERFASCIN ANG-XRT140-V5-HNPPIC-US

PERFASCIN XRT140-V5 Replacement Smart Remote Control User Manual

Model: ANG-XRT140-V5-HNPPIC-US

PRODUCT OVERVIEW

The PERFASCIN XRT140-V5 is a replacement smart remote control designed for various Vizio D, M, P, and V Series TVs. This infrared (IR) remote requires no programming or pairing and is ready for use simply by inserting batteries. It features dedicated buttons for popular streaming services such as HBOMAX, Netflix, Prime Video, Pluto TV, iHeartRadio, Crackle, and WatchFree.





Figure 1: Front view of the PERFASCIN XRT140-V5 remote control, showing all buttons including dedicated app keys for streaming services.

COMPATIBLE MODELS

This remote control is compatible with the following Vizio TV series and specific models:

- **Series:** D-Series, M-Series, P-Series, V-Series
- **Specific Models:** V435-H11, V585-H11, V555-H11, V705-H1, M50Q7-H1, M55Q7-H1, M65Q7-H1, M55Q8-H1, M65Q8-H1, V555-H1, V655-H9, V705-H13, V405-H9, V405-H19, V505-H9, V505-H19, V605-H3, V655-H4, V655-H9, V655-H19, V705-H3, V705-H13, V435-H1, P65Q9-H1, P75Q9-H1,

P65QX-H1, P75QX-H1, P85QX-H1, OLED55-H1, OLED65-H1, V755-H4, M706X-H3, M506X-H9, M586X-H1, V655-H, V585-H, V405-H, M656-H4, V505-H

SETUP

Setting up your PERFASCIN XRT140-V5 remote control is a simple process. No complex programming or pairing is required.

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.





Figure 2: Rear view of the remote control with the battery cover removed, revealing the two AAA battery slots.

3. Insert two (2) new 1.5V AAA alkaline batteries into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Figure 3: Rear view of the remote control with the battery cover securely closed.

2. Initial Use

Once batteries are installed, the remote is ready to operate your compatible Vizio TV. Point the remote directly at the TV's infrared receiver for optimal performance.

OPERATING INSTRUCTIONS

The XRT140-V5 remote control provides intuitive access to your Vizio TV's functions and popular streaming applications.

Key Functions:

- **Power Button:** Turns the TV on or off.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **App Keys:** Dedicated buttons for direct access to HBOMAX, Netflix, Prime Video, Pluto TV, iHeartRadio,

Crackle, and WatchFree.

- **OK Button:** Confirms selections within menus.
- **Navigation Pad (Up/Down/Left/Right):** Navigates through menus and options.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the TV's main smart TV interface.
- **CC (Closed Caption) Button:** Toggles closed captions on or off.
- **VOL +/-:** Adjusts the volume level.
- **Mute Button:** Mutes or unmutes the TV audio.
- **CH +/-:** Changes TV channels.
- **Number Pad (0-9):** Directly enters channel numbers or other numerical inputs.
- **PIC Button:** Accesses picture mode settings.
- **INFO Button:** Displays information about the current program or content.
- **Settings (Gear Icon) Button:** Opens the TV's settings menu.



Figure 4: Angled view of the remote control, showcasing its ergonomic design for comfortable handling.

To ensure the longevity and optimal performance of your PERFASCIN XRT140-V5 remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries simultaneously with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** While designed to be durable, avoid dropping the remote, as this can damage internal components.

TROUBLESHOOTING

If you encounter issues with your PERFASCIN XRT140-V5 remote control, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly installed batteries. Obstruction between remote and TV. Remote out of range.	Replace batteries with new 1.5V AAA alkaline batteries, ensuring correct polarity. Remove any obstructions. Move closer to the TV and ensure direct line of sight to the TV's IR sensor.
Specific buttons not working	Button stuck or dirty.	Gently press the button multiple times. Clean around the button with a soft, dry cloth.
Remote works intermittently	Low battery power. Interference.	Replace batteries. Ensure no strong light sources (like direct sunlight or fluorescent lights) are interfering with the TV's IR sensor.

If the issue persists after trying these steps, please contact customer service for further assistance.

SPECIFICATIONS

- **Model:** ANG-XRT140-V5-HNPPIC-US
- **Brand:** PERFASCIN
- **Compatibility:** Vizio D, M, P, V Series TVs
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (Not Included)
- **Dimensions:** 7 x 2 x 0.65 inches (17.78 x 5.08 x 1.65 cm)
- **Item Weight:** 2.08 ounces (58.97 grams)
- **Connectivity Technology:** Infrared (IR)
- **Special Feature:** Ergonomic design, Dedicated App Keys

CUSTOMER SUPPORT

For any questions, concerns, or further assistance regarding your PERFASCIN XRT140-V5 remote control,

please contact our customer service team. We are committed to providing professional support.
Contact information is typically provided by the seller at the point of purchase or on the product packaging.

IMPORTANT NOTES

- This is an IR remote control and does not require Bluetooth pairing.
- Ensure a clear line of sight between the remote and your TV for proper operation.