

- [Manuals.plus](#) /
- › [Armocity](#) /
 - › Armocity Computer Desk User Manual

Armocity 55GB

Armocity Computer Desk User Manual

Model: 55GB

- [Information](#)
- [Components](#)
- [Setup](#)
- [Operation](#)
- [Maintenance & Support](#)
- [Overview](#)
- [Safety](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Warranty](#)

1. PRODUCT OVERVIEW

The Armocity Computer Desk is a versatile and modern workstation designed for home office, gaming, and general use. It features integrated LED lighting, a built-in power outlet with USB ports, a reversible design for flexible setup, and a movable monitor stand for ergonomic positioning. This manual provides detailed instructions for assembly, operation, and maintenance to ensure optimal use and longevity of your desk.



Figure 1.1: Armocity Computer Desk with LED Lights, Power Outlet, and USB ports, showcasing its modern design and integrated features.

2. SAFETY INFORMATION

- **Children Safety:** Children are not allowed to climb on the computer gaming desk for safety use.
- **Assembly Precautions:** Using the incorrect screw to assemble the table will cause the board to split or break. Always use the correct hardware as indicated in the assembly instructions.
- **Weight Capacity:** Do not overload the desk. The maximum weight recommendation is 400 pounds. Exceeding this limit may cause damage or injury.
- **Electrical Safety:** Ensure the power cord is not pinched or damaged. Do not expose the power outlets or USB ports to moisture. Disconnect from power before cleaning or if any electrical issue occurs.
- **Stability:** Ensure all connections are securely tightened after assembly to prevent wobbling. Periodically check and re-tighten screws as needed.

3. INCLUDED COMPONENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the packing list provided with your desk

for a complete inventory. The main components include:

- 1 x Computer Desk with Outlets and USB
- 1 x Monitor Stand Shelf
- 2 x Iron Hooks
- Assembly Hardware (screws, bolts, tools as required)




Figure 3.1: Diagram showing the desk's dimensions and key components like the monitor stand, power strip, and storage shelves.

4. SETUP AND ASSEMBLY

Assembly of the Armocity Computer Desk typically requires two people and takes approximately 1.5 to 2 hours. Follow the detailed instructions provided in the separate assembly manual included with your product. Below are general steps and important considerations:

1. **Prepare Workspace:** Clear a spacious area for assembly. Lay out all components and hardware, ensuring they match the packing list.
2. **Assemble Frame:** Begin by assembling the metal frame components. Ensure all screws are finger-tightened initially, then fully tighten once the frame is stable.
3. **Attach Desktop Panels:** Secure the three desktop panels to the assembled frame. Note the splice board modern look with mixed black and oak sections.

4. **Install Storage Shelves:** Attach the four storage shelves to the designated areas on the desk frame.
5. **Integrate Power Unit:** Install the power outlet and USB charging station into its designated slot. The design is reversible, allowing you to place the charging port on the left or right side of the desk according to your preference.
6. **Position Monitor Stand:** Place the movable monitor stand shelf on the desktop. This stand is designed to be movable, allowing for flexible ergonomic positioning. *Note: This stand is not screwed into the desk; some users may opt for additional securing methods like command strips for increased stability.*
7. **Attach Iron Hooks:** Secure the two iron hooks to the side of the desk frame as desired for headphones or other accessories.
8. **Connect LED Lights:** Plug the wire of the LED light into a USB port on the integrated power unit.
9. **Final Check:** Once assembled, ensure all screws are securely tightened and the desk is stable.



Figure 4.1: Illustration of the reversible design, allowing the power outlet section to be positioned on either side of the desk.

5. OPERATING INSTRUCTIONS

5.1. LED Lights

The integrated LED lights enhance your workspace ambiance, especially for gaming or evening work. They offer a variety of customization options:

- **Power On/Off:** The LED lights are powered via a USB connection to the desk's integrated power unit. Ensure the USB cable is securely plugged in.
- **Color Modes:** The lights feature 20 static colors and 21 dynamic modes. Use the included remote control or a compatible mobile application (if available, refer to the LED light's specific instructions) to cycle through colors and effects.

Movable Monitor Stand is a Must Have for Your Correct Sitting Position



Figure 5.1: Visual representation of the LED lighting modes, including 20 static colors and 21 dynamic modes.



Figure 5.2: Example of app control for the LED lighting, allowing for easy color and mode selection.


5.2. USB Charging Station & Power Outlets

The desk is equipped with 3 standard AC outlets and 2 USB ports for convenient power access:

- **AC Outlets:** Use the 3 AC outlets (120V/12A) to power your computer, monitor, desk lamp, or other electronic devices.
- **USB Ports:** The 2 USB ports (5V/2A) are ideal for fast charging of your phone, tablet, or other USB-powered devices.
- **Power Cord:** The integrated power unit connects to a wall outlet via a 6.57-foot long power cord.

Our

Other



Sturdy and Thick Steel Structure
Thick Enough to Clip a Dual Monitor Mount



Flimsy and Thin Frame
Can't Afford to Clip a Dual Monitor Mount



Heavy Duty Metal Frame



Light and Flimsy Metal Frame

Figure 5.4: Illustration demonstrating the ergonomic benefits of the movable monitor stand for maintaining correct sitting posture.

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Armocity Computer Desk:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Dusting:** Regularly dust the desk and its components to prevent buildup.
- **Screw Tightness:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary to maintain stability.
- **Cable Management:** Organize cables to prevent tripping hazards and to maintain a tidy workspace.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly after assembly.	Screws or bolts are not fully tightened.	Ensure all assembly hardware is securely tightened. Refer to the assembly manual for specific locations.
LED lights are not turning on.	USB cable for LED lights is not properly connected or power unit is not plugged in.	Check that the LED light's USB cable is firmly plugged into a USB port on the desk's power unit. Ensure the desk's main power cord is plugged into a working wall outlet.
Power outlets or USB ports are not working.	Desk's main power cord is not plugged in or circuit breaker tripped.	Verify the desk's power cord is securely plugged into a live wall outlet. Check your home's circuit breaker if other outlets are also not working.
Monitor stand slides or moves too easily.	The monitor stand is designed to be movable and is not fixed.	This is by design. For increased stability, consider using non-slip pads or adhesive strips (e.g., command strips) on the bottom of the monitor stand.
Damage to desk board during assembly.	Incorrect screws used or excessive force applied.	Always use the exact screws specified in the assembly manual for each step. Do not overtighten screws. If damage occurs, contact customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Armocity
Model Number	55GB
Product Dimensions (D x W x H)	55.2"D x 19.6"W x 29.6"H
Color	Grey and Black
Style	Desk with LED Lights and Outlets
Base Material	Metal
Finish Type	Wood
Special Feature	Reversible
Recommended Uses	Computer Desk, Desk with Storage, Gaming, Office Desk, Writing
Included Components	1 * Computer Desk with Outlets and USB, 1 * Monitor Stand Shelf, 2 * Iron Hooks
Maximum Weight Recommendation	400 Pounds
Required Assembly	Yes
Recommended Number of People for Assembly	2
Power Outlets	3 AC Outlets (120V/12A)

Feature	Detail
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	6.57 FT
Number Of Shelves	4
Item Weight	17.69 Kilograms

9. WARRANTY AND SUPPORT

Armocity offers a **2-YEAR WARRANTY** for this 55-inch computer desk. This warranty covers manufacturing defects and significant damage upon receipt.

If you have any questions regarding the assembly, operation, or if you received a damaged product, please contact Armocity customer support. Our support team is dedicated to resolving any issues you may encounter within one business day.

For support, please visit the official Armocity store or contact us through the platform where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question