

VEGER V1115

VEGER Portable Charger User Manual

Model: V1115 | Brand: VEGER

1. INTRODUCTION

This user manual provides detailed instructions for the operation and maintenance of your VEGER 10000mAh Portable Charger. This device is designed to provide convenient power on the go for a variety of electronic devices, featuring built-in cables and a wall plug for versatile charging and recharging options.

2. SAFETY INFORMATION

To ensure safe operation and prolong the lifespan of your portable charger, please adhere to the following safety guidelines:

- Do not expose the device to extreme temperatures (above 60°C/140°F or below 0°C/32°F), direct sunlight, or high humidity.
- Avoid dropping, impacting, or disassembling the device. Unauthorized repairs can void the warranty and pose safety risks.
- Keep the device away from water and other liquids.
- Use only compatible charging cables and adapters.
- Store the device in a cool, dry place when not in use.
- Keep out of reach of children.
- Do not insert foreign objects into any ports.

Comprehensive Protections



Figure 2.1: Comprehensive Protection Features

The VEGER portable charger incorporates multiple safety mechanisms to protect against common electrical issues such as short circuits, over current, over voltage, and overheating, ensuring safe and reliable charging.

3. PRODUCT OVERVIEW

The VEGER portable charger is designed for convenience and versatility. Key features include:

- **Built-in Cables & Wall Plug:** Integrated USB-C and Lightning cables, plus a foldable AC wall plug for direct recharging.
- **Multiple Outputs:** Four output options (2 built-in cables, USB-C port, USB-A port) allow simultaneous charging of up to four devices.
- **High Capacity:** 10000mAh battery capacity, sufficient for multiple charges of smartphones and other

small devices.

- **Compact Design:** Slim and lightweight, ideal for travel.
- **Digital Display:** Clear LED display showing remaining battery percentage.



Figure 3.1: All-in-One Portable Charger Design

This image illustrates the comprehensive design of the VEGER portable charger, showcasing its integrated cables and foldable wall plug for ultimate convenience.



Figure 3.2: Front View with Cables Extended

A detailed view of the portable charger, emphasizing its sleek design and the accessibility of its built-in charging cables.

4. SETUP

Before first use, it is recommended to fully charge your VEGER portable charger.

4.1 Initial Charging

1. **Using the Built-in Wall Plug:** Fold out the integrated AC wall plug and insert it directly into a standard wall outlet. The digital display will show the charging progress.
2. **Using the USB-C Port:** Connect a USB-C cable (not included) to the power bank's USB-C input/output port and then to a USB power adapter.

A full charge typically takes approximately 6 hours via the wall plug or 5 hours via the USB-C port.

2 Options for recharging the power bank

6 hrs
By Wall Plug

5 hrs
By USB C Port



Figure 4.1: Recharging Options

The portable charger offers flexible recharging options: directly from a wall outlet using its integrated plug, or through its USB-C port for convenience.

4.2 Understanding the Digital Display

The LED digital display indicates the remaining battery percentage of the power bank. When charging or discharging, the numbers will fluctuate to show real-time status.

5. OPERATING INSTRUCTIONS

5.1 Charging Your Devices

The VEGER portable charger can charge up to four devices simultaneously.

1. Using Built-in Cables:

- For iPhone/iPad: Use the built-in Lightning cable.
- For USB-C devices: Use the built-in USB-C cable.

2. Using USB Ports:

- Connect your device's USB-A cable to the power bank's USB-A output port.
- Connect your device's USB-C cable to the power bank's USB-C input/output port.

3. Once connected, the power bank will automatically begin charging your device(s). The digital display will show the remaining battery percentage.



Figure 5.1: Simultaneous Device Charging

This illustration demonstrates the ability of the Veger portable charger to charge multiple devices concurrently, utilizing

its various output options.

5.2 Recharging the Power Bank

Refer to section 4.1 for detailed instructions on recharging the power bank.

6. COMPATIBILITY

The VEGER portable charger offers wide compatibility with various electronic devices:

- **iPhones/iPads:** Compatible with all iPhone models (e.g., iPhone 13/12/11/Xs/X/8/SE) and iPad models (e.g., iPad Air, iPad Pro) via the built-in Lightning cable or a separate USB-A/USB-C to Lightning cable.
- **USB-C Devices:** Compatible with Android smartphones (e.g., Google Pixel, Samsung S21/S20/S10/S9, Z Fold2/Note20/Note10) and other USB-C enabled tablets and devices via the built-in USB-C cable or a separate USB-C cable.
- **Micro USB Devices:** Compatible with devices requiring Micro USB (e.g., Vivo Z5x/Z3x) via the built-in Micro USB cable.
- **Other Devices:** Can charge other USB-powered devices such as AirPods, smartwatches, and small electronic gadgets using their respective USB cables connected to the power bank's USB-A or USB-C ports.

Universal Compatibility

For iPhones / ipads series



iPhone 13/12/11/ Xs/
X 12 pro max/SE/8 plus



iPad Air 9.7"/10.5"/10.9"
iPad Pro 10.5"/10.9"



Apple AirPods Pro/
AirPods...

Type-C



Google Pixel P5/P4/P4a
/P3/P3XL...



Samsung S21/S20/S10/S9/
Z Fold2/ Note20/Note 10

Micro USB



vivo Z5x/Z3X/

And More



Figure 6.1: Universal Device Compatibility

The charger supports a broad range of devices, including Apple products, Android phones with USB-C, and older devices with Micro USB, making it a versatile charging solution.

7. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your portable charger:

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid storing the device in extremely hot or cold environments.
- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.

- Ensure the built-in cables are properly stored in their designated slots when not in use to prevent damage.

8. TROUBLESHOOTING

If you encounter issues with your VEGER portable charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging.	Low power bank battery; loose connection; incompatible cable/device.	Recharge the power bank. Ensure cables are securely connected. Verify device compatibility.
Power bank not recharging.	Loose wall plug/USB-C connection; faulty outlet/adaptor.	Ensure the wall plug is fully inserted or USB-C cable is secure. Try a different outlet or adaptor.
Slow charging.	Using non-fast charging port/cable; multiple devices charging simultaneously.	Ensure you are using the appropriate port/cable for fast charging. Disconnect other devices if faster charging is needed for one.
Digital display not working.	Device is off; internal malfunction.	Press the power button to activate the display. If issue persists, contact customer service.

9. SPECIFICATIONS

Feature	Detail
Model Number	V1115
Battery Capacity	10000 Milliamp Hours
Product Dimensions	5.9 x 2.7 x 0.72 inches
Item Weight	8 ounces
Input (Wall Plug)	100-240VAC, 50/60 Hz
Output (Built-in Cables & USB Ports)	Up to 15W (5V/3A)
Special Features	Built-in Lightning cable, Built-in USB-C cable, Foldable AC Wall Plug, Digital Display
What's in the Box	Portable charger with built-in cables, user manual

Ultra Compact Size

Take it and power up your devices anywhere



8 oz



5.9 x 2.7 x 0.72 in



Figure 9.1: Ultra Compact Size

The charger's compact dimensions and light weight make it highly portable and convenient for travel.

10. OFFICIAL PRODUCT VIDEOS

Watch the official product video for a visual guide on using your VEGER Portable Charger:

Your browser does not support the video tag.

Video 10.1: VEGER Portable Charger with Built-in Cable and Wall Plug

This video provides a comprehensive overview of the VEGER portable charger, demonstrating its features, built-in cables, and integrated wall plug for convenient charging and recharging.

11. WARRANTY AND SUPPORT

Your VEGER portable charger comes with a worry-free 12-month guarantee. For any issues or inquiries, please contact VEGER customer service. They are available 7 days a week, 24 hours a day, and aim to resolve problems within 12 hours.

Manufacturer: VEGER

Seller: VEGER-US

For further assistance, please refer to the contact information provided in your product packaging or visit the official VEGER website.