

Armocity B0BCL26D7L

Armocity 47-inch Computer Gaming Desk with LED Lights and Power Outlet User Manual

Brand: Armocity | Model: B0BCL26D7L

1. INTRODUCTION

Thank you for choosing the Armocity 47-inch Computer Gaming Desk. This desk is designed to enhance your gaming or work experience with integrated LED lighting, convenient power outlets, and a reversible, movable monitor stand. Please read this manual carefully before assembly and use to ensure proper setup and safe operation.

2. SAFETY INFORMATION

- Ensure correct screws are used during assembly to prevent the desk board from splitting or breaking.
- Do not allow children to climb on the desk.
- The desk has a maximum weight capacity of 300 lbs (136 kg). Do not exceed this limit.
- Keep all electrical components away from water or excessive moisture.
- Do not attempt to modify the electrical components or wiring.

3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact Armocity customer support.

- Desk Boards (Main desktop, side desktop, storage shelves)
- Metal Frame Components
- Power Outlet and USB Charging Station (pre-installed in side desktop)
- Movable Monitor Stand Shelf
- 2 Iron Hooks
- LED Light Strip (pre-installed in monitor stand)
- Full Set Installation Accessories (screws, Allen wrench, screwdriver)
- Installation Instruction Manual (separate document)

4. SETUP AND ASSEMBLY

Refer to the separate **Installation Instruction Manual** included in your package for detailed, step-by-step assembly diagrams and instructions. The following provides general guidance:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list in the separate manual.
2. **Assemble the Frame:** Begin by assembling the metal frame components. Ensure all screws are tightened securely but do not overtighten to avoid stripping.
3. **Attach Desktop Boards:** Secure the main desktop and side desktop to the assembled frame. Note that the side desktop with the power outlet is **reversible**, allowing you to position the charging station on either the left or right side according to your preference.
4. **Install Storage Shelves and Hooks:** Attach the two storage shelves and iron hooks to the designated areas on the side frame.
5. **Position Monitor Stand:** Place the movable monitor stand on the main desktop. It is not fixed, allowing for flexible positioning.
6. **Connect Power:** Plug the desk's power cord (6.57 feet long) into a standard wall outlet.



Figure 4.1: Desk dimensions and components overview. The side desktop with power outlets can be installed on either side.




Figure 4.2: Key features and structural elements of the desk, including the modern two-color desktop, sturdy structure, iron hooks, and storage shelves.

Your browser does not support the video tag.

Video 4.1: Official Armocity Gaming Desk with LED Lights overview, demonstrating features and setup options.

5. OPERATING INSTRUCTIONS

5.1 LED Lights

The monitor stand features integrated LED lights to enhance your gaming or work environment. These lights offer:

- **20 Static Colors:** Choose from a variety of solid colors to match your mood or setup.
- **21 Dynamic Modes:** Explore various lighting effects and patterns.

Control the LED lights using the remote control (if included) or integrated buttons on the monitor stand. Refer to the separate LED light instruction sheet for specific control details.



Figure 5.1: Illustration of the controller RGB lighting modes, showing 20 static colors and 21 dynamic modes.

5.2 Power Outlets and USB Ports

The side desktop is equipped with a built-in power strip for convenient access to power. It includes:

- **3 AC Outlets (120V/12A):** For powering your computer, monitor, lamps, and other AC-powered devices.
- **2 USB Ports (5V/2A):** For charging smartphones, tablets, and other USB-powered devices.

The power cord for this station is 6.57 feet long, providing flexibility in desk placement. Ensure devices are properly plugged in and do not overload the power strip.




Figure 5.2: Detail of the integrated power outlet and USB charging station, showing devices charging.

5.3 Movable Monitor Stand

The monitor stand is designed to be movable, allowing you to adjust your monitor's height and position for optimal ergonomics. This helps maintain a correct sitting posture, reducing strain during long periods of use.



Figure 5.3: The movable monitor stand promotes correct sitting posture by allowing height adjustment for your monitor.

6. MAINTENANCE

To ensure the longevity and appearance of your Armocity desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners to maintain stability.
- **Electrical Components:** Keep the power outlets and USB ports clean and free of dust. Do not insert foreign objects into the ports.

7. TROUBLESHOOTING


If you encounter any issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Holes do not align during assembly.	Incorrect orientation of parts or minor manufacturing variance.	Review the instruction manual carefully to ensure parts are oriented correctly. Loosen all screws slightly, align the parts, then tighten. If issues persist, contact customer support.

Problem	Possible Cause	Solution
Power outlets/USB ports not working.	Not plugged into wall, overloaded circuit, internal wiring issue.	Ensure the desk's power cord is securely plugged into a functional wall outlet. Check if the wall outlet is working by plugging in another device. Avoid plugging too many high-power devices into the strip. If the issue continues, contact customer support.
Desk is wobbly.	Loose fasteners, uneven floor.	Tighten all assembly screws. Use the adjustable feet (if present) to level the desk on uneven surfaces.
LED lights not turning on or changing colors.	Power issue, remote control battery dead, connection issue.	Ensure the desk's power is connected. Check the remote control battery. Verify all LED light connections are secure.


8. SPECIFICATIONS

Feature	Detail
Brand	Armocity
Model	B0BCL26D7L
Desk Design	Computer Desk
Product Dimensions (D x W x H)	47.2"D x 19.69"W x 29.6"H
Color	Grey and Black
Style	Modern
Base Material	Metal
Top Material Type	Metal (with Oak finish)
Special Feature	Reversible design, LED Lights, Power Outlets, USB Ports, Movable Monitor Stand
Power Outlets	3 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	6.57 feet
Number of Shelves	2
Maximum Weight Recommendation	300 Pounds (136 kg)
Required Assembly	Yes
Recommended Number of People for Assembly	1




120V/12A

3 AC Outlets



5V/2A

[2 USB Ports]



6.57-Foot

[Power Cord]

Figure 8.1: Illustration highlighting the sturdy and thick steel structure of the Armocity desk compared to a light and flimsy metal frame.

9. WARRANTY AND CUSTOMER SUPPORT

Armocity provides a **Limited Warranty** for this product. For specific details regarding the warranty coverage and duration, please refer to the warranty information included with your purchase or contact customer support.

If you have any questions during assembly, encounter damage, or require assistance with your Armocity Computer Gaming Desk, please contact our customer support team. We are committed to resolving all problems efficiently.

Contact Information: Please refer to the contact details provided in your product packaging or on the official Armocity website for the most up-to-date support information.