

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Armocity](#) /

› Armocity Computer Desk with LED Lights, 55 Inch Desk with Power Outlet and USB, Reversible Large Desk with Moveable Monitor Stand, 55.2" Gaming PC Table for Home Office, Workstation, Grey and Black Grey and Black 55.2" - User Manual

Armocity 55GB

Armocity Computer Desk User Manual

Model: 55GB

INTRODUCTION

Thank you for choosing the Armocity Computer Desk. This desk is designed to enhance your home office or gaming setup with its integrated LED lights, power outlets, USB charging ports, and a versatile reversible design. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk.



Image: The Armocity Computer Desk, showcasing its spacious design, integrated LED lighting, and convenient power and USB outlets.

SAFETY INFORMATION

Please read all safety warnings before assembly and use.

- Children are not allowed to climb on the computer gaming desk for safety use.
- Using the incorrect screw to assemble the table will cause the board to split or break. Always use the correct hardware as indicated in the assembly steps.
- Ensure all connections for the power outlets and USB ports are secure before use.
- Do not overload the power outlets. Refer to the specifications for maximum electrical load.

COMPONENTS LIST

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, please contact Armocity customer support.

- 1 x Computer Desk with Outlets and USB

- 1 x Monitor Stand Shelf
- 2 x Iron Hooks
- Assembly Hardware (screws, bolts, tools as specified in packaging)

SETUP AND ASSEMBLY

Assembly typically requires two people. Follow the steps carefully to ensure proper and safe construction.

Step 1: Unpack and Identify Parts

Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided labels or diagrams.

Step 2: Assemble the Frame

Begin by assembling the main metal frame of the desk. Ensure all connections are finger-tight before fully tightening with the provided tools.



Image: Illustration highlighting the sturdy and thick steel structure of the Armocity desk frame, designed for durability and stability.

Step 3: Attach Desktop Panels and Shelves

Attach the three desktop panels to the assembled frame. Note the reversible design: you can position the small black desktop section on either the right or left side, which also determines the placement of the charging port.



Image: Diagram illustrating the reversible design of the desk, allowing the charging station to be positioned on either the left or right side.

Install the four storage shelves into their designated positions. These shelves provide ample space for your computer tower, books, or other items.

Step 4: Install Power Outlet and USB Hub

Secure the integrated power outlet and USB hub into the designated slot on the desktop. Ensure the power cable is routed safely and is not pinched.

Step 5: Place Monitor Stand and Hooks

The monitor stand shelf is moveable and can be placed anywhere on the main desktop surface. Attach the two iron hooks

to the side of the desk frame as desired for headphones or other accessories.





Image: An overhead view of the desk with key dimensions and features highlighted, including the monitor stand, power outlet, storage shelves, and iron hooks.

OPERATING INSTRUCTIONS

Using the LED Lights

The desk features integrated LED lights. Plug the LED light wire into one of the USB ports on the desk. Use the included controller or a compatible app to change lighting modes and colors. There are 20 static colors and 21 dynamic modes available.

Our



Sturdy and Thick Steel Structure
Thick Enough to Clip a Dual Monitor Mount

Other



Flimsy and Thin Frame
Can't Afford to Clip a Dual Monitor Mount



Heavy Duty Metal Frame



Light and Flimsy Metal Frame

Image: Visual representation of the controller for the RGB lighting modes, showing options for 20 static colors and 21 dynamic modes.

Utilizing Power Outlets and USB Ports


The desk is equipped with 3 AC outlets and 2 USB ports (5V/2A) for convenient charging of your devices. Simply plug your devices into the available ports. The power cable length is 6.57 feet.



120V/12A
3 AC Outlets



5V/2A
[2 USB Ports]



6.57-Foot
[Power Cord]

Image: Close-up view of the integrated power strip with 3 AC outlets and 2 USB ports, demonstrating phone and tablet charging capabilities.

Adjusting the Monitor Stand

The monitor stand is designed to be moveable, allowing you to adjust your monitor's height for an ergonomic sitting position. This helps promote correct posture during work or gaming sessions.

Movable Monitor Stand is a Must Have for Your Correct Sitting Position



Image: Illustration demonstrating the importance of the movable monitor stand for achieving a correct and ergonomic sitting position, contrasting incorrect and correct postures.

MAINTENANCE

To ensure the longevity and appearance of your Armocity Computer Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Dusting:** Regularly dust the desk and its components to prevent buildup.
- **Tightening:** Periodically check and tighten all screws and bolts to maintain stability.
- **Electrical Components:** Keep the power outlets and USB ports free from dust and debris. Do not expose them to liquids.

TROUBLESHOOTING

If you encounter any issues with your Armocity Computer Desk, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly.	Loose screws or uneven floor.	Tighten all assembly screws. Adjust leveling feet if present, or place shims under legs on uneven surfaces.
LED lights are not working.	USB connection loose, power issue, or remote battery.	Ensure the LED light USB cable is securely plugged into a working USB port. Check the power source. Replace remote battery if applicable.
Power outlets/USB ports not charging.	Desk not plugged in, circuit breaker tripped, or device issue.	Verify the desk's main power cord is securely plugged into a wall outlet. Check your home's circuit breaker. Test with a different device to rule out device-specific issues.

SPECIFICATIONS

Feature	Detail
Model Number	55GB
Product Dimensions	55.2"D x 19.6"W x 29.6"H
Color	Grey and Black
Base Material	Metal
Finish Type	Wood
Special Feature	Reversible, LED Lights, Power Outlets, USB Ports
Included Components	Computer Desk, Monitor Stand Shelf, 2 Iron Hooks
Maximum Weight Recommendation	400 Pounds
Power Outlets	3 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	6.57 FT
Number of Shelves	4
Item Weight	17.69 Kilograms

WARRANTY AND SUPPORT

Armocity offers a **2-YEAR LIMITED WARRANTY** for this computer desk. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

If you have any questions during assembly, encounter damage, or require further assistance, please contact Armocity customer support. Our team is dedicated to resolving any issues within one business day.

For support, please visit the official Armocity store or contact us through your purchase platform.

[Visit the Armocity Store on Amazon](#)

© 2024 Armocity. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BCL3ZVLM>

More documents and user manuals: <https://manuals.plus/>