



Manuals.plus /

› [Lenovo](#) /

› [Lenovo Tab M10 Plus Gen 3 10.6-inch Tablet User Manual](#)

Lenovo ZAAJ0402US

Lenovo Tab M10 Plus Gen 3 10.6-inch Tablet User Manual

Model: ZAAJ0402US

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Lenovo Tab M10 Plus Gen 3 tablet. Please read this manual thoroughly before operating the device and retain it for future reference.

PRODUCT OVERVIEW

The Lenovo Tab M10 Plus Gen 3 is a 10.6-inch Android tablet designed for multimedia consumption, productivity, and educational use. It features a 2K IPS display, quad speakers with Dolby Atmos, and runs on Android 12.




Figure 1: Front view of the Lenovo Tab M10 Plus Gen 3 tablet displaying a vibrant wallpaper.

Key Features:

- 10.6-inch 2K IPS Display
- MediaTek Helio G80 Processor
- 4GB RAM, 128GB Storage
- Android 12 Operating System
- Quad Speakers with Dolby Atmos
- Front and Rear Cameras
- Lightweight and Portable Design

WHAT'S IN THE BOX

Upon unboxing your Lenovo Tab M10 Plus Gen 3, verify that all components are present:

- Lenovo Tab M10 Plus Gen 3 Tablet
- Charger
- Quick Start Guide (may be separate or integrated)
- Safety and Warranty Information (may be separate or integrated)

If any items are missing or damaged, contact your retailer or Lenovo support immediately.

SETUP

1. Charging the Tablet

Before initial use, fully charge your tablet. Connect the provided charger to the tablet's USB-C port and plug it into a

power outlet. The charging indicator will illuminate.



Figure 2: Side view illustrating the USB-C charging port and speaker placement.

2. Powering On/Off

- **To Power On:** Press and hold the Power button (located on the side) until the Lenovo logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears, then select "Power off".
- **To Restart:** Press and hold the Power button until the power options menu appears, then select "Restart".




Figure 3: Side view highlighting the power button and volume controls.

3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes:

1. Selecting your language.
2. Connecting to a Wi-Fi network.
3. Signing in with your Google account or creating a new one.
4. Setting up screen lock (PIN, pattern, password, or fingerprint).
5. Reviewing and accepting terms and conditions.

OPERATING INSTRUCTIONS

Navigation

The tablet uses a touch-based interface. Common gestures include:

- **Tap:** Select an item or open an app.
- **Long Press:** Access contextual menus or move icons.
- **Swipe:** Scroll through content or navigate between screens.
- **Pinch-to-Zoom:** Enlarge or reduce content size.



Figure 4: The tablet's home screen, showing typical Android interface elements and app icons.

Connecting to Wi-Fi

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle **Wi-Fi On**.

3. Select your desired network from the list.
4. Enter the password if prompted, then tap **Connect**.

Using Cameras

The tablet is equipped with both front and rear cameras. Open the Camera app to capture photos or videos.

- Tap the shutter button to take a photo.
- Switch between photo and video modes as needed.
- Use the icon to switch between front and rear cameras.



Figure 5: Rear view of the tablet, highlighting the main camera lens and flash.

Immersive Reading Mode

To reduce eye strain during extended reading sessions, activate Immersive Reading Mode. This feature adjusts display settings for enhanced readability, simulating a paper-like experience. Access this mode through the Quick Settings panel or Display settings.

MAINTENANCE

Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn smudges, lightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

Battery Care

- Avoid extreme temperatures, as they can degrade battery life.

- Use only the charger provided or a certified compatible charger.
- Do not leave the tablet fully discharged for extended periods.

Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to **Settings > System > System update**.

TROUBLESHOOTING

Problem	Possible Solution
Tablet does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a force restart by holding the power button for 10-15 seconds.
Wi-Fi connection issues.	Restart your Wi-Fi router. On the tablet, toggle Wi-Fi off and then on again. Forget the network and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps are crashing or freezing.	Close and reopen the app. Clear the app's cache Settings > Apps > [App Name] > Storage & cache > Clear cache). Update the app from the Google Play Store. Restart the tablet.
Slow performance.	Close unused apps. Clear cache for frequently used apps. Free up storage space by deleting unnecessary files. Restart the tablet regularly.

SPECIFICATIONS

Feature	Detail
Model Name	Lenovo Tab M10 Plus Gen 3
Model Number	ZAAJ0402US
Display	10.6-inch 2K (2000x1200) IPS
Processor	MediaTek Helio G80
RAM	4GB
Storage	128GB
Operating System	Android 12 (or later)
Wireless Connectivity	Wi-Fi 802.11ac
Front Camera	8MP
Rear Camera	13MP
Audio	Quad Speakers with Dolby Atmos
Dimensions (LxWxH)	10.6 x 6.9 x 1.7 inches
Weight	1 pound
Color	Storm Gray

WARRANTY INFORMATION

Lenovo products are covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Lenovo support website. Proof of purchase is required for warranty claims.

Optional protection plans may be available for extended coverage. Refer to your purchase documentation for details on any additional plans acquired.

SUPPORT

For further assistance, technical support, or service inquiries, please contact Lenovo customer support through the following channels:

- **Lenovo Support Website:** support.lenovo.com
- **Customer Service Phone:** Refer to your region-specific contact information on the support website.

When contacting support, please have your tablet's model number (ZAAJ0402US) and serial number ready.

