

Femivo DC101AF

Femivo 4K Digital Camera User Manual

Model: DC101AF

1. INTRODUCTION

Welcome to the user manual for your new Femivo 4K Digital Camera. This camera is designed for both photography and video recording, offering features such as 4K video resolution, 48MP image capture, autofocus, anti-shake technology, and a convenient 180° flip screen. This manual provides detailed instructions on setting up, operating, maintaining, and troubleshooting your camera to ensure you get the most out of its capabilities.



Figure 1: Femivo 4K Digital Camera with included 32GB SD card and two batteries.

2. What's Included

Please check the package contents to ensure all items are present:



Figure 2: Package contents including the camera, user manual, charger, cables, lens, lens cap, batteries, SD card, camera bag, strap, and cleaning cloth.

- Femivo 4K Digital Camera Body
- Lens
- Lens Cap
- User Manual
- Charger
- Mini USB Cable
- HDMI Cable
- 32GB SD Card
- Rechargeable Battery (x2)
- Camera Bag
- Wrist Strap
- Cleaning Cloth

3. SETUP

3.1. Battery Installation and Charging

1. Open the battery compartment cover located at the bottom of the camera.
2. Insert the rechargeable battery, ensuring the correct polarity as indicated inside the compartment.
3. Close the battery compartment cover securely.
4. Connect the camera to the charger using the provided Mini USB cable. Plug the charger into a power outlet. The charging indicator light will illuminate.
5. Allow the battery to fully charge before first use. A full charge typically takes approximately 2-3 hours.

3.2. SD Card Installation and Formatting

1. Locate the SD card slot, usually next to the battery compartment.
2. Insert the provided 32GB SD card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.
3. Turn on the camera.

4. Navigate to the camera's settings menu.
5. Select the "Format SD Card" option and confirm. This will erase all data on the card and prepare it for use with your camera.



Figure 3: Location of the battery and SD card slot on the camera.

4. OPERATING THE CAMERA

4.1. Basic Controls and Interface

Familiarize yourself with the camera's buttons and the 3-inch LCD screen. The screen displays shooting information, menu options, and live view.

Travel Camera with Flash



Figure 4: Rear view of the camera highlighting the 3-inch flip screen and control buttons.

4.2. Taking Photos

The camera features a 48MP image sensor with autofocus and anti-shake for clear photos.

1. Turn on the camera.
2. Frame your shot using the flip screen.
3. Half-press the shutter button to activate autofocus. The focus frame will change color (e.g., from yellow to green) when focus is achieved.
4. Fully press the shutter button to capture the photo.



Figure 5: Demonstrating the half-press autofocus feature for clear image capture.

4.3. Recording Videos

Record high-quality 4K videos with ease. The camera supports pause function, time-lapse, and slow-motion.

1. Switch the camera to video mode.
2. Press the record button to start recording.
3. Press the record button again to pause or stop recording.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the Femivo Digital Camera in use, highlighting its video recording capabilities.

4.4. Using the Flip Screen

The 180° flip screen allows for easy self-portraits (selfies) and vlogging. Simply rotate the screen to face forward for convenient framing.

4.5. Flash Modes

The built-in flash can be adjusted for different lighting conditions:

- **Image Flash Modes:** Auto, Force Flash, No Flash
- **Video Flash Modes:** Force Flash, No Flash

Access flash settings through the camera's menu.

4.6. Digital Zoom

The camera features 16x digital zoom. Use the zoom controls (often marked 'W' for wide and 'T' for telephoto) to adjust the focal length. Note that digital zoom may reduce image quality compared to optical zoom.

4.7. Webcam Functionality

Your Femivo camera can be used as a webcam for live streaming or video calls.

1. Connect the camera to your computer using the Mini USB cable.
2. On the camera screen, select the "PC" or "Webcam" mode (if prompted).
3. Your computer should recognize the camera as a webcam. Select it in your video conferencing or streaming software.



Figure 6: The camera can be used as a webcam for live streaming and video calls.

5. MAINTENANCE

5.1. Cleaning the Camera

- Use the provided cleaning cloth or a soft, lint-free cloth to gently wipe the camera body and screen.
- For the lens, use a lens cleaning solution and a microfiber cloth specifically designed for camera lenses. Avoid touching the lens surface with your fingers.
- Do not use harsh chemicals or abrasive cleaners.

5.2. Battery Care

- Store batteries in a cool, dry place when not in use.
- Avoid fully discharging the batteries frequently to prolong their lifespan.
- If storing the camera for an extended period, remove the batteries.

5.3. Storage

- Store the camera in its camera bag to protect it from dust and scratches.
- Keep the camera away from extreme temperatures, high humidity, and direct sunlight.

6. TROUBLESHOOTING

If you encounter issues with your camera, please refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Camera does not turn on	Battery is low or not inserted correctly.	Ensure batteries are fully charged and correctly inserted. Try using the second battery.
SD card error / Card not recognized	SD card is not formatted or is faulty.	Format the SD card via the camera's settings menu. Ensure the SD card is inserted correctly. Try a different compatible SD card.

Problem	Possible Cause	Solution
Photos are blurry	Improper focus, low light, or camera shake.	Half-press the shutter button to autofocus before fully pressing. Ensure adequate lighting or use the flash. Hold the camera steady or use a tripod.
No audio in recorded videos	Microphone settings or malfunction.	Check audio settings in the camera menu. Ensure no external microphone is connected if you intend to use the built-in one. If the issue persists, contact customer support.
Screen is cracked or damaged	Physical damage.	This requires repair. Contact customer support for assistance.
Cannot connect to computer as webcam	Incorrect connection mode or driver issue.	Ensure "PC" or "Webcam" mode is selected on the camera after connecting via USB. Try a different USB port or cable. Check computer's device manager for driver issues.

7. SPECIFICATIONS

Key technical specifications for the Femivo 4K Digital Camera:

Feature	Detail
Model Name	4K Vlogging Camera with SD Card, 48MP Digital Camera with 2 Rechargeable Batteries
Model Number	DC101AF
Photo Sensor Resolution	48 MP
Video Resolution	2160p (4K), 4320p
Screen Size	3 Inches
Display Type	LCD
Digital Zoom	16x
Image Stabilization	Digital
Autofocus	Yes (Contrast/Face/Smile Detection)
Flash	Built-In
Supported Memory Card	Micro SD (up to 128 GB)
Battery Type	Rechargeable Lithium Polymer Battery, 800mAh
Connectivity	Micro USB, HDMI
Item Weight	0.54 Pounds




8. WARRANTY AND SUPPORT

Your Femivo 4K Digital Camera comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

For any questions, technical assistance, or warranty claims, please do not hesitate to contact Femivo customer support. We are committed to providing excellent service and will respond to your inquiries within 24 hours.

For additional support, you may refer to the official [User Guide \(PDF\)](#) or [User Manual \(PDF\)](#).

Related Documents - DC101AF

<div><div>Digital Camera User Manual</div><div></div><div>When you receive the camera, please read the quick guide and operate it first, so as to facilitate subsequent use.</div><div>1</div></div>	<p>Digital Camera User Manual - DC101L-AF 4K</p> <p>User manual for the DC101L-AF 4K digital camera, providing instructions on battery insertion, charging, SD card usage, formatting, taking photos, playback, downloading files, and using it as a webcam.</p>
<div><div>Digital Camera User Manual</div><div></div></div>	<p>wrozgxaig DC101AF Digital Camera User Manual</p> <p>Comprehensive user manual for the wrozgxaig DC101AF digital camera, covering setup, operation, features, and safety guidelines.</p>
<div><div>Digital Camera User Manual</div><div></div><div>When you receive the camera, please read the quick guide and operate it first, so as to facilitate subsequent use.</div><div>1</div></div>	<p>Digital Camera User Manual - DC101L-AF 4K</p> <p>User manual for the DC101L-AF 4K digital camera, providing instructions on battery insertion, charging, SD card usage, formatting, taking photos, playback, downloading files, and using it as a webcam.</p>

Documents - Femivo – DC101AF



[Digital Camera User Manual - DC101L-AF 4K](#)

User manual for the DC101L-AF 4K digital camera, providing instructions on battery insertion, charging, SD card usage, formatting, taking photos, playback, downloading files, and using it as a webcam.

lang:en score:19 filesize: 282.89 K page_count: 12 document date: 2022-10-18



[\[pdf\] User Manual](#)

DC101AF 135mm 100mm 20220907 AD 4K Digital Camera for Photography and Video Autofocus Anti Shake 48MP Vlogging with SD Card 3 180° Flip Screen Compact Flash 16X Zoom Travel 2 Batteries User Manual Femivo 81HjYpS3fzL m media amazon images I |||

Digital Camera User Manual

1MFBTFSFBEUIFVTFSNBOVBMDBSFGVMMZCFGPSFVTFBOELFFQJUGPSGVUVSFSFGFSFOD

Contents -FUUFS UP FBS VTUPNFS *OUSPEVDUJPO PG BNFSB 1BSUT PX UP JOTFSU BOE

SFNPWF UIF CBUUFSZ PX UP DIBSHF UIF D...

lang:en score:18 filesize: 398.13 K page_count: 30 document date: 2022-10-18