Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Tiny Land /
- > Tiny Land Wooden Dollhouse User Manual

Tiny Land WT0017

Tiny Land Wooden Dollhouse User Manual

Model: WT0017 | Brand: Tiny Land

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Tiny Land Wooden Dollhouse. Designed to inspire imagination and creativity, this three-story dollhouse features 6 rooms and comes with 31 pieces of modern furniture. Please read this manual thoroughly before assembly and use to ensure safe and optimal enjoyment of the product.



Figure 1.1: Tiny Land Wooden Dollhouse in use.

2. SAFETY INFORMATION

WARNING:

- Adult supervision is required during assembly and play.
- Keep the product away from fire and open flames.
- This product contains small parts and is not suitable for children under 36 months due to choking hazards.

• Ensure all parts are securely fastened before allowing children to play.

The dollhouse is constructed from high-quality, sustainable wood and finished with waterproof paints, ensuring durability and safety. It is CPSIA certified.

3. What's in the Box

The Tiny Land Wooden Dollhouse package includes the following components:

- Wooden Dollhouse structure components
- 31 pieces of furniture accessories, including:
 - Living Room furniture (e.g., sofa, coffee table, lamp)
 - Dining Room furniture (e.g., table, chairs, bench)
 - Bedroom furniture (e.g., bed, dresser)
 - Bathroom furniture (e.g., bathtub, toilet, sink vanity)
 - Children's Room furniture (e.g., bunk beds, rocking horse)
 - Baby Room furniture (e.g., crib, play tent, baby walker)
- Assembly hardware (screws, connectors)
- · Detailed assembly instructions



Figure 3.1: Included furniture accessories.

4. SETUP AND ASSEMBLY

Assembly of the Tiny Land Wooden Dollhouse is designed to be straightforward. It is recommended that an adult performs the assembly.

4.1 Preparation

- Unpack all components and verify against the parts list provided in the separate assembly instructions.
- Ensure you have a clear, flat, and spacious area for assembly.
- Gather necessary tools (e.g., screwdriver, not included).

4.2 Assembly Steps

Refer to the detailed step-by-step assembly instructions included in your package for specific diagrams and fastening procedures. General steps include:

- 1. Assemble the base structure of the dollhouse.
- 2. Attach the side panels and internal dividers to form the rooms.
- 3. Install the floor panels for each level.
- 4. Secure the roof sections.
- 5. Place the decorative wallpapers in each room as desired.
- 6. Arrange the 31 furniture pieces within the rooms according to preference.



Figure 4.1: Dollhouse dimensions and construction details.

5. OPERATING INSTRUCTIONS (PLAY)

The Tiny Land Wooden Dollhouse is designed for imaginative play for children aged 36 months to 10 years. Its open-plan design allows for easy access to all rooms and encourages creative storytelling and role-playing.

5.1 Engaging with the Dollhouse

- Children can arrange and rearrange the 31 furniture pieces to create various room layouts and scenarios.
- The dollhouse features 6 distinct rooms: living room, dining room, bedroom, bathroom, children's room, and baby room, each with unique wallpaper designs to inspire different play themes.
- Encourage children to develop narratives and characters for their dollhouse inhabitants, fostering creativity and social skills.



Figure 5.1: Children engaging in imaginative play with the dollhouse.

INSPIRE IMAGINATION Let Kids Dive into a World of Imaginative Play



Figure 5.2: Detailed views of various dollhouse rooms.

6. MAINTENANCE

Proper care will ensure the longevity of your Tiny Land Wooden Dollhouse.

- Cleaning: Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Storage:** Store the dollhouse in a dry environment, away from direct sunlight or extreme temperatures, to prevent warping or fading of the wood and paint.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Tighten as necessary to maintain structural integrity.
- Furniture Care: The wooden furniture pieces can also be wiped clean with a damp cloth.

7. TROUBLESHOOTING

If you encounter any issues with your Tiny Land Wooden Dollhouse, please refer to the following common solutions:

Problem	Possible Cause	Solution
Parts do not fit together during assembly.	Incorrect orientation or mismatched parts.	Refer to the assembly instructions carefully. Ensure parts are oriented correctly and that you are using the right components for each step.
Dollhouse feels wobbly after assembly.	Screws are not fully tightened.	Check all assembly points and tighten screws firmly. Do not overtighten.
Missing or damaged parts.	Manufacturing defect or shipping damage.	Contact Tiny Land customer service immediately for assistance (see Section 9).

For issues not listed here, or if the suggested solutions do not resolve the problem, please contact Tiny Land customer support.

8. Specifications

Model: WT0017Brand: Tiny Land

• Product Dimensions: 31 (H) x 28 (L) x 13 (W) inches

Item Weight: Approximately 17.91 pounds
Material: High-quality, sustainable wood
Recommended Age: 36 months - 10 years

Number of Rooms: 6Furniture Pieces: 31

• Certifications: CPSIA Certified

9. WARRANTY AND SUPPORT

9.1 Product Warranty

Tiny Land offers a **2-year quality guarantee** for this dollhouse. This warranty covers manufacturing defects and ensures the product meets our quality standards. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

If you have any questions about the product, require assistance with assembly, or need to make a warranty claim, please contact Tiny Land customer service. You can visit the official Tiny Land Store on Amazon for

more information and contact options:

Visit the Tiny Land Store

Our dedicated support team is available to assist you.

© 2025 Tiny Land. All rights reserved.

Related Documents - WT0017



Tiny Land Dollhouse Assembly Instructions

Comprehensive assembly instructions for the Tiny Land Dollhouse, including parts list, furniture details, and step-by-step building guidance. Features warnings, parental supervision requirements, cleaning instructions, and warranty information.



Tiny Land Serenity Play Kitchen Assembly Guide

Comprehensive assembly guide for the Tiny Land Serenity Play Kitchen, including parts list, step-by-step instructions, and important safety warnings. Learn how to build your child's new play kitchen.



Tiny Land Iconic Aqua Kitchen: Assembly Guide & Safety Information

Comprehensive assembly instructions and safety guidelines for the Tiny Land Iconic Aqua Kitchen. Learn how to safely build this engaging play kitchen for children aged 3+, featuring realistic details and encouraging creative role-play.



Tiny Land Wooden Train Set Assembly Instructions and Components

Detailed guide for the Tiny Land Wooden Train Set, including a full component list, assembly diagram description, safety warnings, and contact information for the wooden toy train. Features track pieces, buildings, vehicles, and accessories.



Tiny Land Play Tent Assembly Instructions - Easy Setup Guide

Step-by-step assembly instructions for the Tiny Land Play Tent, including safety warnings, parts list, and clear guidance for setting up your child's play space.





Tiny Land Wooden Train Set 110 Pcs - Assembly Instructions

Detailed assembly instructions for the Tiny Land Wooden Train Set, featuring 110 pieces. Includes a comprehensive parts list and visual examples of track layouts. Designed for children aged 3 and up.