

[Manuals.plus](#) /

› [Tribesigns](#) /

› Tribesigns Modern Console Table HOGA-JW0352 Instruction Manual

Tribesigns HOGA-JW0352

Tribesigns Modern Console Table HOGA-JW0352 Instruction Manual

Model: HOGA-JW0352

INTRODUCTION

Thank you for choosing the Tribesigns Modern Console Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new console table. Please read these instructions carefully before assembly and retain them for future reference.

SAFETY INFORMATION

Important Safety Warnings:

- Do not overload the table. The maximum weight recommendation is 120 lbs.
- Keep away from children to prevent injury from sharp edges.
- Always follow assembly instructions carefully.
- Place the table on a flat, stable surface to prevent tipping.
- Avoid placing hot items directly on the surface without protection.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (Wood)
- Metal Base Frame (Geometric Design)
- Assembly Hardware (Screws, bolts, washers, etc.)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual (this document)

ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface (e.g., a blanket or carpet) to prevent scratches.
2. **Identify Parts:** Refer to the included parts diagram (if available) to identify each component.
3. **Assemble Base:** Attach the various sections of the metal base frame together using the provided hardware. Ensure all connections are secure but do not overtighten screws initially.
4. **Attach Tabletop:** Carefully place the tabletop onto the assembled metal base. Align the pre-drilled holes on the tabletop with the corresponding holes on the base. Secure the tabletop to the base using the appropriate screws.
5. **Final Tightening:** Once all components are assembled, gently tighten all screws and bolts. Do not overtighten to avoid damaging the materials.
6. **Positioning:** Carefully move the assembled console table to its desired location. Ensure it is stable and level.



Image: Fully assembled Tribesigns Modern Console Table, showcasing its rustic brown top and geometric metal base.



Image: A detailed view of the geometric metal base, highlighting its design and construction.

USAGE AND PLACEMENT

The Tribesigns Modern Console Table is designed for indoor use. It can be placed in entryways, living rooms, hallways, or behind sofas to display decorative items, lamps, books, or other personal belongings. Ensure the weight of items placed on the table does not exceed the maximum weight recommendation of 120 lbs.



Image: The console table positioned in an entryway, demonstrating its functional and aesthetic placement.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your console table, follow these care guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the wooden tabletop.
- **Heat Protection:** Use coasters or placemats under hot items to protect the surface from heat damage.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Table is wobbly	Uneven floor or loose connections.	Ensure the table is on a level surface. Check and tighten all assembly screws. Adjust leveling feet if present.
Parts do not fit	Incorrect orientation or manufacturing defect.	Review the assembly instructions to ensure parts are oriented correctly. If still an issue, contact customer support for replacement parts.
Scratches on surface	Abrasion from objects or improper cleaning.	Use furniture polish or touch-up pens for minor scratches. Always use protective pads under items.

SPECIFICATIONS

- Brand:** Tribesigns
- Model Number:** HOGA-JW0352
- Table Design:** Console Table
- Color:** Rustic Brown (Top), Black (Base)
- Material Type:** Wood (Top), Metal (Frame)
- Dimensions (L x W x H):** 39.37 inches x 11.81 inches x 33.88 inches
- Tabletop Thickness:** 1.97 Inches
- Maximum Weight Recommendation:** 120 Pounds
- Indoor/Outdoor Usage:** Indoor



Image: Detailed dimensions of the console table, including length, width, and height measurements.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please refer to the contact information provided at the point of purchase or visit the official Tribesigns store online.

Online Store: [Tribesigns Official Store](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BCQRY1LR>

More documents and user manuals: **<https://manuals.plus/>**