

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Soundstream](#) /

› [Soundstream Smart Refrigerator Coffee Table User Manual - Model CT51-FRIDGE-BK](#)

## Soundstream CT51-FRIDGE-BK

# Soundstream Smart Refrigerator Coffee Table User Manual

Model: CT51-FRIDGE-BK

## INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Soundstream Smart Refrigerator Coffee Table. Please read this manual thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the product is placed on a stable, level surface.
- Do not expose the unit to rain or moisture.
- Keep ventilation openings clear of obstructions.
- Do not operate with a damaged power cord or plug.
- Unplug the unit before cleaning or maintenance.
- Do not allow children to play with the appliance.

## PACKAGE CONTENTS

- Soundstream Smart Refrigerator Coffee Table
- Power Cord
- User Manual

## PRODUCT OVERVIEW

The Soundstream Smart Refrigerator Coffee Table combines a functional coffee table with integrated refrigeration, Bluetooth speakers, wireless charging, and additional power outlets.



Figure 1: Front view of the Soundstream Smart Refrigerator Coffee Table with both refrigerated drawers open, displaying beverages and snacks.

## Key Features:

- **Dual Refrigerated Drawers:** Two independent drawers with adjustable temperature settings. Each drawer has a capacity of 70 Liters.
- **Bluetooth Speaker System:** Integrated speakers for audio streaming.
- **Wireless Charging:** 15W wireless charging pad on the tempered glass top.
- **USB Ports:** Two USB Type-A ports and one USB Type-C port for device charging.
- **110V Outlets:** Two standard 110V AC outlets for powering other devices.
- **Tempered Glass Top:** Durable and scratch-resistant surface with integrated touch controls.
- **RGB Accent Lighting:** Customizable lighting for ambiance.
- **Storage Shelf:** Open shelf for additional storage or decorative items.



Figure 2: Annotated diagram showing the various features and components of the smart refrigerator coffee table, including the tempered glass top, wireless charger, touch controls, RGB accent lighting, USB ports, and the capacity of each drawer.



Figure 3: Rear view of the smart refrigerator coffee table, indicating the location of the 110V outlets, storage shelf, power AC input, and the Bluetooth speaker system.

## SETUP INSTRUCTIONS

- Unpacking:** Carefully remove the unit from its packaging. Retain packaging for future transport if needed.
- Placement:** Place the refrigerator coffee table on a flat, stable surface, ensuring adequate ventilation around the unit. Avoid direct sunlight or heat sources.
- Power Connection:** Connect the power cord to the unit and then to a standard 110V AC wall outlet.
- Initial Cooling:** Allow the unit to stand upright for at least 2 hours before plugging it in. After plugging in, allow the drawers to cool for approximately 2-4 hours before placing items inside.

## OPERATING INSTRUCTIONS

## 1. Refrigerator Drawer Controls

The tempered glass top features capacitive touch controls for managing the refrigerator drawers.




Figure 4: Detailed view of the smart touch controls on the glass surface, illustrating options for temperature, audio, and lighting adjustments.

- Activate Settings:** Double-click the circular icon above the temperature display to activate the settings for the drawers.
- Select Drawer:** Use the left/right arrow icons to select either the left or right drawer for temperature adjustment.
- Adjust Temperature:** Use the '+' and '-' icons to set the desired temperature. The temperature range for Drawer 1 is 37.4°F - 46.4°F (3°C - 8°C) and for Drawer 2 is 42.8°F - 53.6°F (6°C - 12°C).
- ECO Mode:** Press the 'ECO' icon to activate energy-saving mode.

Your browser does not support the video tag.

Video 1: Demonstrates how to adjust the temperature settings for the refrigerator drawers using the touch controls on the glass top.

## 2. Bluetooth Speaker System

- 1. Activate Sound Settings:** Double-click the circular icon below the volume display to activate the settings for the sound system. The Bluetooth connection will initiate.
- 2. Pairing:** On your device, search for "Soundstream Fridge" in your Bluetooth settings and pair.
- 3. Adjust Volume:** Use the '+' and '-' icons to set the desired volume level. The accent lighting will reflect volume adjustments.
- 4. Equalizer/Sound Modes:** Use the equalizer icon to cycle through different sound modes (if available).



Figure 5: The smart refrigerator coffee table with its blue accent lighting activated, indicating the aesthetic feature of the device.

### 3. Wireless Charging

Place your Qi-compatible device on the "Wireless Charger" circle on the tempered glass top. Ensure the device is centered for optimal charging.



## Charging Station

Charge all your devices with the integrated Wireless Charger & Three USB Ports

Includes: 15W Wireless Charger, (2) USB Type-A Ports and (1) USB Type-C Port

Figure 6: A smartphone being charged wirelessly on the integrated charging pad located on the tempered glass surface of the table.

### 4. USB Ports and 110V Outlets

The unit includes two USB Type-A ports, one USB Type-C port, and two 110V AC outlets for charging and powering additional devices.



Figure 7: Side panel of the smart refrigerator coffee table, highlighting the accessible USB ports and 110V power outlets.

## MAINTENANCE AND CARE

- Cleaning:** Unplug the unit before cleaning. Wipe the exterior with a soft, damp cloth. For the glass top, use a glass cleaner. Do not use abrasive cleaners or solvents.
- Drawer Cleaning:** Remove drawers and wash with mild soap and water. Ensure they are completely dry before reinserting.
- Ventilation:** Regularly check and clean the ventilation grilles to ensure proper airflow and efficient cooling.
- Power Cord:** Inspect the power cord periodically for any damage. If damaged, contact customer support for replacement.

## TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Unit does not power on.	No power supply; power cord not properly connected.	Ensure the power cord is securely plugged into both the unit and a working wall outlet. Check the circuit breaker.
Drawers are not cooling.	Temperature setting too high; ventilation blocked; door not closed properly.	Adjust temperature to a lower setting. Ensure adequate space around the unit for ventilation. Check that drawers are fully closed.
Bluetooth speakers not connecting.	Bluetooth not activated; device not in pairing mode.	Double-click the sound icon on the touch panel to activate Bluetooth. Ensure your device's Bluetooth is on and searching for devices.
Wireless charging not working.	Device not Qi-compatible; device not properly aligned; foreign objects on charging pad.	Verify your device supports Qi wireless charging. Reposition the device on the charging pad. Remove any objects between the device and the pad.

## SPECIFICATIONS

Feature	Detail
Brand	Soundstream

Feature	Detail
Model Number	CT51-FRIDGE-BK
Product Dimensions (L x W x H)	51.25 x 27.5 x 18.25 inches
Refrigerator Capacity	70 Liters per drawer (140 Liters total)
Temperature Range (Drawer 1)	37.4°F - 46.4°F (3°C - 8°C)
Temperature Range (Drawer 2)	42.8°F - 53.6°F (6°C - 12°C)
Installation Type	Countertop
Defrost System	Automatic
Wireless Charging	15W Qi-compatible
USB Ports	2x USB Type-A, 1x USB Type-C
AC Outlets	2x 110V
Door Material Type	Stainless Steel
Top Material	Tempered Glass

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Soundstream website. Keep your proof of purchase for warranty claims.

**Contact Information:** Please refer to the manufacturer's website or product packaging for the most up-to-date contact details for customer service.