

Fashionit U Speaker

Fashionit U Speakers Mini Bluetooth Speaker Instruction Manual

Model: U Speaker

Brand: Fashionit

1. INTRODUCTION AND OVERVIEW

The Fashionit U Speakers Mini is a portable wireless Bluetooth speaker designed for active lifestyles, travel, home, or office use. This bundle includes two complementing speakers, offering convenient, portable, and fashionable audio without sacrificing performance or versatility. Each speaker features a magnetic base, built-in microphone, and a remote selfie button.

Despite its miniature size, the U Speakers Mini delivers exceptional, clean stereo sound quality. It supports Bluetooth 5.0 for seamless pairing with most Bluetooth-enabled devices, allowing for surround sound experiences anywhere.

2. WHAT'S IN THE BOX

- 2 x U Speakers Mini Portable Wireless Bluetooth Speakers (Red & Black)
- 1 x Micro USB to USB Charging Cord

3. PRODUCT FEATURES

- **Compact Design:** One of the smallest wireless speakers, weighing 2.46 oz with a 1.4-inch diameter.
- **Exceptional Sound:** Boasts clean stereo sound quality.
- **Bluetooth 5.0:** Supports instant and seamless pairing with most Bluetooth-enabled devices.
- **Magnetic Base:** Each speaker has a durable aluminum shell with a magnetic base for versatile placement.
- **Built-in Microphone:** Enables easy hands-free calling.
- **Remote Selfie Button:** Functions as a remote shutter for wireless selfies.
- **Long Playtime:** Up to 4 hours of playback per speaker on a single charge.

4. SETUP GUIDE

4.1 Initial Charging

Before first use, fully charge your U Speakers Mini. Connect the provided Micro USB to USB charging cord to the charging port on the speaker and a compatible USB power source. The indicator light will show charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the power button located on the bottom of the speaker for approximately 2-3 seconds until you hear an audible prompt and the indicator light illuminates.
- **To Power Off:** Press and hold the power button again for approximately 2-3 seconds until you hear an audible prompt and the indicator light turns off.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

To connect your U Speakers Mini to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (indicator light will be blinking).
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings.
3. Search for available devices and select "U Speaker" from the list.
4. Once connected, the indicator light on the speaker will become solid, and you will hear a confirmation tone.

5.2 Stereo Pairing (for two speakers)

To achieve a true wireless stereo (TWS) experience with two U Speakers Mini:

1. Ensure both speakers are fully charged and powered off.
2. Power on both speakers simultaneously. They will automatically attempt to pair with each other.
3. Once successfully paired together, one speaker will act as the master (left channel) and the other as the slave (right channel). You will hear a confirmation tone.
4. Now, connect your device to the master speaker via Bluetooth as described in section 5.1.

5.3 Audio Playback

- **Play/Pause:** Press the power button once to play or pause audio.
- **Volume Control:** Adjust volume directly from your connected device.
- **Track Navigation:** Use your connected device to skip tracks.

5.4 Hands-Free Calling

When connected to your smartphone, the built-in microphone allows for hands-free calls:

- **Answer Call:** Press the power button once.
- **End Call:** Press the power button once during a call.
- **Reject Call:** Press and hold the power button for 2 seconds.

5.5 Selfie Remote Control

The U Speakers Mini can also function as a remote shutter for your smartphone camera:

1. Ensure the speaker is paired with your smartphone via Bluetooth.
2. Open your smartphone's camera application.
3. Press the power button on the speaker once to trigger the camera shutter.

6. MAGNETIC BASE USAGE

The magnetic base allows you to attach the speaker to any magnetic surface, providing flexible placement options. This is particularly useful for hands-free listening in various environments, such as a kitchen fridge, metal shelving, or even certain vehicle surfaces.



Image: The U Speakers Mini showcasing its magnetic base, allowing it to attach to metallic surfaces for versatile placement.

7. PRODUCT IMAGES



Image: A single U Speakers Mini in black, highlighting its compact, spherical design and speaker grille.



Image: A single U Speakers Mini in red, placed on a wooden surface, emphasizing its sleek metallic finish and small footprint.



Image: A hand holding a U Speakers Mini, demonstrating its miniature size and portability.



Image: Two U Speakers Mini, one red and one black, positioned together to illustrate their stereo pairing capability.

8. PRODUCT VIDEOS

8.1 U Speakers Mini by FashionIt

Video: An official video from FashionIt showcasing the U Speakers Mini, highlighting its features and compact design. This video demonstrates the speaker's portability and ease of use in various settings.

8.2 Decibel Sound Test U Speakers Mini

Video: A decibel sound test of the U Speakers Mini, demonstrating its audio output capabilities. This video provides an auditory representation of the speaker's volume and clarity.

9. SPECIFICATIONS

Model Name	U Speaker
------------	-----------

Speaker Type	Component
Special Feature	Portable, Magnetic Base, Built-in Mic, Selfie Remote
Connectivity Technology	Bluetooth 5.0
Audio Output Mode	Stereo (with pairing)
Speaker Size	1.4 Inches (45.45mm x 33mm)
Battery Capacity	400 mAh
Playback Time	Up to 4 hours
Charging Time	Approx. 2 hours
Material	Aluminum
Item Weight	2.46 oz (70g) per speaker
Color	Red & Black (as per bundle)
Is Waterproof	FALSE

10. MAINTENANCE

- **Cleaning:** Wipe the speakers with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speakers frequently. Charge them regularly, even if not in use for extended periods.

11. TROUBLESHOOTING

- **Speaker not turning on:** Ensure the speaker is fully charged. Connect it to the charging cable and try again.
- **Unable to pair with device:**
 - Make sure the speaker is in pairing mode (blinking indicator light).
 - Ensure Bluetooth is enabled on your device.
 - Move the speaker closer to your device.
 - Forget/remove "U Speaker" from your device's Bluetooth list and try pairing again.
 - Restart both the speaker and your device.
- **No sound or low volume:**
 - Check the volume levels on both the speaker and your connected device.
 - Ensure the speaker is properly paired.
 - If using two speakers, ensure they are correctly stereo paired.
- **Selfie remote not working:**
 - Confirm the speaker is paired with your smartphone.
 - Ensure your camera app is open and active.

12. WARRANTY AND SUPPORT

The Fashionit U Speakers Mini comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and how to claim warranty service, please refer to the warranty card included in your product packaging or visit the official Fashionit website.

For further assistance or technical support, please contact Fashionit customer service through their official website or the contact information provided in your product documentation.