

[Manuals.plus](#) /

> [GTKZW](#) /

> GTKZW 30-inch Induction Cooktop User Manual

GTKZW Induction Cooktop 30 inch

GTKZW 30-inch Induction Cooktop User Manual

Model: Induction Cooktop 30 inch | Brand: GTKZW

1. INTRODUCTION

Thank you for choosing the GTKZW 30-inch Induction Cooktop. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: GTKZW 30-inch Induction Cooktop overview.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- **Electrical Connection:** This cooktop requires hardwiring to a 220-240V electrical supply. Installation should be performed by a qualified electrician in accordance with local electrical codes. Do not use a plug.
- **Compatible Cookware:** Use only induction-ready cookware made of steel, cast iron, enameled iron, or stainless steel with a flat bottom. Non-magnetic materials like aluminum, ceramic, copper, or glass are not compatible. An "E0" code indicates incompatible cookware.
- **Child Safety Lock:** The cooktop is equipped with a child safety lock function to prevent accidental operation.
- **Overheat Protection:** The cooktop features an overheat protection function to prevent damage from excessive temperatures.
- **Residual Heat Indicator:** An "H" warning indicates that the cooktop surface is hot after use. Avoid touching the surface until the indicator disappears.
- **Electromagnetic Radiation:** The ceramic cooktop produces no electromagnetic radiation and is safe for use, including by pregnant women.

HOT WARNING

"H" to remind you that the temperature is too high, do not touch it.



Figure 2: Residual heat indicator ("H") on the cooktop display.

SUITABLE FOR ALL KINDS OF COOKWARES



Figure 3: Illustration of compatible and non-compatible cookware for induction cooktops.

3. PRODUCT FEATURES

- **High Power Output:** 9000W total power with 5 burners, including 2 bridge elements, for rapid heating and efficient cooking.
- **LED Sensor Touch Control:** Intuitive touch controls for easy operation.
- **9 Power Levels (P1-P9):** Precise temperature control from boiling to simmering.
- **Bridge Heating Elements:** Two bridge zones accommodate larger or rectangular cookware, ideal for grilling fish or steak.
- **Safety Functions:** Child safety lock, 99-minute timer, residual heat indicator, and overheat protection.
- **Built-in Design:** Space-saving design for a sleek kitchen aesthetic.
- **Durable Surface:** Black ceramic glass surface is durable, high-temperature resistant, and easy to clean.



Figure 4: Key features of the GTKZW 9000W Built-in Electric Cooktop.

4. SETUP AND INSTALLATION

The GTKZW Induction Cooktop is designed for built-in installation. Ensure proper ventilation and electrical connections are made by a certified professional.

4.1 Dimensions and Cutout

The product dimensions are approximately 30 x 20 x 3 inches (76.2 x 50.8 x 7.6 cm). Refer to the diagram below for precise cutout dimensions for built-in installation.

BUILT-IN SIZE & EASY TO INSTALL



Figure 5: Built-in dimensions and installation guide.

4.2 Electrical Connection

This appliance requires a 220-240V hardwired connection. It does not come with a plug. Consult a qualified electrician for safe and compliant installation.



Figure 6: Electrical wiring diagram for hardwired installation.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The cooktop features an LED sensor touch control panel for intuitive operation. The main controls include power on/off, individual burner selection, power level adjustment (+/-), timer, and child lock.

LED TOUCH SCREEN



Figure 7: Detailed view of the LED touch screen control panel.

5.2 Power Level Adjustment

The cooktop offers 9 power levels (P1-P9) for precise heat control. Simply select the desired burner and adjust the power using the touch slider or +/- buttons.

9 POWER LEVELS & TEMPERATURE SETTINGS



Figure 8: Visual representation of 9 power levels for various cooking needs.

5.3 Using Bridge Zones

The two bridge elements can be combined to create a larger cooking surface, perfect for oversized pots, griddles, or rectangular pans. This feature allows for versatile cooking options like grilling a whole fish or multiple items simultaneously.

5.4 Timer Function

Set a cooking timer for up to 99 minutes. The cooktop will automatically turn off the selected burner(s) once the timer expires.

5.5 Child Lock Function

Activate the child lock to prevent accidental changes to settings or unintended operation, enhancing kitchen safety.

Your browser does not support the video tag.

Video 1: Demonstration of the GTKZW 30-inch Induction Cooktop's features, including touch controls, power levels, and cooking versatility.

6. MAINTENANCE AND CLEANING

The black ceramic glass surface is designed for easy cleaning. For best results, clean the cooktop after each use once it has cooled down.

- Wipe the surface with a soft cloth and mild detergent.
- For stubborn stains, use a ceramic cooktop cleaner.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals that can scratch or damage the surface.
- Ensure the cooktop is completely dry before next use.



EASY TO CLEAN

High quality glass surface, just wipe it with a cleaning cloth.

Figure 9: Cleaning the ceramic glass surface with a soft cloth.

7. TROUBLESHOOTING

If you encounter issues with your cooktop, refer to the following common problems and solutions:

Problem/Error Code	Possible Cause	Solution
"E0" code appears	Incompatible cookware or no cookware detected.	Ensure you are using induction-ready cookware. Replace with a suitable magnetic pot or pan.
Cooktop not turning on	No power supply, child lock activated, or incorrect operation.	Check electrical connection. Deactivate child lock. Refer to operating instructions for proper startup.
Burner not heating	Cookware not centered, too small, or not induction-compatible.	Center cookware on the burner. Use appropriate size and type of cookware.
"H" indicator remains on	Residual heat on the cooktop surface.	This is normal. The surface is still hot. Do not touch until the indicator disappears.

For issues not listed here, please contact customer support.

8. SPECIFICATIONS

Attribute	Value
Brand	GTKZW
Model	Induction Cooktop 30 inch
Item Weight	37.2 pounds
Product Dimensions	30 x 20 x 3 inches
Installation Type	Built-in
Burner Type	Induction
Heating Elements	5 (including 2 bridge zones)
Color	Black
Control Console	LED Sensor Touch Control
Voltage	220-240 Volts
Wattage	9000 watts
Fuel Type	Electric
Compatible Cookware	Magnetic Cookware (steel, cast iron, enameled iron, stainless steel)
Material Type	Ceramic Glass
Certification	Energy Star

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact GTKZW customer service directly. Keep your purchase receipt as proof of purchase.

GTKZW Customer Service: Please refer to the contact information provided in your product packaging or on the official GTKZW website.

