

[manuals.plus](#) /

› [JCLOUD](#) /

› [JCLOUD Smart Scent Air Machine AE-108 User Manual](#)

JCLOUD AE-108

JCLOUD Smart Scent Air Machine AE-108 User Manual

Model: AE-108

1. INTRODUCTION

Thank you for choosing the JCLOUD Smart Scent Air Machine AE-108. This waterless essential oil diffuser utilizes advanced Cold-Air Diffusion Technology to disperse fragrance effectively across areas up to 1000 square feet. This manual provides comprehensive instructions for the safe and efficient operation, setup, and maintenance of your device. Please read this manual thoroughly before use and retain it for future reference.

2. PRODUCT OVERVIEW

2.1 Included Components

- JCLOUD Smart Scent Air Machine AE-108
- USB-Cable

2.2 Key Features

- **Cold-Air Diffusion Technology:** Disperses essential oils without heat or water, preserving their therapeutic properties.
- **Waterless Operation:** Eliminates the need for water, simplifying maintenance and preventing mold buildup.
- **Wide Coverage:** Effectively scents areas up to 1000 square feet.
- **100ML Capacity:** Allows for extended operation without frequent refills.
- **Compact Design:** Suitable for various home and office environments.

2.3 Product Diagram



Figure 1: Front view of the JCLOUD Smart Scent Air Machine AE-108. This image shows the sleek black casing with the JCLOUD logo and a rose gold accent on the right side.



Figure 2: The JCLOUD Smart Scent Air Machine AE-108 shown alongside an empty blue essential oil bottle, illustrating the type of container used for fragrance.

3. SETUP

- 1. Unpack the Device:** Carefully remove the scent machine and all accessories from the packaging.
- 2. Locate the Oil Bottle Compartment:** The oil bottle compartment is typically accessed from the top or side of the device. Refer to Figure 3 for the top view showing the oil port.



Figure 3: Top view of the JCLOUD Smart Scent Air Machine AE-108, highlighting the circular opening for the essential oil bottle connection.

3. **Fill the Oil Bottle:** Unscrew the empty essential oil bottle (if provided separately) and fill it with your desired essential oil. Do not overfill. The maximum capacity is 100ML.
4. **Attach the Oil Bottle:** Screw the filled essential oil bottle securely into the nebulizing mechanism within the compartment. Ensure it is tightly sealed to prevent leaks.
5. **Connect Power:** Insert the USB-Cable into the power port on the device. Connect the other end of the USB-Cable to a suitable power adapter (not included) and plug it into a wall outlet. This device operates on corded electric power and does not contain an internal battery. Refer to Figure 4 for the back view showing the power port.



Figure 4: Back view of the JCLOUD Smart Scent Air Machine AE-108, indicating the location of the USB power input port.

6. **Placement:** Place the scent machine on a flat, stable surface in the desired area. Ensure it is away from direct sunlight, heat sources, and out of reach of children and pets.

4. OPERATING INSTRUCTIONS

1. **Power On:** Once connected to power, the device should indicate it is ready for operation (e.g., an indicator light). Press the power button (location may vary, typically on the top or front panel) to turn on the machine.
2. **Adjust Scent Intensity:** The JCLOUD Smart Scent Air Machine AE-108 typically features adjustable intensity settings. Refer to the control panel for options to increase or decrease the diffusion strength. Higher settings will consume more oil.
3. **Timer Function (if available):** Some models include a timer function. Consult your device's specific controls to set desired operating intervals or durations.
4. **Power Off:** Press the power button again to turn off the machine. Disconnect from the power source if the device will not be used for an extended period.

Note: The device operates using Cold-Air Diffusion Technology, which means it does not produce mist or steam. You may not visibly see the diffusion, but the fragrance will be dispersed into the air.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your JCLOUD Smart Scent Air Machine AE-108.

5.1 Cleaning the Device

- **Exterior Cleaning:** Wipe the exterior of the machine with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Nebulizer Cleaning:** If you notice a decrease in scent output or plan to switch essential oils, clean the nebulizer. Remove the essential oil bottle. Fill a clean, empty bottle with rubbing alcohol and attach it to the nebulizer. Run the machine for 15-30 minutes to clear any residue. Then, reattach your essential oil bottle.

5.2 Essential Oil Replacement

When the essential oil bottle is empty, replace it by following the steps outlined in Section 3. Ensure the device is powered off and unplugged before replacing the oil bottle.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No scent output	<ul style="list-style-type: none">• Essential oil bottle is empty.• Nebulizer is clogged.• Device is not powered on.	<ul style="list-style-type: none">• Refill or replace the essential oil bottle.• Clean the nebulizer as described in Section 5.1.• Ensure the device is plugged in and powered on.
Device not turning on	<ul style="list-style-type: none">• Power cable not connected properly.• Power outlet is not functioning.	<ul style="list-style-type: none">• Check the USB-Cable connection to the device and power adapter.• Test the power outlet with another appliance.
Leaking oil	<ul style="list-style-type: none">• Essential oil bottle not screwed in tightly.• Bottle is damaged.	<ul style="list-style-type: none">• Ensure the essential oil bottle is securely tightened.• Replace the essential oil bottle if damaged.

If the problem persists after attempting these solutions, please contact JCLOUD customer support.

7. SPECIFICATIONS

Model Name	AE-108
Brand	JCLOUD
Colour	Black
Material	Plastic
Power Source	Corded Electric
Wattage	10 Watts
Capacity	100 Milliliters (Oil Bottle)

Coverage Area	Up to 1000 Square Feet
Item Weight	812 g
Item Dimensions (LxWxH)	14.7 x 5.8 x 16 Centimeters
Special Feature	Cold-Air Diffusion Technology

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official JCLOUD website. If you encounter any issues not covered in this manual, please contact JCLOUD customer service for assistance.

Contact Information: Please refer to your purchase receipt or the JCLOUD official website for the most current customer support contact details.

© 2023 JCLOUD. All rights reserved.

Related Documents - AE-108

	<p>JCLOUD Smart Scent Air Machine Pro 800ML User Guide</p> <p>User guide for the JCLOUD Smart Scent Air Machine Pro 800ML (Item Model: A6), detailing APP operation, Bluetooth connection, scheduling, password changes, and factory reset procedures.</p>
	<p>JCLOUD Smart Scent Air Machine 300ML User Guide</p> <p>Comprehensive user guide for the JCLOUD Smart Scent Air Machine 300ML (Model P300), detailing app operation, HVAC integration, troubleshooting, and maintenance procedures for optimal performance.</p>
	<p>JCLOUD Smart Scent Air Machine Pro User Guide</p> <p>User guide for the JCLOUD Smart Scent Air Machine Pro (Model ND500), detailing APP operation, Bluetooth connection, schedule personalization, password changes, and factory reset procedures.</p>