

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jazmm](#) /

› [AM FM Walkman Radio:900mAh Rechargeable Portable Transistor Pocket Radio with Best Reception Digital Tuning, LCD Screen,Stereo Earphone Jack, Sleep Timer and Alarm Clock for Jogging,Walking Grey](#)

Jazmm 898

Jazmm AM/FM Walkman Radio User Manual

Model: 898

INTRODUCTION

Thank you for purchasing the Jazmm AM/FM Walkman Radio. This portable transistor radio is designed for excellent reception and clear sound, featuring digital tuning, an LCD screen, a stereo earphone jack, sleep timer, and alarm clock functions. Its compact size and rechargeable battery make it ideal for various activities such as jogging, walking, or simply enjoying your favorite stations on the go. Please read this manual carefully to ensure proper operation and maintenance of your device.



Image: Front view of the Jazmm AM/FM Walkman Radio in grey, showing the digital display and included stereo earphones.

PRODUCT OVERVIEW

Components

- **Portable Radio Unit:** The main device with digital display, controls, and speaker.
- **USB Charging Cable:** For recharging the built-in 900mAh battery.
- **Owner's Manual:** This instruction guide.
- **Wrist Strap:** For convenient carrying.

3.5mm Earphone Jack

Listen quietly without being disturbed by the outside world



Image: The compact size of the radio, measuring approximately 4.14 inches in height, 2.29 inches in width, and 0.7 inches in thickness, with an attached wrist strap.

SETUP

Initial Charge

Before first use, fully charge the radio's built-in 900mAh rechargeable battery. Connect the provided USB charging cable to the radio's charging port and a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging indicator on the LCD screen will show the charging status. A full charge typically takes 2-3 hours and provides 6-18 hours of usage depending on volume and earphone use.

900mAH Rechargeable Battery

- Charging with Type-C
- Charging Time: **2-3h**
- Using Time: **6-18h**



Image: The radio connected to a power outlet via a USB-C cable for charging, illustrating the charging process.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Long press the **SLEEP** button located on the side of the radio. The LCD screen will illuminate.
- **To Power Off (Complete Shutdown):** Long press the **SLEEP** button again. This will turn off the radio completely and reset any temporary settings.
- **To Power Off (Standby Mode):** Short press the **SLEEP** button. The radio will stop playing, but the clock display will remain active.

Your browser does not support the video tag.

Video: A demonstration of the radio's features and basic operation, including power on/off and general functionality.

Tuning and Band Selection

- **Band Selection:** Press the **BAND** button to switch between AM and FM frequencies.
- **Manual Tuning:** Use the **TUNING** arrow buttons (< and >) to manually adjust the frequency.
- **Auto Search:** Long press the **MEM/SCAN** button to automatically search for available stations. The radio will scan and stop on the next strong signal.

Excellent AM FM Reception

Built-in DSP chip is not afraid of signal reception



Image: The radio with its extended antenna, illustrating its capability to receive various radio signals for news, music, and weather.

Your browser does not support the video tag.

Video: A step-by-step guide on how to play AM/FM radio, including turning on the device, switching bands, and tuning to stations.

Volume Control

Adjust the volume using the **VOLUME +** and **VOLUME -** buttons located on the side of the radio.

Multifunctional Rechargeable AM FM Radio



Image: The radio highlighting its high-quality speaker, designed for clear and loud audio output.

Preset Stations

The radio can store up to 20 preset stations. To auto-search and save stations, long press the **MEM/SCAN** button. The radio will automatically scan and save stations to memory. To manually save a station, tune to your desired frequency, then short press the **MEM/SCAN** button. Use the **M-/M+** buttons to select a preset number, then short press **MEM/SCAN** again to confirm. To recall a preset station, use the **M-/M+** buttons.

Auto Scan 20 Preset Stations



Auto Scan



Memory 20 Preset



Digital Frequency



Image: The radio's display showing options for auto scan, memory for 20 presets, and digital frequency tuning.

Clock and Alarm Clock Settings

The radio features a digital clock and an alarm clock function.

- **Setting the Clock:** In clock mode, long press **TIME/AL**. Use **TUNING** buttons to adjust 12/24 hour system and time. Press **TIME/AL** to confirm hour, then adjust minute with **TUNING** buttons and confirm with **TIME/AL**.
- **Setting the Alarm Clock:** Short press **TIME/AL** on the clock interface. The alarm clock icon will flash. Long

press **TIME/AL** to set the alarm time. Use **TUNING** buttons to adjust the time and **TIME/AL** to confirm.

- **Closing the Alarm Ring:** When the alarm is ringing, press **TUNING** to enter snooze mode (snooze icon flashes). The alarm will ring again after 5 minutes. To completely turn off the alarm, press any button except **TIME/AL** or **TUNING**.

Your browser does not support the video tag.

Video: Instructions on how to set the clock and alarm clock functions on the radio.

Sleep Timer

The sleep timer allows you to set the radio to automatically turn off after a specified period (15-90 minutes). In radio mode, long press the **SLEEP** button. Use the **TUNING** buttons to adjust the power-off time. Press **SLEEP** again to confirm the setting.

Lock Function

To prevent accidental button presses, use the lock function. Long press the **LOCK/ST** button. The display will show a lock icon, and other buttons will be unresponsive. Long press **LOCK/ST** again to unlock the radio.

Earphone Use

For private listening, plug any standard 3.5mm earphones into the earphone jack located on the top of the radio. The radio's speaker will automatically mute when earphones are connected.

High Quality Speaker

More clearly and louder to listen to music



Image: A close-up of the radio's 3.5mm earphone jack, demonstrating how to connect headphones for quiet listening.

MAINTENANCE

- Clean the radio with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from water, moisture, and extreme temperatures.

- Avoid dropping the radio or subjecting it to strong impacts.
- When not in use for extended periods, store the radio in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the radio fully.
Poor reception/Static	Weak signal; antenna not extended.	Extend the telescopic antenna fully. Try moving to a different location.
Buttons unresponsive	Lock function is active.	Long press the LOCK/ST button to unlock.
Alarm not sounding	Alarm not set or turned off.	Verify alarm settings and ensure it is activated.

SPECIFICATIONS

- **Model Number:** 898
- **Brand:** Jazmm
- **Product Dimensions:** 2 x 0.7 x 4 inches
- **Item Weight:** 3.17 ounces
- **Battery:** 900mAh Lithium Ion (Rechargeable, included)
- **Frequency Range:** AM/FM (Specific ranges not provided in input, but generally standard for portable radios)
- **Display:** LCD
- **Connectivity:** USB (for charging), 3.5mm Earphone Jack
- **Special Features:** Digital Tuning, Sleep Timer, Alarm Clock, 20 Preset Stations, Lock Function
- **Manufacturer:** Jimeng
- **Country of Origin:** China
- **Date First Available:** September 2, 2022

WARRANTY AND SUPPORT

Jazmm offers a 12-month warranty on this AM/FM radio. For any product-related inquiries, technical support, or warranty claims, please contact our customer service team. We provide 24/7 world-class customer service to assist you.

For further assistance, please refer to the official Jazmm store or contact the seller directly through the platform where the product was purchased.

