

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Carrera](#) /
- › [Carrera Vertical LCD Aluminum Radiant Panel Heater 2000W User Manual](#)

## Carrera Vertical LCD Aluminum 2000W

# Carrera Vertical LCD Aluminum Radiant Panel Heater 2000W User Manual

Model: Vertical LCD Aluminum 2000W

[Introduction](#)   [Safety Information](#)   [Product Overview](#)   [Setup & Installation](#)   [Operating Instructions](#)  
[Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

---

Thank you for choosing the Carrera Vertical LCD Aluminum Radiant Panel Heater 2000W. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new heater. Please read all instructions carefully before use and retain this manual for future reference.

## 2. IMPORTANT SAFETY INFORMATION

---

**WARNING:** To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this heater.
- Do not use this heater outdoors.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This product is compliant with CE and NF standards.

### 3. PRODUCT OVERVIEW

---

The Carrera Vertical LCD Aluminum Radiant Panel Heater 2000W is designed for efficient and rapid heating. Its vertical and curved format, combined with an aluminum heating core, ensures quick temperature rise and even heat distribution.

- **Power:** 2000W for effective heating.
- **Heating Core:** Aluminum radiant panels for rapid heat-up.
- **Design:** Vertical and curved format, suitable for various room layouts.
- **Thermostat:** Electronic thermostat with digital display for precise temperature control.
- **Technology:** Thermal Redistribution Technology (TRT) for optimized heat spread.
- **Installation:** Easy H-shaped wall mount support.



*Image 3.1: The Carrera Vertical LCD Aluminum Radiant Panel Heater shown installed in a dining room setting, with an inset image highlighting its digital control panel.*



*Image 3.2: A detailed view of the heater's perforated front surface, showcasing its modern design.*

## 4. SETUP & INSTALLATION

---

This radiant panel heater is designed for wall mounting. Ensure the installation location is suitable and adheres to all local electrical and safety codes.

### 4.1 Wall Mounting

1. **Choose Location:** Select a wall location that is clear of obstructions and combustible materials. Ensure there is adequate space around the heater as per safety guidelines (at least 1 meter from combustible materials).
2. **Prepare Wall:** Mark the drilling points for the H-shaped wall mount support. Use a level to ensure the mount is straight.
3. **Install Mount:** Drill holes and securely attach the H-shaped wall mount bracket to the wall using

appropriate screws and wall plugs (not supplied, ensure they are suitable for your wall type and the heater's weight).

4. **Mount Heater:** Carefully lift the heater and hook it onto the installed wall mount support. Ensure it is securely seated and stable.
5. **Connect Power:** Plug the heater into a suitable electrical outlet. Ensure the outlet is properly grounded and rated for 2000W.



*Image 4.1: The Carrera Vertical LCD Aluminum Radiant Panel Heater shown mounted on a wall, illustrating its vertical design.*

## 5. OPERATING INSTRUCTIONS

---

Your Carrera heater features an electronic thermostat with a digital display for easy and precise control.

### 5.1 Initial Power On

1. Ensure the heater is securely mounted and plugged into a power outlet.
2. Press the Power button ( ) on the control panel. The LCD display will illuminate.

### 5.2 Setting the Temperature

1. Once powered on, the display will show the current room temperature or the last set temperature.
2. Use the Up (▲) and Down (▼) arrow buttons to adjust the desired temperature.
3. The heater will automatically turn on or off to maintain the set temperature.

### 5.3 Mode Selection (if applicable)

Some models may offer different heating modes (e.g., Comfort, Eco, Frost Protection). Refer to the specific icons on your digital display and use the Mode button (often represented by an 'M' or a sun/moon icon) to cycle through available modes.

## 5.4 Turning Off the Heater

Press the Power button ( ) again to turn off the heater. The display may show a standby indicator or turn off completely.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and efficient operation of your heater.

### 6.1 Cleaning

1. **Disconnect Power:** Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
3. **Dust Removal:** Use a soft brush or vacuum cleaner with a brush attachment to remove dust from the air inlets and outlets.
4. **Do Not Immerse:** Never immerse the heater in water or any other liquid.

### 6.2 Storage

If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

## 7. TROUBLESHOOTING

---

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Power button not pressed.	Check if the heater is properly plugged into a working outlet. Press the Power button.
Heater is on but not heating.	Temperature setting is too low. Overheat protection activated.	Increase the desired temperature setting. Unplug the heater, let it cool for 30 minutes, then plug it back in. Ensure air inlets/outlets are not blocked.
Digital display is not working.	Power issue. Internal malfunction.	Check power supply. If problem persists, contact customer support.

Problem	Possible Cause	Solution
Unusual noises or odors.	Dust accumulation. Internal component issue.	Unplug and clean the heater thoroughly. If noises/odors persist or are strong, discontinue use and contact customer support.

## 8. PRODUCT SPECIFICATIONS

---

<b>Brand</b>	Carrera
<b>Model</b>	Vertical LCD Aluminum 2000W
<b>Power Output</b>	2000W
<b>Heating Method</b>	Radiant (Aluminum Core)
<b>Dimensions (D x W x H)</b>	12.5P x 45l x 90H centimeters (approx. 90 x 45 x 90 cm)
<b>Weight</b>	7 Kilograms
<b>Special Feature</b>	Electronic Thermostat with Digital Display, Thermal Redistribution Technology (TRT)
<b>Mounting Type</b>	Wall Mount (H-shaped support)
<b>Compliance</b>	CE and NF standards

## 9. WARRANTY & CUSTOMER SUPPORT

---

Specific warranty information for this product is not available in the provided details. Please refer to the warranty card included with your purchase or contact the retailer for details regarding warranty coverage. For technical assistance, spare parts, or any questions not covered in this manual, please contact Carrera customer support through their official website or the contact information provided with your product packaging.

*Note: Information regarding the availability of spare parts is not available.*