Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VORDRASSIL D343840

VORDRASSIL Electric Gua Sha Massager

USER MANUAL

Introduction

The VORDRASSIL Electric Gua Sha Massager is a versatile beauty instrument designed for facial and body sculpting, anti-aging, and muscle relaxation. It combines traditional Gua Sha techniques with modern electric functions, offering multiple modes for various therapeutic and cosmetic benefits. This manual provides essential information on product components, safety guidelines, operation, maintenance, and specifications to ensure optimal use and longevity of your device.

Safety Information

Please read all safety instructions carefully before using the device. Failure to follow these guidelines may result in injury or damage to the product.

- **General Precautions:** Avoid use on damaged skin.
- Do not use while sleeping.
- Stop use immediately if any discomfort is experienced.
- Keep out of reach of children.
- Do not immerse the device in water or other liquids.
- Use only the provided USB cable for charging.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

Product Overview

Package Contents

Upon opening your VORDRASSIL Electric Gua Sha Massager package, you should find the following items:

- 1 x Electric Scratch Massager (Main Unit)
- 1 x Manually Gua Sha Stone
- 1 x USB Charging Cable

- 1 x User Manual (this document)



Figure 1: Package Contents of the Electric Gua Sha Massager.

Product Features

The VORDRASSIL Electric Gua Sha Massager offers a range of features designed to enhance your skincare and relaxation routine:

- **Scratch Massage Function:** Applies negative pressure and heat to promote muscle relaxation and alleviate tension.
- **Ergonomic Radian Design:** Contours to the skin for effective massage, relieving muscle stiffness and back pain.
- **Compact and Portable:** Small and lightweight, suitable for use anywhere.
- **Multi-functional Application:** Suitable for various body parts including back, stomach, shoulders, and legs.
- **Skin Firming:** Enhances absorption of skincare creams and improves massage efficacy.
- **Microcurrent Technology:** Balances biological currents, promoting smooth and tender skin.
- **Lifting and Squeezing Action:** Improves blood flow and accelerates cell movement for nourished skin.

- **Four Operating Modes:** Customizable settings for different needs.
- **USB Rechargeable:** Convenient charging with a built-in lithium battery.



Figure 2: Key Features of the Electric Gua Sha Massager.

Setup

Charging the Device

Before first use, or when the battery is low, charge the Electric Gua Sha Massager using the provided USB cable.

1. Connect the small end of the USB cable to the charging port on the device.
2. Connect the larger end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
3. The indicator light on the device will show charging status (refer to device specific light behavior for full charge indication).
4. A full charge takes approximately 90 minutes and provides up to 4 hours of usage.



Figure 3: Electric Gua Sha Massager and Charging Cable.

Operating Instructions

Basic Usage Steps

Follow these steps for effective use of the Electric Gua Sha Massager:

1. **Prepare Skin:** Take the appropriate amount of your preferred skincare product (e.g., cream, serum, essential oil) and place it in your hands.
2. **Apply Product:** Apply the skincare product evenly to the area of your face or body you intend to massage. This ensures smooth gliding of the device and enhances product absorption.
3. **Select Mode:** Turn on the device and choose the desired operating mode based on your needs. The device features 4 distinct modes.
4. **Massage:** Gently drag the device upwards from the bottom of the target area. Maintain consistent pressure and movement.




Figure 4: Applying Skincare Products with the Massager.

Understanding the 4 Modes

The device offers four modes to cater to different massage and skincare requirements. Refer to your device's specific indicator lights or display for mode selection.

- **Mode 1 (Gentle):** Ideal for sensitive skin or initial use, providing a mild massage.
- **Mode 2 (Standard):** Suitable for daily skincare routines, promoting absorption and gentle sculpting.
- **Mode 3 (Intense):** For deeper massage and targeting specific areas with more pronounced tension or for advanced sculpting.
- **Mode 4 (Heat/Vibration Combination):** Combines warmth and vibration for enhanced muscle relaxation and improved circulation.

Application Areas and Benefits

The Electric Gua Sha Massager can be used on various parts of the face and body to achieve specific benefits:

- **Face:**
    - Lighten fine lines and reshape the V-face contour.
    - Reduce contour and improve three-dimensional feeling.

- Tighten eye circumference, eliminate dark circles, and reduce under-eye puffiness.
- Increase skincare product penetration.

- **Body:**
  - **Back & Shoulders:** Relieve tough muscles and back pain, promote warm physical therapy.
  - **Stomach & Legs:** Aid in general massage and relaxation.
  - **Hands:** Relieve hand pain and tightness after training (acupuncture physiotherapy).
  - **Acupoint Massage:** Can be used for targeted acupoint stimulation to relieve various discomforts (e.g., Tianzhu point for shoulder/neck pain, Dazhui point for shoulder/neck discomfort, Sea Point for fatigue, Xi acupoint for cold hands/feet, Fenglong point for headache/dizziness).



Figure 5: Facial Benefits of the Massager.




Figure 6: Diverse Applications of the Massager.



Figure 7: Acupoint Massage Guide.

Maintenance

Proper care and maintenance will extend the life of your VORDRASSIL Electric Gua Sha Massager.

- **Cleaning:** After each use, wipe the device surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the device in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it in its original packaging or a protective pouch when not in use.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

Troubleshooting

If you encounter any issues with your VORDRASSIL Electric Gua Sha Massager, please refer to the following common solutions:

- **Device Not Turning On:**
  - Ensure the device is fully charged. Connect it to the USB cable and allow it to charge for at least 90 minutes.
  - Press and hold the power button for a few seconds to ensure it's not just a quick press.
- **Weak Vibration/Heat:**
  - Check battery level and recharge if necessary.
  - Ensure proper contact with the skin.
  - Verify that the correct mode is selected.
- **Device Malfunction or Unusual Behavior:**
  - Discontinue use immediately.
  - Contact customer support for further assistance. Do not attempt to repair the device yourself.

Specifications

Item Type	Electric Scratch Massager
Brand	VORDRASSIL
Model Number	D343840
Material	ABS Plastic
Power	5 W
Power Supply	USB Cable
Battery Type	Lithium Battery (Built-in)
Battery Capacity	500mAh
Modes	4 Modes
Dimensions (Approx.)	9 cm x 9 cm / 3.54 inches x 3.54 inches
Product Dimensions	3.74 x 3.74 x 0.83 inches
Item Weight	0.2 Kilograms / 7.16 ounces
UPC	780854311575
Manufacturer	Dongguan Define Beauty Electronic Technology Co. Ltd.

Warranty and Support

VORDRASSIL is committed to customer satisfaction and ensures stringent manufacturing and quality standards for its products.

- **Satisfaction Guarantee:** If any product received has a problem, please contact us immediately.
- **Return Policy:** The product is eligible for a refund or replacement within 30 days of receipt.
- **Customer Service:** For product support, troubleshooting, or warranty claims, please contact VORDRASSIL customer service through the platform where the product was purchased or visit the official VORDRASSIL store page on Amazon: VORDRASSIL Store.

© 2024 VORDRASSIL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BCY3KKPW

More documents and user manuals: **https://manuals.plus/**