

BRIO 36003

BRIO World 36003 Turbo Train Instruction Manual

Model: 36003 | Brand: BRIO

1. INTRODUCTION

This manual provides essential information for the safe and proper operation of your BRIO World 36003 Turbo Train. Designed for children aged 3 and up, this battery-operated toy train offers a dynamic play experience with its speed boost function and interactive light indicators. It is crafted from durable plastics to meet BRIO's high standards, ensuring long-lasting play and seamless integration with any existing BRIO World train set.



Figure 1: BRIO World 36003 Turbo Train in its packaging.

2. PACKAGE CONTENTS

The BRIO World 36003 Turbo Train package includes the following items:

- 1x Turbo Train Engine
- 1x Passenger Carriage

- 1x Train Figure

3 PIECES



Figure 2: The three main components of the Turbo Train set: engine, carriage, and figure.

3. SETUP

3.1 Battery Installation

The Turbo Train requires 2 AA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the underside of the train engine.
2. Using a small Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

3.2 Connecting the Train Cars

The Turbo Train engine and passenger carriage connect using magnetic couplers. Simply bring the magnetic ends of the train cars together to form a connection.



Figure 3: The Turbo Train engine and passenger carriage connected, with the figure placed inside.

4. OPERATING INSTRUCTIONS

4.1 Basic Movement

The Turbo Train features a control button on its top surface for basic movement:

- **Forward:** Press the forward button once to start the train moving forward at a standard speed.
- **Stop:** Press the stop button (usually the middle button) once to halt the train.
- **Reverse:** Press the reverse button once to make the train move backward.



Figure 4: Pressing the forward button to initiate movement. The white lights indicate standard operation.

4.2 Dynamic Speed Boost

Activate the dynamic speed boost for an exhilarating burst of speed:

- **Turbo Button:** Press the large turbo button (often marked with a lightning bolt or similar symbol) on the top of the train.
- **Speed Increase:** The train's speed will double for approximately 5 seconds.
- **Light Indicators:** During the turbo boost, the train's white side lights will change to an engaging blue, providing visual feedback of the activated boost.



Figure 5: Activating the turbo boost, indicated by the blue side lights.

5. MAINTENANCE

- **Cleaning:** Wipe the train and accessories with a damp cloth. Do not immerse in water.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage. Replace all batteries at the same time.
- **Storage:** Store the train and accessories in a dry place away from direct sunlight.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Train does not move or lights do not illuminate.	Batteries are low, incorrectly installed, or not present.	Check battery installation and replace with fresh AA batteries if necessary. Ensure correct polarity.
Train moves slowly or inconsistently.	Low battery power. Obstruction on tracks or wheels.	Replace batteries. Clear any debris from tracks or train wheels.
Turbo boost does not activate or lights do not change color.	Low battery power. Button not pressed correctly.	Replace batteries. Ensure the turbo button is pressed firmly.

7. SPECIFICATIONS

- **Model Number:** 36003 (Internal: 63600300)
- **Brand:** BRIO
- **Product Dimensions:** 7.83 x 3.58 x 2.01 inches
- **Item Weight:** 6.1 ounces
- **Batteries:** 2 AA batteries required (not included)
- **Recommended Age:** 3 years and up
- **Release Date:** March 1, 2023

8. SAFETY INFORMATION

WARNING: Not suitable for children under 3 years due to small parts which may present a choking hazard.

- Always supervise children during play.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Dispose of batteries responsibly.

9. WARRANTY AND SUPPORT

Specific warranty details and direct customer support contact information are not provided in the product data. For inquiries regarding warranty or support, please refer to the official BRIO website or contact your retailer.







10. PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video 1: An official product overview demonstrating the BRIO World 36003 Turbo Train's features and functionality.

© 2023 BRIO. All rights reserved.

Related Documents - 36003

	<p>BRIO Battery-Operated Steaming Train - User Manual and Instructions</p> <p>Comprehensive guide for the BRIO Battery-Operated Steaming Train (model 33884). Learn how to install batteries, operate the train, generate steam, and understand safety precautions. Includes tips for optimal play and maintenance.</p>
	<p>BRIO World Remote Control Travel Train Troubleshooting Guide</p> <p>Provides essential troubleshooting steps for the BRIO World Remote Control Travel Train, helping users resolve issues related to infrared control, channel synchronization, remote operation, and battery performance.</p>
	<p>BRIO Remote Control Train - User Manual and Operating Instructions</p> <p>Comprehensive guide for the BRIO Remote Control Train, covering operation, battery installation, safety precautions, and FCC compliance. Learn how to set up and enjoy your BRIO RC train.</p>
	<p>BRIO Rote Lola 33592: Questions and Answers</p> <p>Find answers to common questions about the BRIO Rote Lola 33592 toy train, including operation, troubleshooting, and battery replacement. This guide provides information on how to use, maintain, and resolve issues with the toy.</p>
	<p>BRIO Central Train Station - Battery Replacement and Operation Guide</p> <p>Instructions and safety information for the BRIO Central Train Station toy, detailing how to replace batteries and operate its sound features. Includes important warnings and guidelines for safe use.</p>
	<p>BRIO Builder Flashlight - Interactive Toy Accessory Guide</p> <p>Learn how to use and care for the BRIO Builder Flashlight, a colorful LED accessory compatible with BRIO Builder tools. Includes battery installation, safety guidelines, and product features.</p>

