Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TJD MT-750

TJD MT-750 7.5-inch Android 12 Tablet User Manual

Model: MT-750

Introduction

This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your TJD MT-750 7.5-inch Android 12 Tablet. Please read this guide thoroughly to ensure proper use and to maximize your device's performance and longevity.

Package Contents

Upon unboxing your TJD MT-750 tablet, please verify that all the following items are included:

- TJD MT-750 7.5-inch Android 12 Tablet
- Quick Start Guide (User Manual)
- Power Adapter (Charger)
- USB Type-C Cable



Image: The TJD MT-750 tablet, along with its quick start guide, power adapter, and USB Type-C charging cable, as found in the product packaging.

Device Overview

Familiarize yourself with the physical components of your TJD MT-750 tablet:

- **Power Button:** Located on the side, used to turn the tablet on/off or wake/sleep the screen.
- **Volume Buttons:** Adjust audio output levels.
- **USB Type-C Port:** For charging and data transfer.
- **Micro SD Card Slot:** Allows for expandable storage up to 512GB.
- **Front Camera:** 2MP camera for video calls and selfies.
- **Rear Camera:** 8MP camera for capturing photos and videos.
- **Dual Speakers:** Provide stereo audio output.



Image: The TJD MT-750 tablet highlighting its 2MP front camera for video calls and 8MP rear camera for photography.

Setup

1. Charging the Tablet

Before first use, fully charge your tablet. Connect the USB Type-C cable to the tablet's charging port and the other end to the provided power adapter. Plug the adapter into a wall outlet. The battery indicator on the screen will show charging status.

2. Powering On/Off

- **To Power On:** Press and hold the Power button until the TJD logo appears on the screen.
- **To Power Off:** Press and hold the Power button until a power menu appears. Select "Power off" and confirm.
- **To Sleep/Wake:** Briefly press the Power button to turn the screen off or on without powering down the device.

3. Initial Configuration

The first time you power on your tablet, you will be guided through a setup wizard:

1. **Language Selection:** Choose your preferred language.
2. **Wi-Fi Connection:** Select your Wi-Fi network and enter the password to connect to the internet.
3. **Google Account:** Sign in with your existing Google account or create a new one. This is necessary to access Google Play Store and other Google services.
4. Follow the on-screen prompts to complete the setup, including setting up screen lock, date, and time.

Operating Instructions

1. Basic Navigation

The TJD MT-750 tablet uses a touch-sensitive screen for navigation:

- **Tap:** To select an item or open an app.
- **Swipe:** To scroll through lists or switch between home screens.
- **Pinch:** To zoom in or out on images and web pages.
- **Long Press:** To access contextual menus or move app icons.

2. Connecting to Wi-Fi

To connect to a Wi-Fi network:

1. Go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list of available networks.
4. Enter the network password if prompted, then tap **Connect**.

3. Bluetooth Pairing

To pair with Bluetooth devices (e.g., headphones, speakers):

1. Go to **Settings** > **Connected devices** > **Bluetooth**.
2. Toggle Bluetooth **On**.
3. Ensure your Bluetooth device is in pairing mode.
4. Select the device from the list of available devices and follow any on-screen prompts to complete pairing.

4. Installing and Managing Applications

Your TJD MT-750 tablet is GMS certified, providing full access to the Google Play Store:

- **To Install Apps:** Open the **Play Store** app, search for your desired application, and tap **Install**.
- **To Uninstall Apps:** Long-press the app icon on the home screen or app drawer, then drag it to the "Uninstall" option, or go to **Settings** > **Apps** > select the app > **Uninstall**.



Image: The TJD MT-750 tablet showcasing the YouTube application, demonstrating its GMS certification and access to Google services.

5. Camera Usage

To use the tablet's cameras:

1. Open the **Camera** app.
2. Tap the shutter button to take a photo.
3. Switch between front (2MP) and rear (8MP) cameras using the camera switch icon.
4. Select video mode to record videos.

6. Storage Management

Your tablet comes with 64GB of internal storage, expandable up to 512GB via a Micro SD card.

- **To Check Storage:** Go to **Settings** > **Storage** to view internal and external storage usage.
- **To Insert Micro SD Card:** Locate the SD card slot on the side of the tablet, gently insert the card until it clicks into place.

7. Battery Management

The 4000 mAh battery provides up to 8 hours of usage. To optimize battery life:

- Reduce screen brightness.
- Turn off Wi-Fi and Bluetooth when not in use.
- Close unused applications running in the background.
- Enable Battery Saver mode in **Settings** > **Battery**.



Image: The TJD MT-750 tablet displaying various applications and estimated battery life for activities such as gaming, video playback, and music.

Maintenance

1. Cleaning Your Tablet

To keep your tablet in optimal condition:

- Use a soft, lint-free cloth to clean the screen and body.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- Do not allow moisture to enter openings.

2. Software Updates

Regularly check for software updates to ensure your tablet has the latest features and security patches:

1. Go to **Settings** > **System** > **System update**.
2. Follow the on-screen instructions to download and install any available updates.

3. Storage Optimization

To maintain smooth performance, manage your tablet's storage:

- Regularly clear app cache: **Settings** > **Apps** > select app > **Storage & cache** > **Clear cache**.
- Uninstall unused applications.
- Transfer large files (photos, videos) to an SD card or cloud storage.

Troubleshooting

Here are solutions to common issues you might encounter:

Tablet Not Turning On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes.
- Perform a forced restart by pressing and holding the Power button for 10-15 seconds.

Wi-Fi Connection Issues

- Check if Wi-Fi is enabled in **Settings**.
- Verify the Wi-Fi password.
- Restart your Wi-Fi router and the tablet.
- Forget the network and reconnect: **Settings** > **Network & internet** > **Wi-Fi** > tap network name > **Forget**.

Slow Performance or Apps Crashing

- Close all background applications.
- Clear app cache (see Storage Optimization section).
- Ensure sufficient free storage space.
- If issues persist, consider a factory reset (**Settings** > **System** > **Reset options** > **Erase all data (factory reset)**). **Warning:** This will erase all data on your tablet. Back up important data first.

Specifications

Feature	Specification
Model Name	TJD MT-750
Operating System	Android 12.0
Processor	Quad-core 64-bit 1.6 GHz

Feature	Specification
RAM	4GB (2GB physical + 2GB virtual)
Internal Storage	64GB
Expandable Storage	Up to 512GB via Micro SD card
Display Size	7.5 inches
Display Resolution	1440 x 1080 IPS
Front Camera	2MP
Rear Camera	8MP
Wi-Fi	IEEE 802.11b/g/n 2.4GHz
Bluetooth	Bluetooth 4.0
Battery	4000 mAh Lithium-ion (up to 8 hours usage)
Charging Port	USB Type-C
Dimensions (L x W x H)	18.5 x 13.5 x 0.8 cm
Weight	330 grams
Special Features	Fast Charging, Stereo Speakers, Expandable Storage

Warranty Information

The TJD MT-750 Android tablet comes with a**24-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.
Please retain your proof of purchase for warranty claims. For any warranty-related inquiries, please contact customer support.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact TJD customer support. We are committed to providing 24/7 service for our products.
For the most up-to-date support information, including contact details and FAQs, please visit the official TJD website or refer to the contact information provided with your purchase.

© 2023 TJD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BCYX849W

More documents and user manuals: **https://manuals.plus/**