

[Manuals.plus](#) /

› [Hansprou](#) /

› Hansprou 12V Professional Dog Grooming Clippers User Manual

Hansprou 12V Motor

Hansprou 12V Professional Dog Grooming Clippers User Manual

Model: 12V Motor Blue

INTRODUCTION

The Hansprou 12V Professional Dog Grooming Clippers are engineered for efficient and comfortable pet grooming, particularly for large dogs with thick coats. This device features a powerful 12V motor, durable titanium alloy and ceramic blades, and a low-noise design, ensuring a smooth and stress-free grooming experience for both you and your pet. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your clippers.



Figure 1: Hansprou 12V Professional Dog Grooming Clippers and included accessories.

SETUP

1. **Unpack Contents:** Carefully remove all items from the packaging. Verify that the clippers, power adapter, 10 guard combs, cleaning brush, and user manual are present.
2. **Inspect Clippers:** Examine the clippers for any signs of damage. Ensure the blades are securely attached and free from debris.
3. **Connect Power:** As these are corded clippers, plug the power adapter into the clippers and then into a standard electrical outlet. The 3-meter long cord provides ample reach.
4. **Attach Guard Comb (Optional):** Select the desired guard comb based on the hair length you wish to achieve. Align the comb with the clipper blade and snap it firmly into place.

Gear 5 Fine Adjustment + 8 Guide Combs

Easily control the fine length change of hair,
and make your pet look more exquisite



Figure 2: Display of the 10 included guard combs and the clipper's 5-level fine adjustment dial.

OPERATING INSTRUCTIONS

1. **Prepare Your Pet:** Before grooming, ensure your pet's fur is clean, dry, and thoroughly brushed to remove any tangles or mats. This prevents blade snagging and ensures an even cut.
2. **Turn On Clippers:** Press the power button to turn on the clippers. The ultra-quiet design (approximately 50db) helps keep pets calm during grooming.
3. **Adjust Blade Length:** The clippers feature a 5-level fine adjustment dial on the blade, allowing for quick length changes from 0.8mm to 2.0mm. Rotate the dial to select the desired cutting length. When using guard combs, the dial setting will affect the final length.
4. **Begin Grooming:** Hold the clippers firmly with the anti-skid texture body. Start grooming in the direction of hair growth, using smooth, even strokes. Avoid pressing too hard against the skin.
5. **Monitor Blade Temperature:** While the ceramic blade helps reduce heat, periodically check the blade temperature to ensure it does not become too hot, especially during extended use. Allow the clippers to cool if necessary.
6. **Turn Off Clippers:** Once grooming is complete, press the power button to turn off the clippers and unplug them from the power source.

Aluminum Alloy Material +Thread Anti-skid Design

anti-skid texture body, comfortable to handle



Figure 3: Demonstrating the use of Hansprou clippers for pet grooming.

MAINTENANCE

1. **Clean Blades After Each Use:** Detach the blades by pushing them forward. Use the included cleaning brush to remove all trapped hair from the blades and the clipper head.
2. **Oil Blades Regularly:** Apply a few drops of clipper oil (not included) to the blades before and after each use. This lubricates the blades, reduces friction and heat, and prolongs their lifespan.
3. **Reattach Blades:** Once cleaned and oiled, reattach the blades securely to the clipper body.
4. **Store Properly:** Store the clippers and all accessories in a clean, dry place, away from direct sunlight and moisture.

3M Long Cord

Plug and use, no need to worry about power



Figure 4: Detachable blades for easy cleaning and maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clippers not turning on	No power supply	Ensure the clippers are securely plugged into a working electrical outlet. Check the power adapter for damage.
Hair pulling or snagging	Dull blades, dirty blades, matted fur	Clean and oil the blades. Ensure your pet's fur is brushed and free of mats before grooming. Consider replacing blades if they are dull.
Blades getting hot	Lack of lubrication, prolonged use	Apply clipper oil to the blades. Take short breaks during grooming to allow the blades to cool down.
Unusual noise or vibration	Loose blades, internal issue	Check if the blades are properly attached. If the issue persists, discontinue use and contact customer support.

SPECIFICATIONS

- **Brand:** Hansprou
- **Model:** 12V Motor
- **Power Source:** Corded Electric
- **Motor:** 12V High-Speed Strong Power Motor
- **Blades:** Titanium Alloy Blade + Ceramic Moving Blade (35-tooth cutter heads)
- **Blade Adjustment:** 5 Levels (0.8mm, 1.1mm, 1.4mm, 1.7mm, 2.0mm)
- **Guard Combs:** 10 included (for various hair lengths)
- **Cord Length:** 3 meters
- **Noise Level:** Approximately 50db
- **Body Material:** Aluminum Alloy Fuselage with Anti-skid Texture
- **Color:** Blue
- **Item Weight:** 0.69 Kilograms (1.52 Pounds)
- **Package Dimensions:** 10 x 7.09 x 2.72 inches

WARRANTY INFORMATION

Please refer to the product packaging or the official Hansprou website for specific warranty details. Typically, products are covered against manufacturing defects for a limited period from the date of purchase. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, concerns, or technical assistance regarding your Hansprou Dog Grooming Clippers, please contact Hansprou customer support. Contact information can usually be found on the product packaging, the official Hansprou website, or through your retailer's support channels.