

[Manuals.plus](#) /

› [AGARO](#) /

› AGARO MC 8012 Full Body Massage Chair User Manual

AGARO MC 8012

AGARO MC 8012 Full Body Massage Chair User Manual

Model: MC 8012

1. INTRODUCTION

Thank you for choosing the AGARO MC 8012 Full Body Massage Chair. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your massage chair. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

To ensure safe operation, please observe the following precautions:

- Always place the massage chair on a flat, stable surface.
- Ensure adequate space around the chair for reclining and movement.
- Keep children and pets away from the chair during operation.
- Do not use the chair if you have any medical conditions that may be aggravated by massage, such as heart disease, pregnancy, or severe osteoporosis. Consult a physician before use.
- Unplug the chair from the power outlet when not in use or before cleaning.
- Do not attempt to repair or disassemble the chair yourself. Contact qualified service personnel.
- Avoid prolonged exposure to direct sunlight or high humidity.

3. PRODUCT COMPONENTS

The AGARO MC 8012 massage chair consists of the main chair unit, a remote controller, and a power cord. Specific components include:

- Main Massage Chair Body
- Remote Controller
- Power Cable
- Leg Rest Assembly

- Armrest with Shortcut Keys and Wireless Charging Pad

4. ASSEMBLY AND INSTALLATION

The AGARO MC 8012 massage chair requires some assembly. It is recommended to seek professional installation to ensure proper setup and functionality. If self-installing, carefully follow the instructions provided in the separate assembly guide or video. Ensure all connections are secure before powering on the chair.

5. CONTROL PANEL AND REMOTE CONTROLLER

Your massage chair can be operated using the wired remote controller and the integrated handrail shortcut keys.

5.1 Remote Controller

The remote controller features an LCD display and various buttons for comprehensive control over massage functions.



Image: Remote Controller with labeled functions.

- **Power On/Off button:** To turn the chair on or off.
- **Automatic function mode button:** Select from various pre-programmed massage modes.
- **Pause button:** Temporarily stop the current massage program.
- **Zero gravity mode selection button:** Activate or adjust the zero gravity positions.
- **Menu selection button:** Navigate through the remote's menu options.
- **Navigation buttons (OK, Up, Down, Left, Right):** For menu navigation and selection.
- **Linkage seating/lying adjustment button:** Adjust the backrest and leg rest simultaneously.
- **Leg rest adjustment button:** Independently adjust the leg rest position.
- **Back rest adjustment button:** Independently adjust the backrest position.

5.2 Handrail Shortcut Keys

The right armrest includes shortcut keys for quick access to frequently used functions:

- On/Off button
- Chair angle adjust button
- Pause button
- Auto mode button
- Voice wake up
- Heating
- Air pressure
- Entire foot lifting
- Zero gravity
- Backrest lifting

6. OPERATING THE MESSAGE CHAIR

6.1 Power On/Off

Press the Power On/Off button on the remote or handrail to start or stop the massage chair.

6.2 Zero Gravity Function

The chair offers 3 levels of zero gravity angles. This scientific design positions your body to release pressure, aligning your heart and knees horizontally to reduce heart pressure and stimulate blood circulation.

AGARO

**Massage Chair
Model : 8012**



- 4D Massage • Zero Gravity
- Air Compression Massage

Image: Zero Gravity positions for optimal relaxation.

Press the Zero Gravity button on the remote or handrail to cycle through the available angles.

Your browser does not support the video tag.

Video: Demonstration of the Zero Gravity recline function.

6.3 Reclining Adjustment

Use the linkage seating/lying adjustment buttons on the remote or the chair angle adjust button on the handrail to adjust the backrest and leg rest simultaneously. Individual adjustment buttons are also available on the remote.

6.4 Automatic Programs

The chair includes 21 automatic massage functions designed for various needs, such as:

- Comfortable Massage
- Relaxing Massage
- Traction Massage
- Shoulder and Neck Massage
- Back and Waist Massage
- Whole Body Massage
- Protection of Vertebral Massage
- Fatigue Recovery
- Stretching Muscles and Activating Collateral
- Beautiful Buttock Shaping
- Soothing Sleep
- Air Compression

Select your desired program using the Automatic function mode button on the remote.

6.5 Manual Massage Techniques

The chair offers 11 massage techniques, including:

- Kneading (Seven modes)
- Tapping (Tapping I, Tapping II)
- Simultaneous Kneading and Tapping
- Shiatsu (Shiatsu I, Shiatsu II)
- Shoulder Lifting
- 3D (3D I, 3D II, 3D III, 3D IV)

These techniques can be selected and adjusted manually via the remote controller.

Your browser does not support the video tag.

Video: Visualizing various massage techniques like kneading and shiatsu tapping.

6.6 SL-Track System

The S-shape massage structures in the backrest are designed according to human body engineering principles, ensuring a close-fitting back massage. The massage width is adjustable from 6 to 21 cm across 3 levels (wide, middle, narrow). The super long "SL" shape curved rail technology provides a massage distance of 135 cm, covering from head to leg, helping to maintain the body's natural "S" shaped curve and relieve tense muscles.

Model	Massage Technique	Manual Massage Techniques	Number of Speed Level	Space Saving	Zero Gravity	Automatic Massage Program	Upper arm airbag massage	Under arm airbag massage	Leg Airbag Massage	Foot Airbag Massage	Shoulder Airbags	Back Heating technology	Spring Loaded Footrest extension	Wireless Phone Charging	USB & Bluetooth
 8012 (BROWN)	4D	11	5	Yes	Yes	21	6	8	6	22	Yes	Yes	Yes	Yes	 Yes  No
 7012 (BROWN)	3D	5	3	Yes	Yes	12	4	8	4	12	Yes	Yes	Yes	No	Yes

Image: SL-Track system illustrating massage coverage from neck to hip.

6.7 Air Compression Massage

The chair features full-body air massage with airbags located in various areas, including the legs. The kneading and airbag compression massage functions on the leg rest help relieve stiffness and tension in leg muscles.

FULL BODY AIR MASSAGE



Kneading



Rolling



Shiatsu



Tapping



Knocking



Tapping/
Kneading




Speed

5 Level
speed



3 Levels
air massage



Lower back
heating

Image: Full body air massage system with airbags.



COMPLETE LEG MASSAGE

FOOT & AIRBAG
COMPRESSION



CALF MASSAGE



LEG AIRBAG
MASSAGE

Image: Complete leg massage features including foot and calf compression.

6.8 Foot Roller Massage

The foot roller function stimulates the soles of the feet, promoting blood circulation and providing a relaxing foot massage.

6.9 Heating Function

The chair includes a lukewarm heat function, particularly in the back area, to enhance relaxation and muscle relief. This feature can be activated via the handrail shortcut key or remote.

Your browser does not support the video tag.

Video: Demonstration of the back heating function.

6.10 Bluetooth Connectivity

Enjoy high-definition music during your massage by connecting your device via Bluetooth to the chair's integrated speakers.

BLUETOOTH SPEAKERS



Wireles Charger

Image: Location of Bluetooth speakers and wireless charger.

6.11 Wireless Charging

The left armrest features a shortcut key for wireless charging. Place your mobile phone on the fixed wireless charging area to charge it while enjoying your massage.

Your browser does not support the video tag.

Video: Demonstration of the wireless charging feature.

6.12 AI Voice Control

The chair supports AI Voice Control for convenient operation. Refer to the specific voice commands in the detailed user guide for activation and usage.

7. CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your massage chair:

- **Cleaning:** Wipe the chair with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the chair in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly check the power cord and plug for any damage. If damaged, discontinue use and contact customer support.

8. TROUBLESHOOTING

If you encounter any issues with your AGARO MC 8012 massage chair, please refer to the following common solutions:

- **Chair does not power on:** Ensure the power cord is securely plugged into both the chair and a working electrical outlet. Check the circuit breaker.
- **Massage function stops unexpectedly:** The chair may have an overheating protection mechanism. Turn off the chair, unplug it, and allow it to cool down for 30-60 minutes before restarting.
- **Remote controller not responding:** Check if the remote's battery needs replacement (if applicable) or if the cable is securely connected.
- **Unusual noises during operation:** Minor operational noises are normal. If you hear loud or unusual grinding/clunking sounds, turn off the chair and contact customer support.

For persistent issues, please contact AGARO customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	AGARO
Model Number	MC 8012 (Item model number: 33864)
Color	Brown
Material	Leather
Product Dimensions (LxWxH)	178 x 74 x 107 cm
Item Weight	119 kg
Back Style	Curved Back
Special Feature	Heat
Frame Material	Metal
Massage Techniques	11 (Kneading, Tapping, Shiatsu, 3D, etc.)
Automatic Programs	21
Zero Gravity Levels	3
Massage Track	SL-Shape Curved Rail (135cm)
Connectivity	Bluetooth Speaker, Wireless Charging
Control	Remote, Handrail Shortcut Key, AI Voice Control

10. WARRANTY AND SUPPORT

The AGARO MC 8012 Full Body Massage Chair comes with a **1 Year Warranty**. For any warranty claims, technical support, or service inquiries, please contact AGARO customer service. Keep your purchase receipt as proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0BD49HZX1>

More documents and user manuals: <https://manuals.plus/>