

[Manuals.plus](#) /

› [KXAITO](#) /

› KXAITO 6092 Sport Watch User Manual

KXAITO 6092

KXAITO 6092 Sport Watch User Manual

Model: 6092

INTRODUCTION

Welcome to the KXAITO 6092 Sport Watch user manual. This guide provides detailed instructions for the proper setup, operation, and maintenance of your new watch. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW

Key Features

- Durable zinc alloy case with stainless steel back.
- Scratch-resistant watch dial.
- Japan imported quartz and electronic movement for precise timekeeping.
- Dual analog and digital time display.
- Functions: Calendar, Alarm, Hourly Chime, Date, Stopwatch.
- LED Backlight for visibility in low light conditions.
- Shock-resistant design.
- 5 ATM (50 meters) water resistance.
- Comfortable and durable polyurethane (TPU) strap.
- 12/24 hour format option.

Package Contents

- 1 x KXAITO 6092 Digital Sport Watch
- 1 x Gift Box
- 1 x User Manual



A front view of the KXAUTO 6092 Sport Watch, showcasing its silver bezel, black resin strap, and dual analog-digital display.



The KXAITO 6092 Sport Watch worn on a wrist, illustrating its size and fit.

WATCH COMPONENTS AND BASIC FUNCTIONS





This diagram identifies the four control buttons: **LIGHT** (top left), **MODE** (bottom left), **START** (top right), and **RESET** (bottom right). It also highlights the digital time display, date display, and 12/24 hour format indicator.

- **LIGHT Button (Top Left):** Activates the LED backlight for the digital display.
- **MODE Button (Bottom Left):** Cycles through different display modes: Time Display, Alarm Setting, Stopwatch, and Date Display.

- **START Button (Top Right):** Used to start/stop functions in stopwatch mode, or to adjust values during setting modes.
- **RESET Button (Bottom Right):** Used to reset functions in stopwatch mode, or to confirm and move to the next setting item during setting modes.

SETUP INSTRUCTIONS

Setting Digital Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the seconds begin to flash, indicating you are in setting mode.
2. Press the **RESET** button to cycle through the setting items: Seconds → Hour → Minute → Month → Date → Day of Week.
3. Use the **START** button to adjust the flashing value for each item.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.

Setting Analog Time

The analog hands are typically synchronized with the digital time or set independently via buttons. For this model, the analog time is set through the digital interface:

1. While in the digital time setting mode (where seconds are flashing), continue pressing the **RESET** button until the analog hour or minute hand starts flashing (if applicable).
2. Use the **START** button to advance the analog hands. Hold the **START** button to move the hands quickly.
3. Once the analog time matches the digital time, press the **MODE** button to exit setting mode.

Setting the Alarm

1. From the normal time display, press the **MODE** button until you reach the Alarm mode (indicated by 'AL' or a bell icon).
2. Press the **RESET** button to select the hour or minute to set. The selected value will flash.
3. Use the **START** button to adjust the flashing hour or minute.
4. Press the **MODE** button to exit Alarm setting mode.
5. To activate/deactivate the alarm, press the **START** button while in Alarm mode. An alarm icon will appear/disappear.

Using the Stopwatch

1. From the normal time display, press the **MODE** button until you reach the Stopwatch mode (indicated by 'ST' or 'CHRONO').
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. Press the **MODE** button to exit Stopwatch mode.

12/24 Hour Format

In the digital time setting mode (where seconds are flashing), press the **START** button when the hour is flashing to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

OPERATING YOUR WATCH

Switching Display Modes

Press the **MODE** button (bottom left) to cycle through the various display modes: normal time, alarm, stopwatch, and date.

Activating the LED Backlight

Press the **LIGHT** button (top left) to illuminate the digital display for a few seconds, allowing for visibility in dark conditions.

CARE AND MAINTENANCE

Water Resistance

Your KXAITO 6092 Sport Watch is water resistant up to 5 ATM (50 meters). This means it is suitable for daily use, resistant to splashes, rain, and brief immersion in water. However, it is not recommended for prolonged underwater activities like diving.

Important: Do not press any buttons while the watch is submerged in water. Avoid exposure to hot water or steam (e.g., hot showers, saunas) as this can damage the waterproof seals and compromise water resistance.

Cleaning

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish or strap material. For the strap, mild soap and water can be used, ensuring it is thoroughly rinsed and dried afterward.


TROUBLESHOOTING

- **Digital display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Time is inaccurate:** Re-set the time following the instructions in the 'Setting Digital Time and Date' section. If the issue persists, the battery may be weak.
- **Water condensation inside the watch:** This indicates a breach in the water resistance. Avoid further water exposure and contact customer support for assistance.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though not a feature of this model). If unresponsive, a battery replacement might resolve the issue.

TECHNICAL SPECIFICATIONS



Total length of watch:
262mm
circumference:
(max)236mm
(min)180mm



Model: KXAUTO Watch Store

Case material: zinc alloy

Style: Sport watch with
double display

Watch strap material: TPU

Watch movement: Original movement
imported from Japan

Weight:80g

Battery: Maxell Japan battery

Thickness: 17mm

Mirror: high hardness tempered mirror

Waterproof: 50 meters waterproof

This diagram illustrates the watch's dimensions and material specifications, including case diameter, total length, strap width, and materials.

Specification	Detail
Brand	KXAUTO
Model Number	6092

Case Diameter	56 mm
Case Thickness	16 mm
Strap Length	260 mm
Strap Adjustment Range	140 mm - 230 mm
Strap Width	22 mm
Movement	Japan Imported Quartz and Electronic Movement
Case Material	Zinc Alloy
Strap Material	Polyurethane (TPU)
Mirror Material	High Hardness Tempered Mirror
Water Resistance	5 ATM (50 meters)
Weight	80 grams

WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your KXAITO 6092 Sport Watch, please contact KXAITO customer service. Refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BD4BJTQ1>

More documents and user manuals: <https://manuals.plus/>