

[Manuals.plus](#) /

› [SUPERJARE](#) /

› SUPERJARE Reversible L-Shaped Computer Desk with Power Socket and File Cabinet User Manual

## SUPERJARE VC7936ZCH

# SUPERJARE Reversible L-Shaped Computer Desk with Power Socket and File Cabinet User Manual

**Brand:** SUPERJARE | **Model:** VC7936ZCH

## 1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your SUPERJARE Reversible L-Shaped Computer Desk (Model VC7936ZCH). Please read this manual thoroughly before assembly and use to ensure proper function and safety.

This desk features a reversible L-shaped design, integrated power sockets and USB ports, a file cabinet, a monitor stand, and storage shelves, designed for home office environments.



*Image 1.1: Overview of the SUPERJARE L-Shaped Computer Desk, showcasing its various features including the monitor stand, power outlets, and file cabinet.*

## Safety Information

- Always follow assembly instructions carefully.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the desk or shelves beyond their intended capacity.
- Keep children and pets away from the assembly area.
- Use caution when handling power cords and electrical outlets. Do not expose to moisture.

## 2. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed in the packaging are present and undamaged. If any parts are missing or damaged, please contact customer support.

The package typically includes:

- Desk panels (L-shaped desktop, monitor stand, shelves, drawer components)
- Metal frame components
- Hardware kit (screws, bolts, cam locks, drawer slides, etc.)
- Integrated power socket with USB ports and power cord
- Assembly tools (e.g., Allen wrench)
- Instruction manual

### 3. SETUP AND ASSEMBLY

Assembly typically requires two people. All parts are clearly marked. A 3D installation video may be available for additional guidance. Using a home drill can expedite the process, but ensure not to overtighten screws.

#### Reversible Design

This desk features a reversible design, allowing the file cabinet and monitor stand sections to be configured on either the left or right side to suit your space requirements. Refer to the specific instructions for your desired orientation.



Image 3.1: The reversible design allows for two installation directions, adapting to various room layouts.

#### Dimensions

Before assembly, ensure you have adequate space for the desk. The overall dimensions are approximately 140 cm (L) x 140 cm (L) x 48 cm (W) x 75 cm (H).



Image 3.2: Detailed dimensions of the desk components, including the monitor stand, desktop sections, and file cabinet.

## Assembly Steps (General Overview)

1. **Unpack and Identify Parts:** Lay out all components and hardware. Match them against the parts list in your instruction manual.
2. **Assemble Frame:** Connect the metal frame components using the provided screws and Allen wrench. Do not fully tighten until all frame pieces are in place.
3. **Attach Desktop Panels:** Secure the main desktop panels to the assembled frame.
4. **Assemble File Cabinet:** Follow the specific instructions for assembling the drawer box and installing the drawer slides. Ensure correct orientation of drawer slides.
5. **Install Drawers:** Insert the assembled drawers into the cabinet.
6. **Attach Monitor Stand and Shelves:** Secure the monitor stand and any additional storage shelves to the desk frame.
7. **Install Power Socket:** Place the integrated power socket into its designated cutout on the desktop.
8. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws and fasteners.

## 4. OPERATING INSTRUCTIONS

### 4.1 Integrated Power Socket and USB Ports

The desk is equipped with an integrated power strip featuring 4 standard AC outlets (125V/12A) and 2 USB ports (5V-2A). This allows for convenient charging and powering of electronic devices directly on your desk, reducing cable clutter.

- Connect the desk's power cord (6.6 feet long) to a wall outlet.
- Plug in your devices (laptops, phones, monitors, etc.) into the available AC outlets or USB ports.
- Ensure devices do not exceed the maximum power rating of the strip.



**4AC Outlets**  
**125V/12A**



**2 USB Ports**  
**5V-2A**



**Power Cord**  
**6.6-Foot**

*Image 4.1: The integrated power socket provides convenient access to power and USB charging for various devices.*

## 4.2 File Cabinet and Storage

The desk includes a two-drawer file cabinet. The top drawer is suitable for stationery and small items, and features a lock for securing contents. The bottom drawer is designed for hanging letter/A4 size file folders.

- **Top Drawer:** Use the provided key to lock and unlock the top drawer.
- **Bottom Drawer:** Utilize the built-in rails for hanging letter or A4 size file folders.
- **Open Shelves:** The desk also features open shelves for additional storage or display of items such as printer paper, books, or decorative objects.

**No Interlock System**



*Image 4.2: The file cabinet's bottom drawer is designed to accommodate hanging letter or A4 size file folders for organized storage.*

### 4.3 Ergonomic Monitor Stand

The integrated monitor stand elevates your display to an optimal viewing height, promoting a correct sitting posture and reducing strain on your neck and spine. It also frees up valuable desktop space underneath.



Image 4.3: The ergonomic monitor stand helps maintain a proper sitting posture, aligning your line of sight with the screen.

## 5. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Electrical Components:** Keep the power socket and USB ports dry and free from dust. Do not attempt to disassemble or repair electrical components.

## 6. TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common problems and solutions:

| Problem                                   | Possible Cause                                                         | Solution                                                                                                                                                                                |
|-------------------------------------------|------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Desk is wobbly or unstable.               | Loose fasteners; uneven floor.                                         | Ensure all screws and bolts are fully tightened. Adjust leveling feet if present, or place shims under legs on uneven surfaces.                                                         |
| Drawers do not slide smoothly.            | Incorrectly installed drawer slides; debris in tracks.                 | Verify drawer slides are installed correctly and aligned. Clean tracks of any dust or obstructions.                                                                                     |
| Power outlets/USB ports not working.      | Desk power cord not plugged in; wall outlet issue; overloaded circuit. | Check if the desk's power cord is securely plugged into a functional wall outlet. Test the wall outlet with another device. Ensure total power draw does not exceed the strip's rating. |
| Missing or damaged parts during assembly. | Packaging error; shipping damage.                                      | Do not proceed with assembly. Contact SUPERJARE customer support immediately for replacement parts.                                                                                     |

## 7. SPECIFICATIONS

- **Brand:** SUPERJARE
- **Model Number:** VC7936ZCH
- **Dimensions (Overall):** Approximately 140 cm (L) x 140 cm (L) x 48 cm (W) x 75 cm (H) (55.1" L x 55.1" L x 18.9" W x 29.8" H)
- **Material:** Engineered wood (P2 chipboard), Powder-coated steel frame
- **Color:** Rustic Brown
- **Special Features:** Reversible L-shape, Built-in power socket (4 AC outlets, 2 USB ports), File cabinet (lockable top drawer, letter/A4 hanging bottom drawer), Monitor stand, Storage shelves
- **Power Socket Output:** 4 AC Outlets (125V/12A), 2 USB Ports (5V-2A)
- **Power Cord Length:** 6.6 feet
- **Certifications:** Meets TSCA and CARB certifications
- **Weight:** Approximately 34.02 kg (75 lbs)

## 8. WARRANTY AND SUPPORT

SUPERJARE products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official SUPERJARE website.

If you require assistance with assembly, have questions about product features, or need to report missing/damaged parts, please contact SUPERJARE customer support. Contact details are typically provided in the original packaging or on the manufacturer's website.

*Please retain your proof of purchase for warranty claims.*

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0BD582TYT>

More documents and user manuals: <https://manuals.plus/>