Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY JY-3G

YING RAY Replacement Remote Control for Ghp Pleasant Hearth Electric Fireplace (Model JY-3G) - Instruction Manual

Model: JY-3G

1. Introduction

This manual provides comprehensive instructions for the YING RAY Replacement Remote Control, model JY-3G. This remote is specifically designed to operate Ghp Pleasant Hearth Electric Fireplaces that originally used the JY-3G remote control.

Important Compatibility Note:

- This remote control is **only compatible** with electric fireplaces that use the **JY-3G** remote control model.
- It is **not compatible** with models JY-3A or JY-3B.
- Please verify your existing remote control model is JY-3G before use.





Image 1: YING RAY JY-3G Replacement Remote Control. This image displays the front view of the black remote control with its various function buttons.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside

the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

2.2 Initial Use

This replacement remote control is designed to function immediately with compatible JY-3G electric fireplaces. No complex pairing or programming is typically required. Simply point the remote towards your fireplace and press the desired function button.

3. Operating Instructions

Familiarize yourself with the buttons on your JY-3G remote control. Each button controls a specific function of your electric fireplace.




Image 2: JY-3G Remote Control with labeled button functions. This image clearly indicates the purpose of each button on the remote control.

- **Power Button (Red Circle with Line):** Turns the electric fireplace ON or OFF.
- **Side Light Button (Light Bulb Icon):** Controls the side lighting feature of the fireplace.
- **Ember Bed Button (Ember Bed Icon):** Adjusts or activates the ember bed effect.
- **Flame Button (Flame Icon):** Controls the flame effect settings (e.g., intensity, color).
- **Heater Button (Thermometer Icon):** Activates or deactivates the heater function.

- **Heater On/Off Switch (Wavy Lines Icon)**: Toggles the heater power.
- **Timer Button (Clock Icon)**: Sets or adjusts the fireplace's timer function.

Point the remote control directly towards the infrared receiver on your electric fireplace for optimal performance. Ensure there are no obstructions between the remote and the fireplace.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's range decreases or it stops responding. Follow the battery installation steps in Section 2.1.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

4.3 Storage

When not in use for extended periods, remove the batteries to prevent leakage and store the remote in a cool, dry place away from direct sunlight.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	• Dead or incorrectly installed batteries. • Obstruction between remote and fireplace. • Remote is out of range.	• Replace batteries, ensuring correct polarity. • Remove any objects blocking the signal path. • Move closer to the electric fireplace.
Specific functions not working.	• Fireplace not powered on. • Fireplace feature not active or available.	• Ensure the electric fireplace is powered on. • Refer to your fireplace's manual to confirm feature availability.
Remote does not work at all.	• Incorrect remote model. • Remote is faulty.	• Verify your original remote was JY-3G. This remote is not compatible with JY-3A or JY-3B. • Contact customer support if all other troubleshooting steps fail.

6. Specifications

Model: JY-3G

Brand: YING RAY

Item Weight: 1.06 ounces

Package Dimensions: 0.39 x 0.2 x 0.08 inches

Special Feature: Ergonomic design

Max Number of Supported Devices: 1

Compatible Devices: Ghp Pleasant Hearth Electric Fireplaces (specifically those using JY-3G remote)

Connectivity Technology: Infrared (IR)

Manufacturer: ZHUHAI YINGRAY TRADING CO., LTD.

Date First Available: September 5, 2022

7. Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For warranty details or technical support, please contact the seller, YING RAY, directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question