

FULLJA 10F8-Z

FULLJA Digital Photo Frame 10.1 Inch (Model 10F8-Z) User Manual

Your guide to setting up and using your FULLJA Digital Photo Frame.

1. INTRODUCTION

The FULLJA 10.1 Inch Smart Cloud Digital Picture Frame offers a vibrant display and seamless photo sharing capabilities. This manual provides comprehensive instructions to help you set up, operate, and maintain your digital photo frame, ensuring you can easily share and enjoy your cherished memories.



Figure 1: The FULLJA Digital Photo Frame showcasing a family picture, alongside a smartphone demonstrating the photo sharing application.

2. PRODUCT FEATURES

- **Display:** 10.1 Inch FHD 1920x1200 IPS Touch Screen (16:10 ratio) for vivid picture display without distortion.
- **Connectivity:** Dual-WiFi support (2.4GHz + 5GHz) for seamless cloud connectivity.
- **Storage:** Built-in 32GB memory, expandable with an SD Card (max 64GB).
- **Sharing:** Instant sharing of photos and short videos via the VPhoto app, email, or PC Manager.
- **Functions:** Picture, Video, Movie, Music, Background Music, Slideshow, Clock, Calendar, Weather Station, and Motion Sensor.
- **Privacy:** Advanced transmission technology and world-famous cloud platform support for secure and encrypted data transfer.

3. SETUP GUIDE

3.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- FULLJA Digital Photo Frame
- Power Adapter

- User Manual (this document)
- Desktop Stand/Bracket

3.2 Powering On and Basic Configuration

1. Connect the power adapter to the frame and a power outlet.
2. The frame will automatically power on. Follow the on-screen prompts to select your preferred language.
3. Connect the frame to your Wi-Fi network by selecting your network and entering the password. The frame supports both 2.4GHz and 5GHz networks.

3.3 App Download and Pairing

To share photos and videos remotely, download the **VPhoto app** on your smartphone (available on App Store and Google Play).

1. Open the VPhoto app and create an account.
2. On your FULLJA frame, tap the 'Add Friend' icon (often represented by a person with a plus sign) to generate a unique code.
3. In the VPhoto app on your smartphone, enter this code to pair your device with the frame.

Your browser does not support the video tag.

Video 1: Demonstrates the process of setting up the digital photo frame and connecting it to the companion app for photo sharing.

3.4 Mounting Options

The FULLJA Digital Photo Frame can be placed on a desktop or mounted on a wall.

- **Desktop Placement:** Attach the provided bracket to the back of the frame for stable desktop display. The frame supports both horizontal and vertical orientations.
- **Wall Mounting:** The frame features mounting holes on the back. Use appropriate screws (not included) to securely mount the frame to a wall.



Figure 2: Rear view of the digital photo frame, highlighting the detachable desktop stand and the integrated wall mounting points.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Touch Screen

The frame features an intuitive touch screen interface. Swipe left/right to browse photos, tap to access menus, and pinch to zoom.

4.2 Sharing Photos and Videos

Once your frame is paired with the VPhoto app, you can easily share media.

1. Open the VPhoto app on your smartphone.
2. Select the photos or videos you wish to send.
3. Choose your connected frame as the recipient. You can also add a caption to your media.
4. The media will instantly appear on the frame.

Your browser does not support the video tag.

Video 2: A step-by-step guide on how to send photos from your smartphone to the digital picture frame using the companion app.

4.3 Adding Friends and Family

You can invite friends and family to share photos directly to your frame.

1. On your FULLJA frame, tap the 'Add Friend' icon to generate a unique sharing code.
2. Share this code with your friends or family.
3. They will need to download the VPhoto app and enter this code to connect to your frame. Once connected, they can send photos and videos to your frame.

Your browser does not support the video tag.

Video 3: Instructions on how to add friends to your digital picture frame, allowing them to share photos and videos.

4.4 Slideshow and Display Settings

Customize your viewing experience through the frame's settings menu.

- **Slideshow:** Adjust the interval between photos, transition effects, and playback order (sequential or random).
- **Clock & Calendar:** Display current time and date.
- **Weather Station:** View local weather information.
- **Motion Sensor:** Enable the motion sensor to automatically turn the screen on/off when presence is detected, saving energy.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen. Avoid abrasive cleaners or solvents.
- **Software Updates:** The frame may receive periodic software updates. Ensure your frame is connected to Wi-Fi to receive these updates for optimal performance.
- **Storage Management:** Regularly review and delete unwanted photos/videos to manage the 32GB internal memory. Utilize an SD card (up to 64GB) for additional storage.

6. TROUBLESHOOTING

- **Frame Not Responding:** If the touch screen is unresponsive, try restarting the device by unplugging and replugging the power adapter. If the issue persists, locate the reset button (often a small pinhole)

and use a paperclip to perform a soft reset.

- **Cannot Connect to Wi-Fi:** Ensure your Wi-Fi password is correct and the frame is within range of your router. Try restarting your router and the frame.
- **Photos Not Uploading:** Verify that your frame is connected to Wi-Fi and the VPhoto app is properly paired. Check your internet connection.
- **Image Display Issues:** Ensure photos are in supported formats (BMP, JPG, GIF, PNG) and videos are in supported formats (MPEG-1, MPEG-2, MPEG-4, H.263, H.264, RV, etc., up to 1080p).

7. SPECIFICATIONS




| Feature | Detail |
|--------------------|----------------------------|
| Product Dimensions | 8.77 x 11.96 x 0.99 inches |
| Item Weight | 1.65 pounds |
| Item Model Number | 10F8-Z |
| Brand | FULLJA |
| Color | Dark Black |
| Resolution | 1080p (FHD 1920x1200 IPS) |
| Compatible Devices | iPhone (via VPhoto app) |
| Screen Size | 10.1 Inches |
| Internal Memory | 32GB |
| External Storage | SD Card (max 64GB) |











8. WARRANTY & SUPPORT

The FULLJA Digital Photo Frame comes with a one-year limited warranty. We also provide lifetime support and aim for a prompt response within 24 hours for any inquiries or issues.

For support, please refer to the contact information provided in your product packaging or visit the official FULLJA website.

Related Documents - 10F8-Z

| | |
|---|--|
|    | FULLJA Digital Photo Frame User Manual: Setup, Features, and Troubleshooting Comprehensive user manual for the FULLJA Digital Photo Frame. Learn about setup, features, Wi-Fi connectivity, app integration, media playback, settings, troubleshooting, and technical specifications. |
|---|--|

| | |
|--|---|
|    | <p>FULLJA Digital Photo Frame User Manual - Features, Setup, and Troubleshooting</p> <p>Comprehensive user manual for the FULLJA Digital Photo Frame (JT101M). Learn about setup, features, Wi-Fi connection, app usage, media playback, settings, troubleshooting, and technical specifications.</p> |
|    | <p>CVW SWIFT Z 5.5" Wireless Monitor User Manual</p> <p>User manual for the CVW SWIFT Z 5.5-inch wireless monitor, detailing its features, operation, technical specifications, and troubleshooting. Supports HDMI, 3D LUT, HDR, and 1080P60Hz wireless transmission.</p> |
|     | <p>SENECA Z-KEY Series Installation Manual</p> <p>Comprehensive installation guide for the SENECA Z-KEY series of industrial communication modules, detailing setup, configuration, technical specifications, and electrical connections.</p> |