

[Manuals.plus](#) /

› [Asuwish](#) /

› Asuwish Wallet Phone Case and Tempered Glass Screen Protector User Manual for Samsung Galaxy A10e

Asuwish Samsung Galaxy A10e

Asuwish Wallet Phone Case and Tempered Glass Screen Protector User Manual

FOR SAMSUNG GALAXY A10E (MODEL S102DL)

Brand: Asuwish

1. Introduction

This manual provides instructions for the proper installation, operation, and maintenance of your Asuwish Wallet Phone Case and Tempered Glass Screen Protector for the Samsung Galaxy A10e. Please read this manual thoroughly before use to ensure optimal performance and protection for your device.



Image 1.1: Overview of the Asuwish Wallet Phone Case and included Tempered Glass Screen Protector.

2. Package Contents

Verify that all items are present in your package:

- 1 x Asuwish Wallet Phone Case (Gray)
- 1 x Tempered Glass Screen Protector
- 1 x Detachable Wrist Strap

3. Compatibility

This product is specifically designed for the **Samsung Galaxy A10e** (Model S102DL). It is **not** compatible with other Samsung Galaxy models, including the Samsung Galaxy S10e.

Compatible with
Samsung Galaxy A10e only.



A10e



S10e

Image 3.1: Visual guide for device compatibility, confirming fit for Samsung Galaxy A10e only.

4. Setup

4.1. Installing the Phone Case

1. Ensure your Samsung Galaxy A10e is clean and free of dust.
2. Align the phone with the soft TPU inner shell of the case.
3. Gently press the phone into the case, starting from one corner, until it is securely seated. Ensure all buttons and ports align correctly.



TPU BUMPER

Soft TPU inner shell Provides your phone full body protection

Image 4.1: Demonstrating the flexible TPU bumper for easy phone installation and full body protection.

4.2. Installing the Tempered Glass Screen Protector

1. Clean your phone screen thoroughly using an alcohol wipe, then dry with a microfiber cloth. Ensure no dust particles remain.
2. Carefully peel off the protective film from the adhesive side of the tempered glass.
3. Align the screen protector precisely with your phone's screen, paying attention to cutouts for the camera and speaker.
4. Gently lower the screen protector onto the screen. It will adhere automatically.
5. If any bubbles appear, gently push them towards the edges of the screen using a soft cloth or squeegee.

4.3. Attaching the Wrist Strap

1. Locate the small metal loop on the top edge of the phone case.
2. Thread the thin loop of the wrist strap through this metal loop.
3. Pass the larger end of the wrist strap through the thin loop and pull gently to secure it.



Image 4.2: The detachable wrist strap attached to the phone case, also highlighting the case's shock resistance.

5. Operating Instructions

5.1. Using the Wallet Features

The wallet case is designed to consolidate your essentials. It includes:

- **Card Slots:** Six dedicated slots for credit cards, ID cards, or business cards.
- **Cash Bags:** One larger pocket behind the card slots for banknotes.
- **Zipper Coin Wallet:** A secure zippered compartment for coins or small items.
- **Photo Pocket:** A clear slot for a photo ID or a cherished picture.

Card pockets



Photo pocket

Cash slots

Zipper wallet

Image 5.1: Detailed view of the wallet's internal organization, including card slots, cash slots, photo pocket, and zipper wallet.



ZIPPER WALLET

Simplify your life and your pocket

Image 5.2: The zipper wallet compartment, demonstrating its capacity for coins and folded banknotes.

5.2. Using the Kickstand Feature

The case can be folded into a kickstand for hands-free viewing:

1. Open the wallet case fully.
2. Fold the back cover to create a triangular stand, positioning your phone at a comfortable viewing angle.
3. This feature is ideal for watching videos, making video calls, or reading.



RELEASE YOUR HANDS COMPLETELY EASY SUPPORT

Image 5.3: The phone case configured as a kickstand, providing a stable viewing angle.

6. Maintenance

6.1. Cleaning the Phone Case

To maintain the appearance and longevity of your leather wallet case:

- Wipe the exterior with a soft, damp cloth.
- For stubborn dirt, use a mild soap solution on the cloth, then wipe with a clean, damp cloth.
- Avoid harsh chemicals, abrasive cleaners, or excessive moisture.
- Allow the case to air dry completely before reinserting your phone.

6.2. Cleaning the Screen Protector

The tempered glass screen protector can be cleaned with a microfiber cloth to remove fingerprints and smudges.

7. Troubleshooting

7.1. Screen Protector Bubbles

If bubbles appear after installation:

- **Small Bubbles:** Often disappear on their own within 24-48 hours.
- **Large Bubbles:** Gently lift the nearest edge of the screen protector and reapply, pushing the bubble out with a soft cloth as you lay it back down. Ensure the screen is dust-free.

7.2. Cards Not Fitting in Slots

The card slots are designed for standard-sized cards. If cards feel too tight:

- The leather material may be stiff initially. It will soften and stretch slightly with use.
- Avoid overfilling the slots, as this can strain the material and prevent the case from closing properly.

8. Specifications

Brand	Asuwish
Compatible Phone Models	Samsung Galaxy A10e
Material	Leather, TPU
Form Factor	Flip Case
Special Features	Wallet with Card Holder, Zipper Pocket, Kickstand, Screen Protector, Detachable Wrist Strap
Item Weight	2.82 ounces

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Asuwish website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question