

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TRLIFE](#) /

› [TRLIFE Dimmable Wall Sconce User Manual](#)

## TRLIFE GogolS-Brs-2P

# TRLIFE Dimmable Wall Sconce User Manual

Model: GogolS-Brs-2P

## INTRODUCTION

---

Thank you for choosing the TRLIFE Dimmable Wall Sconce. This manual provides important information regarding the installation, operation, and maintenance of your new wall lights. Please read this manual thoroughly before installation and retain it for future reference.

The TRLIFE gooseneck wall sconce features a dimmer knob switch and a 6ft plug-in cord, offering a simple yet elegant design with a vintage and industrial aesthetic. It is ideal for various indoor settings such as bedrooms, living rooms, bedside areas, and stairways.

## SAFETY INFORMATION

---

Please observe the following safety precautions to prevent injury or damage:

- Always disconnect power before installing, cleaning, or servicing the fixture.
- This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Ensure the voltage supply (110V/120V) matches the fixture's requirements.
- Use only dimmable LED bulbs with an E26 base, as specified.
- Do not attempt to modify the fixture. Any modifications may void the warranty and pose a safety risk.
- Keep away from flammable materials.
- If you are unsure about any part of the installation, consult a qualified electrician.

## PACKAGE CONTENTS

---

Verify that all components are present and undamaged before beginning installation:

- 2 x Dimmable Wall Sconces with Plug-in Cord
- 2 x Dimmable A19 LED Bulbs (E26 base, 6W, 2700K Warm White, 620 Lumens)
- 2 x Packet of Mounting Hardware
- 8 x Adhesive Wire Clips
- 1 x Installation Guide (this manual)



Image: Contents of the TRLIFE Wall Sconce package, showing two sconces, two LED bulbs, and power cords.

## PRODUCT OVERVIEW AND FEATURES

---

The TRLIFE Wall Sconce is designed for versatility and ease of use. Key components and features include:

- **Brushed Brass Finish:** The entire lamp body features a modern and elegant brushed brass finish.
- **White Lampshade Interior:** The inside of the lampshade is white to enhance light reflection and brightness.
- **Dimmable Knob Switch:** Located on the backplate for easy on/off control and brightness adjustment (0-100%).
- **E26 Base Light Socket:** UL listed, compatible with standard E26 base bulbs.
- **6ft Plug-in Cord:** Provides flexible power options with an in-line on/off switch.
- **Adjustable Lamp Head:** The lamp head can be adjusted 90 degrees up and down and swung 350 degrees left to right, allowing for flexible lighting direction.



Image: Detailed view of the sconce components, highlighting the brass finish, E26 socket, and included bulb.

# Flexible Adjust Lighting Directions



Swing left and right 350°



Image: Illustration of the flexible adjustment capabilities of the lamp head, including 350-degree rotation and 90-degree tilt.

## SETUP AND INSTALLATION

The TRLIFE Wall Sconce offers two installation options: Plug-in or Hardwire. Choose the method that best suits your needs.

### Option 1: Plug-in Installation (Recommended for ease of use)

1. **Choose Location:** Select a desired location on your wall near an electrical outlet.
2. **Mark Drilling Points:** Hold the sconce's backplate against the wall and mark the positions for the mounting screws.
3. **Drill Holes:** Drill pilot holes at the marked positions. Insert wall anchors if necessary (for drywall).
4. **Mount Backplate:** Secure the sconce's backplate to the wall using the provided mounting screws.
5. **Install Bulb:** Carefully screw the provided dimmable LED bulb into the E26 socket.
6. **Plug In:** Plug the 6ft power cord into a standard 110V/120V electrical outlet.
7. **Manage Cord:** Use the included adhesive wire clips to neatly secure the power cord along the wall, if desired.

## Option 2: Hardwire Installation (Requires electrical knowledge)

**WARNING:** Hardwiring should only be performed by a qualified electrician or a person with adequate knowledge of electrical wiring. Always turn off power at the circuit breaker before beginning.

1. **Disconnect Power:** Turn off the main power supply to the junction box at your circuit breaker.
2. **Remove Plug-in Cord:** Carefully remove the plug-in cord from the sconce. This typically involves disconnecting it from the internal wiring connections within the backplate.
3. **Prepare Wires:** Strip the ends of the house electrical wires (live, neutral, ground) if necessary.
4. **Connect Wires:** Connect the sconce's wires to the house wires:
  - Black (Live) to Black (Live)
  - White (Neutral) to White (Neutral)
  - Green or Bare Copper (Ground) to Green or Bare Copper (Ground)

Secure connections with wire nuts.

5. **Mount Sconce:** Secure the sconce's backplate to the wall or junction box using the provided mounting hardware.
6. **Install Bulb:** Carefully screw the provided dimmable LED bulb into the E26 socket.
7. **Restore Power:** Turn the power back on at the circuit breaker.

# 2 in 1 Design

## Option 1



## Plug-in

## Option 2



## Hardwire

Image: Comparison of Plug-in and Hardwire installation methods.

## OPERATING INSTRUCTIONS

Using your TRLIFE Dimmable Wall Sconce is straightforward:

### 1. Power On/Off:

- If using the plug-in cord, use the in-line on/off switch located on the cord.
- Alternatively, rotate the dimmer knob switch on the sconce's backplate clockwise until it clicks to turn the light ON, and counter-clockwise until it clicks to turn the light OFF.

2. **Adjust Brightness:** Once the light is on, rotate the dimmer knob switch on the backplate clockwise to increase brightness (up to 100%) and counter-clockwise to decrease brightness (down to 0%).

3. **Adjust Lighting Angle:** The lamp head can be manually adjusted. Gently tilt it up or down 90 degrees, or swing it left or right 350 degrees to direct the light as desired.

# Fully Dimmable Wall Sconce



0 100%

## Dimming 0-100%

Simply turn the dimmer knob on/off switch to turn on/off light and adjust light brightness 0-100%




Image: Demonstration of the dimmer knob operation and various brightness levels.

## MAINTENANCE

To ensure the longevity and optimal performance of your TRLIFE Wall Sconce, follow these maintenance guidelines:

- **Cleaning:** Always disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure the fixture is unplugged or power is off at the breaker before replacing the bulb. Allow the bulb to cool completely before handling. Replace with an E26 base, dimmable LED bulb (max 60W equivalent incandescent).
- **Inspection:** Periodically check the power cord for any signs of damage or fraying. If damage is found, discontinue use and contact customer support.

## TROUBLESHOOTING

If you encounter issues with your TRLIFE Wall Sconce, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	<ul style="list-style-type: none"> <li>No power to the outlet/fixture.</li> <li>Bulb is loose or faulty.</li> <li>Dimmer knob is in the OFF position.</li> </ul>	<ul style="list-style-type: none"> <li>Check power outlet, circuit breaker, or wall switch.</li> <li>Tighten or replace the bulb.</li> <li>Rotate the dimmer knob clockwise until it clicks ON.</li> </ul>
Light flickers or dims unexpectedly.	<ul style="list-style-type: none"> <li>Bulb is not dimmable or incompatible.</li> <li>Loose bulb connection.</li> <li>Faulty dimmer switch.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure you are using the provided dimmable LED bulb or a compatible dimmable E26 LED bulb.</li> <li>Tighten the bulb.</li> <li>Contact customer support if the dimmer switch is suspected to be faulty.</li> </ul>
Fixture is hot to the touch.	<ul style="list-style-type: none"> <li>Incorrect bulb wattage used.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure bulb wattage does not exceed the recommended 60W equivalent. Use only LED bulbs.</li> </ul>

## SPECIFICATIONS

Attribute	Detail
Brand	TRLIFE
Model Number	GogolS-Brs-2P
Material	Metal with Brushed Brass Finish
Style	Modern and Elegant, Industrial
Voltage	110V/120V
Bulb Type (Included)	A19 Dimmable LED Bulb (E26 Base)
Bulb Wattage	6W (Equivalent to 60W Incandescent)
Bulb Color Temperature	2700K Warm White
Bulb Brightness	620 Lumens
Dimming Range	0-100%
Cord Length	6 FT (1.83 meters)
Product Dimensions	29.97 x 19.56 x 13.97 cm (11.8 x 7.7 x 5.5 inches)
Item Weight	1.73 kg (3.81 lbs)
Indoor/Outdoor Usage	Indoor Only




Image: Dimensional drawing of the TRLIFE Wall Sconce.

## WARRANTY AND SUPPORT

TRLIFE products are manufactured with quality and durability in mind. For specific warranty details, please refer to the warranty card included in your package or visit the official TRLIFE website. If you have any questions, require technical assistance, or need to report a defect, please contact TRLIFE customer support through the retailer where you purchased the product or via the contact information provided on the official TRLIFE website.

Please have your model number (GogolS-Brs-2P) and purchase date ready when contacting support.