

## Timex TW2V40800QY

# Timex Expedition North Ridge 41mm Watch User Manual

Model: TW2V40800QY

## INTRODUCTION

This manual provides comprehensive instructions for the Timex Expedition North Ridge 41mm Watch, model TW2V40800QY. Please read this manual thoroughly to understand the watch's features, operation, and maintenance procedures. Proper use and care will ensure the longevity and optimal performance of your timepiece.

## PRODUCT OVERVIEW

The Timex Expedition North Ridge 41mm Watch is designed for durability and functionality, featuring a robust case, a clear dial, and essential timekeeping functions. Key features include:

- **Case Size:** 41mm case diameter.
- **Crystal:** Mineral glass crystal for durability.
- **Strap:** Adjustable 20mm silicone strap, fitting up to an 8-inch wrist circumference.
- **Dial:** Full numerals for easy readability, with a date window located at the 3 o'clock position.
- **Illumination:** Indiglo light-up watch dial and luminous hands for visibility in low light conditions.
- **Water Resistance:** Water-resistant to 100 meters (330 feet), suitable for snorkeling and swimming, but not for diving.



Figure 1: Front view of the Timex Expedition North Ridge 41mm Watch. This image displays the watch face with its blue dial, white numerals, and red accents, along with the blue silicone strap.



*Figure 2: Top-down view of the watch strap. This image shows the blue silicone strap and its buckle mechanism.*

## SETUP

---

### Setting the Time

1. **Pull out the crown:** Locate the crown on the right side of the watch case. Gently pull it out to the outermost position. The second hand will stop, indicating the watch is in time-setting mode.
2. **Rotate the crown:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time. Ensure you set the correct AM/PM by observing the date change (the date will change around midnight).
3. **Push in the crown:** Once the time is set, push the crown back into its normal operating position. The second hand will resume movement.

## Setting the Date

1. **Pull out the crown to the middle position:** Gently pull the crown out to the first click position.
2. **Rotate the crown:** Turn the crown counter-clockwise (or as indicated by your specific model) to adjust the date in the date window.
3. **Push in the crown:** Once the date is set, push the crown back into its normal operating position.

***Note:** Avoid setting the date between 9:00 PM and 3:00 AM, as this can interfere with the automatic date change mechanism and potentially damage the movement. If the date needs adjustment during this period, first set the time outside this range, adjust the date, then reset the time.*

## OPERATING INSTRUCTIONS

---

### Using Indiglo Night-Light

The Indiglo night-light illuminates the entire watch dial for easy reading in low-light conditions. To activate Indiglo, simply press and hold the crown. The light will remain on as long as the crown is pressed.

### Water Resistance

Your Timex Expedition North Ridge watch is water-resistant to 100 meters (330 feet). This rating means it is suitable for recreational swimming, showering, and snorkeling. It is **not** designed for scuba diving or high-impact water sports. Always ensure the crown is fully pushed in before exposing the watch to water.

- **100m (330 ft):** Suitable for snorkeling, swimming, and showering.
- **Caution:** Do not operate the crown or pushers while the watch is wet or submerged.



*Figure 3: Side view of the watch. This image highlights the watch's profile, including the crown used for setting time and date, and the textured design of the silicone strap.*

## MAINTENANCE

---

### Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and strap with a soft, damp cloth. For silicone straps, mild soap and water can be used, followed by thorough rinsing and drying. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

### Battery Replacement

The watch is powered by one Lithium Metal battery (included). When the watch stops or the Indiglo light dims significantly, it indicates that the battery needs replacement. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

### Storage

When not in use for extended periods, store your watch in a cool, dry place away from direct sunlight and

extreme temperatures. Avoid storing it near magnetic fields, which can affect the watch's accuracy.



Figure 4: Back view of the watch. This image shows the stainless steel case back with engraved details and how the silicone strap connects to the watch case.

### TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Low battery.	Replace the battery. Consult a professional watch technician.

Problem	Possible Cause	Solution
Indiglo light is dim or not working.	Low battery.	Replace the battery.
Date does not change at midnight.	Time is set to PM instead of AM, or date was set during restricted hours.	Adjust the time to the correct AM/PM. If necessary, reset the date outside the 9 PM - 3 AM window.
Condensation inside the watch.	Temperature changes or compromised water resistance.	Seek immediate professional service to prevent internal damage. Ensure crown is always fully pushed in.







## SPECIFICATIONS

- **Model Number:** TW2V40800QY
- **Case Diameter:** 41mm
- **Case Material:** Not explicitly stated, but typically stainless steel or a durable alloy for Expedition series.
- **Crystal Material:** Mineral Glass
- **Strap Material:** Silicone
- **Strap Width:** 20mm
- **Water Resistance:** 100 meters (330 feet)
- **Movement:** Quartz
- **Battery Type:** 1 Lithium Metal battery (included)
- **Illumination:** Indiglo Night-Light, Luminous Hands
- **Functions:** Hour, Minute, Second, Date
- **Product Dimensions:** 1.57 x 3.94 x 2.36 inches
- **Item Weight:** 8.82 ounces

## WARRANTY AND SUPPORT

Timex watches are covered by a limited warranty against manufacturing defects. For specific warranty details, registration, and service inquiries, please refer to the warranty card included with your purchase or visit the official Timex website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact Timex customer support through their official website or authorized service centers. Contact information can typically be found on the Timex website or in the packaging materials.

	<p><a href="#">Timex W-209 Watch User Manual: Features, Operation, and Warranty</a></p> <p>Comprehensive guide to operating your Timex W-209 watch, covering time setting, chronograph, timer, alarms, occasions, INDIGLO night-light, water resistance, battery, and international warranty information.</p>
	<p><a href="#">Timex Watch User Manual: Features, Operation, and Care</a></p> <p>Comprehensive user manual for Timex watches, detailing features like analog and digital time, multiple time zones, alarms, chronographs, timers, water resistance, and bracelet adjustment.</p>
	<p><a href="#">Timex Combo Watch User Manual and Guide</a></p> <p>Comprehensive user manual and guide for the Timex Combo Watch, covering features, basic operation, time setting, stopwatch, alarm, INDIGLO night-light, water and shock resistance, battery replacement, and international warranty.</p>
	<p><a href="#">Timex Expedition Digital Watch User Manual</a></p> <p>Comprehensive user manual for the Timex Expedition Digital watch, covering functions, basic operations, time and date settings, alarm, timer, chronograph, INDIGLO night-light, water resistance, and battery information.</p>
	<p><a href="#">Timex Expedition World Time Digital Watch User Manual</a></p> <p>Comprehensive user guide for the Timex Expedition World Time Digital watch, covering time setting, world time functionality, chronograph, countdown timer, alarms, INDIGLO night-light, water resistance, and battery care.</p>
	<p><a href="#">Timex Ironman 10/30/50 Lap/Transit Watch User Manual and Guide</a></p> <p>Comprehensive user manual and guide for the Timex Ironman 10, 30, and 50 Lap/Transit digital sports watch, covering basic operation, chronograph, timer, alarm, INDIGLO night-light, water resistance, battery, and warranty information.</p>